

Innholdsfortegnelse - Vedlegg

A.1 Oversikt over notifikasjoner i perioden 1.januar til 31.mars.....	2
A.2 Oversikt over høykriske notifikasjoner i perioden 1.januar til 31.mars	20
A.3 Notifikasjoner - System.....	22
A.31 Notifikasjoner/høykriske notifikasjoner - System.....	22
A.32 Notifikasjoner/høykriske notifikasjoner - System, statistikk.....	23
A.33 Oversikt over Systemer - Beskrivelse	24
A.4 Notifikasjoner - Lokasjon.....	25
A.41 Notifikasjoner/høykriske notifikasjoner - Lokasjon	25
A.42 Notifikasjoner/høykriske notifikasjoner - Lokasjon, statistikk	26
A.43 Oversikt over Lokasjoner - Beskrivelse	27
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	28
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	29
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	30
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	31
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	32
A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse.....	33
A.5 Notifikasjoner - Arbeidsgruppe	34
A.51 Notifikasjoner/høykriske notifikasjoner - Arbeidsgruppe	34
A.52 Notifikasjoner/høykriske notifikasjoner - Arbeidsgruppe, statistikk	35
A.53 Oversikt over Arbeidsgrupper - Beskrivelse.....	36
A.53 Fortsettelse: Oversikt over Arbeidsgrupper - Beskrivelse	37
A.53 Fortsettelse: Oversikt over Arbeidsgrupper - Beskrivelse	38
A.6 Notifikasjoner - Planleggingsgruppe	39
A.61 Notifikasjoner/høykriske notifikasjoner - Planleggingsgruppe.....	39
A.62 Oversikt over Planleggingsgrupper - Beskrivelse	39
A.7 Oversikt Etterslep - MiS	40
7.1 Oversikt, Etterslep - Timer Forebyggende Vedlikehold og Antall Korrektivt Vedlikehold	40
7.2 Oversikt, Etterslep - Sikkerhetskritisk Vedlikehold	41
A.8 CMR Sikkerhetskritisk Korrektivt Vedlikehold - 30 dager	42
A.8 Fortsettelse: CMR Sikkerhetskritisk Korrektivt Vedlikehold - 30 dager.....	43

A.1 Oversikt over notifikasjoner i perioden 1.januar til 31.mars

Functional loc.	Location	System	Main WorkCtr	Priority	ABC indic.	Failure Impact	Notification	Description	Notifictn type	Order	Planner group
1220						U	42411514	Defekt fastmontert radio i drillerbu	M2		PPM
1220-00		00	C01STE	U	A	U	42364478	Lage skiltramme til kjeledress vogner	M2	21996727	SOP
1220-00	D33	00	C32SUR	U	A	U	42467125	Male gule/svarte striper mellom kjeledre	M2	22065567	SSF
1220-00		00	POMPRO	U	A	U	42341362	Assistanse til reingjøring i D&V områder	M2	21968861	PPM
1220-00		00	POMPRO	U	A	U	42360871	Forbruksmateriell til RS1 11	M2	21988701	SOP
1220-00		00	POMPRO	L	A	U	42370703	Støtte til oppdatere master arkiv SKR	M2	21996522	SOP
1220-00		00	POMPRO	U	A	U	42421468	Carseal prosjektet, sikre ventiler	M2	22027885	SOP
1220-00		00	PPMMEC	U	A	U	42346571	Årsbestilling av TESS	M2	21972601	SOP
1220-1 1/2"-WF-71C116-CM1	W41	71	C01PIP	U	3	U	42467846	Utbedre midlertidig fikset deluge linje	M2	22065562	SVM
1220-1 1/2"-WF-71C116-CM1	W41	71	POMMEC	H	3	D	42464877	Delugerer er brukket i unionkobling.	M2	22064263	POM
1220-1"-WD-53B212-CS1	U45	53	C01PIP	U	6	U	42421377	Avsaltet vann. Rør til US-U55-02 defekt	M2	22027882	SOP
1220-1"-WS-50C128-CM1	W13	50	C43ISP	M	3	S	42461980	Lekkasje på sjøvannsrør på W-15.	M2	22062607	SIP
1220-10"-DO-56A491-CC2	P33	56	PPMISP	U	3	U	42467782	FUNN: Korrosjon på 10"-DO-56A491-CC2	M2		SPI
1220-10"-PL-20C803-CM1		20	PPMMEC	M	3	S	42467081	Oljelekkasje fra plugg på tilbakeslagsve	M2	22065559	SOP
1220-10A-BC30A	W08	10	C43ISP	L	N	U	42443961	NDT av Fast line sheaves	M2	22059903	SIP
1220-10B-HA01B	W07	10	PPMMEC	M	N	S	42341687	Ventil ut av kjøler er ødelagd(Drawwork)	M2	21996534	SOP
1220-10C-BC16	W08	10	C01STE	U	N	U	42417167	Sveising av nye tannstenger ----->>	M2	22025764	SDW
1220-10C-BC16	W08	10	POMLOG	U	N	U	42434190	Lage skilt til Odffell HMS koordinator	M2	22042948	POM
1220-10G-BM02B	W07	10	XODTLNSA	U	N	U	42407693	SNHAP aktivitet skidddebeamer	M2		SDW
1220-11A-VL01	D43	11	C43ISP	L	N	U	42340672	Ultralyd på surge tanker.	M2	21968859	SIP
1220-11D-LE 202	T31	11	POMAUT	M	N	S	42360549	Nivåmåling baseolje har gått tett igjen.	M2	21988223	POM
1220-11D-LI 202D	N31	11	POMAUT	L	N	S	42413597	Nivåsensor virker Ustabil ----->	M2		POM
1220-11D-LI 202D	N31	11	PPMAUT	L	N	S	42424876	Nivåsensor virker Ustabil ----->	M2	22030492	SOP
1220-11D-LT 202	T31	11	PPMAUT	L	N	S	42345805	Feil på sensor i 11D-TB01 RUH 1199515	M2	21972558	SOP
1220-11F-JU19	D33	11	JMOAUTSA		N	S	42413895	Matestasjoner mixeanlegg virker ikke---->	M2	22022264	SOP
1220-11G-TB11	D55	11	POMMEC		N	U	42467077	Hyd.lekkasje på kakseanlegg D55	M2		POM
1220-12"BAD2-002	P31	21	PPMMEC	U	5	U	42437336	Liten ekstern lekkasje	M2	22044479	SOP
1220-12"BL1E31G-001	W35	21	PPMMEC	L	Z	S	42372922	12"ventil står fast. (RS1 11)	M2	21997095	SOP
1220-12"-PW-20C810-CM1	P23	20	PPMISP	M	3	S	42410651	FUNN: 12" kuleventil henger i kjetting	M2		SOP
1220-13C		13	PPMMEC	U	A	U	42348667	Montere bonnet bleeder alle Xmas 3	M2	21978545	SOP
1220-13C-JB06B	W23	13	PPMMEC	L	2	S	42409971	Ser ut som der er for mye erifon på B-cy	M2	22021587	SOP
1220-13C-JB19C	W23	13	POMAUT	L	2	S	42352636	Løst erifon nivå på sylinder C P-19	M2	21982289	POM
1220-13C-JB19C	W23	13	PPMMEC	L	2	S	42339956	Boks C P19 tom for erifon	M2	21967981	SOP
1220-13C-JB27A	W43	13	PPMMEC	U	2	U	42339870	Tention Sylinder tom for erifon	M2	21967987	SOP
1220-13C-JB27A	W43	13	PPMMEC	M	2	D	42340193	Tensjon sylinder A mangler erifon.	M2	21967891	SOP
1220-13C-JB40B	W43	13	PPMAUT	M	2	D	42340117	Lekk nitrogensslange til manometer.	M2	21967893	SOP
1220-13C-JB40C	W43	13	PPMMEC	M	2	S	42403051	Lekkasje i tensionboks C brønn P40	M2	21998409	SOP
1220-13C-PT 062	W23	13	PPMAUT	M	2	D	42461569	PT viser feil i forhold til lokal PI.	M2	22061053	SOP
1220-13C-PT 221	W33	13	PPMAUT	U	2	U	42419065	BRØNN NR 22 skifte 4 trykk transmitter f	M2	22026450	SOP
1220-13C-PT 261	W33	13	PPMAUT	U	2	U	42419066	BRØNN NR 26 skifte 4 trykk transmitter f	M2	22026449	SOP
1220-13C-PT 381	W43	13	PPMAUT	U	2	U	42419122	BRØNN NR 38 skifte 4 trykk transmitter f	M2	22026446	SOP
1220-13C-PT 391	W43	13	PPMAUT	U	2	U	42419123	BRØNN NR 39 skifte 4 trykk transmitter f	M2	22026445	SOP
1220-13C-PT 411	W43	13	PPMAUT	U	2	U	42419125	BRØNN NR 41 skifte 4 trykk transmitter f	M2	22026443	SOP
1220-13C-PT 421	W43	13	PPMAUT	U	2	U	42419124	BRØNN NR 42 skifte 4 trykk transmitter f	M2	22026444	SOP
1220-13C-R07		13	POMPRO	U	3	U	42461450	P-07 Pumpe silikat, Ref 09210	M2	22060800	SOP
1220-13C-R39		13	POMPRO	U	3	U	42462916	P-39 P&A. Ref 09330	M2	22061816	SOP
1220-13C-R41	R41	13	POMPRO	U	3	U	42445979	P-41 Mill & PLT Ref. 07790	M2	22060298	SOP
1220-13C-RT03	W23	13	PPMMEC	U	3	U	42437305	Rek tension sylinder fra Natoil	M2	22043592	POM
1220-13C-RT07	W23	13	PPMMEC	U	3	U	42355717	Utskiftning av sylindre og akkumulatører	M2	21984280	SOP
1220-13C-RT08	W23	13	PPMMEC	U	3	U	42355718	Utskiftning av sylindre og akkumulatører	M2	21984279	SOP
1220-13C-RT24	W33	13	PPMMEC	U	3	U	42355719	Utskiftning av sylindre og akkumulatører	M2	21984058	SOP
1220-13C-RT33	W43	13	POMMEC	H	3	D	42427197	P33 Tensionsylinder C lekker ut PSV.	M2	22031791	POM
1220-13C-RT34	W43	13	PPMMEC	U	3	U	42355720	Utskiftning av sylindre og akkumulatører	M2	21984057	SOP

1220-13C-RV03	W23	13	POMPRO	U	3	U	42343130	Sleeve operering P-03 (Baker sleeve)	M2	21970021	SOP
1220-13C-RV03	W23	13	POMPRO	U	3	U	42409987	P-03: lekkasje sjekk + sleeve operering	M2	22019328	SOP
1220-13C-RV03	W23	13	POMPRO	U	3	U	42436683	Studie fra DNV på økt gass inj. trykk	M2	22043411	SOP
1220-13C-RV03	W23	13	POMPRO	U	3	U	42466282	Driftsstøtte P-03	M2	22064620	SDW
1220-13C-RV06	W23	13	C01STE	U	3	U	42419238	Mangler sparkebord rundt tension syl.	M2	22026197	SOP
1220-13C-RV06	W23	13	POMPRO	U	3	U	42403000	Pumpe LVP som forkant til ny opprensing	M2	21998298	SOP
1220-13C-RV06	W23	13	PPMMEC	U	3	U	42425453	P06 Sjøkk passiv brannbeskyttelse.	M2		SOP
1220-13C-RV06	W23	13	PPMSUB	M	3	S	42348080	Steng VX ventil subsea brønnhode e 14 dg	M2	21977939	SOP
1220-13C-RV07	W23	13	POMPRO	U	3	U	42341283	P-07: Vanninjeksjonstest	M2	21969039	SOP
1220-13C-RV07	W23	13	POMPRO	U	3	U	42341323	Reservoartrykkmåling: P-07	M2		POM
1220-13C-RV07	W23	13	POMPRO	U	3	U	42341326	Reservoartrykkmåling: P-07	M2	21968863	SOP
1220-13C-RV07	W23	13	POMPRO	U	3	U	42355142	Silikatpilot P-07	M2	21983437	SOP
1220-13C-RV08	W23	13	C01STE	U	3	S	42408809	Stag til plattform for ringromsventiler	M2	22019281	SVM
1220-13C-RV08	W23	13	POMPRO	U	3	U	42353496	Reservoartrykkmåling P-08	M2	21982980	SOP
1220-13C-RV08	W23	13	POMPRO	U	3	U	42467535	P-8 LVP pumping	M2	22065564	SOP
1220-13C-RV09	W23	13	PPMAUT	U	3	U	42361184	Utføre testing av responstid og oppløsni	M2	21988770	SOP
1220-13C-RV11	W23	13	PPMMEC	U	3	U	42354563	Flytte jumper fra PxxHOLD	M2		SOP
1220-13C-RV13	W23	13	POMPRO	U	3	U	42469242	P-13 Reservoartrykkmåling	M2	22066402	SOP
1220-13C-RV17	W23	13	PPMMEC	U	3	U	42464309	Installere WI manifoldventil P17	M2	22064274	SOP
1220-13C-RV18	W23	13	POMPRO	U	3	U	42352597	P-18 Reservoartrykk måling (50 m² LVP)	M2	21982403	SOP
1220-13C-RV18	W23	13	POMPRO	U	3	U	42359084	P-18A Straddle/logging Ref 09030	M2	21987063	SOP
1220-13C-RV18	W23	13	POMPRO	U	3	U	42426900	P-18 Reservoartrykk måling (50 m² LVP)	M2	22031958	SOP
1220-13C-RV19	W23	13	POMPRO	U	3	U	42415004	Reservoartrykkmåling P-19	M2	22023626	SOP
1220-13C-RV27	W43	13	POMPRO	U	3	U	42342824	Sleeveoperasjon P-27A	M2	21969865	SOP
1220-13C-RV27	W43	13	POMPRO	U	3	U	42408019	P-27A: Sleeveoperasjon og testing	M2	22004183	SOP
1220-13C-RV27	W43	13	PPMMEC	M	3	S	42346046	Brønn i produksjon mangler PBB	M2	21972221	SOP
1220-13C-RV35	W43	13	POMPRO	U	3	U	42349368	Åpne og stenge sleeve i P-35A	M2	21978975	SOP
1220-13C-RV38	W43	13	POMPRO	U	3	U	42469244	P-38 Reservoartrykkmåling	M2	22066401	SOP
1220-13C-RV39	W43	13	C43ISP	M	3	S	42362918	Erosjon-utsatte områder på jumper, P39	M2	21990316	PPM
1220-13C-RV39	W43	13	PPMMEC	H	3	D	42411212	Lekkasje i bleedport i HYD.ving huset	M2	22019240	POM
1220-13C-RV52	W23	13	C43ISP	U	3	U	42438725	Måling av veggykkelse prod rør WAG inj.	M2	22044467	SIP
1220-13C-RV56	W23	13	C32SUR	U	3	U	42425740	Skade på chartek / Riser P-06 i W21	M2	22031117	SSF
1220-13C-RV56	W23	13	POMPRO	U	3	U	42466440	Oppsprekking av nederste sone (sone 3)	M2	22064835	SOP
1220-13C-RV60	W23	13	PPMMEC	U	3	U	42430469	P-10A konvertering fra gass til vann	M2	22035754	SOP
1220-13C-RV66	W23	13	PPMMEC	U	3	U	42430471	P-16 konvertering fra vann til gass	M2	22035753	SOP
1220-13C-RV70	W23	13	POMMEC	U	3	U	42439604	P-20 Konvertering fra gass til vann	M2	22044805	SOP
1220-13C-RV72	W33	13	POMPRO	U	3	U	42350582	P-22A Sleeve operering når gass inj	M2	21979495	SOP
1220-13C-RV82	W43	13	PPMMEC	U	3	U	42356668	P-32A Konvertere fra gass til vann	M2	21986162	SOP
1220-13C-RV84	W43	13	POMPRO	U	3	U	42414284	P-34 Konvertering fra vann til gass	M2	22022722	SOP
1220-13C-RV84	W43	13	POMPRO	U	3	U	42466696	Reservoartrykkmåling P-34	M2	22064985	SOP
1220-13C-RV87	W43	13	PPMAUT	M	3	S	42340121	Det er ikke et eneste tag nr på brønn.	M2	21977945	SOP
1220-13C-WX 061	W23	13	IMOAUTSA	U	2	U	42353164	Vektmålingen for brønn P06 er feil.	M2	21982401	SOM
1220-13C-WX 131	W23	13	PPMAUT	U	2	U	42419063	BRØNN NR 13 skifte 4 trykk transmitter f	M2	22026451	SOP
1220-13C-WX 281	W43	13	PPMAUT	U	2	U	42419068	BRØNN NR 28 skifte 4 trykk transmitter f	M2	22026448	SOP
1220-13C-WX 282	W43	13	PPMAUT	L	2	S	42461637	Feil på manometer eller PT, Stort awik.	M2	22060816	SOP
1220-13C-WX 331	W43	13	PPMAUT	U	2	U	42419069	BRØNN NR 33 skifte 4 trykk transmitter f	M2	22026447	SOP
1220-13C-WX 341	W43	13	PPMAUT	U	2	U	42419071	BRØNN NR 34 skifte 4 trykk transmitter f	M2	22026452	SOP
1220-13F-PT 441	R44	13	PPMAUT	M	2	D	42406802	P-44 DHPG stoppet	M2	22002624	SOP
1220-14"-VF-20B018-CM1	P35	20	C32ISU	M	3	S	42403849	Løsnet isolasjo i gjennomføring P-33	M2	22000992	SSF
1220-14"-WS-11G029-DC1	W23	11	C43ISP	L	N	U	42421939	Utspyling av rør for videoinsp.----->>	M2	22030491	SIP
1220-16"GAH8-001	W13	51	PPMMEC	L	2	S	42409394	Defekt gir på ventil -> Fjerne ratt	M2	22021595	SOP
1220-16"-PL-21B802-EC2	F11	21	POMPRO	U	2	U	42445659	Fjerne pig og preservere oljeeksp GFA	M2	22060519	SOP
1220-16A		16	IMOAUTSA	M	A	D	42340937	UPA linjedetektor for sand mangler verdi	M2	21968797	SOM
1220-16A-ESV 021	W23	16	POMMEC	U	3	U	42350777	Smøre Hyd Master p_02	M2	21979603	POM
1220-16A-ESV 031	W23	16	PPMMEC	M	3	S	42435323	Får ikke stengt tilbakemeld master P-03	M2	22042828	SOP
1220-16A-ESV 131	W23	16	POMMEC	H	3	D	42414968	6M FV-G-PRO TEST AV VENTILTRÆR 2.	M2	21689934	POM

1220-16A-ESV 132	W23	16	POMMEC	H	3	D	42414971	6M FV-G-PRO TEST AV VENTILTRÆR 2.	M2	21689934	POM
1220-16A-ESV 202	W23	16	POMMEC	U	3	U	42350773	Smøre og teste hyd Wing	M2	21979602	POM
1220-16A-ESV 212	W33	16	PPMMEC	M	3	S	42467845	Wing-ventil på brønn P21 stenger selv	M2	22065356	SOP
1220-16A-ESV 241	W33	16	POMMEC	H	3	D	42414661	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	21690000	POM
1220-16A-EZSL 392	W43	16	POMAUT	M	2	D	42364287	Endebrytar stengt ving P39 virkar ikkje.	M2	21991807	POM
1220-16A-HIC 013	D33	87	PPMAUT		N	U	42439108	pimac falt ut på div tag	M2		SOP
1220-16A-HV 0318	W21	16	PPMAUT	U	2	U	42409568	Utføre test i SKR mhp alarmrras	M2	22021728	SOP
1220-16A-HV 043	W23	16	PPMAUT	M	3	S	42435853	Får ikke kjørt choke på P-04 fra SKR.	M2	22042826	SOP
1220-16A-HV 068	W23	16	PPMAUT	L	2	S	42348978	feil. Ny not opprettet : 42348978	M2		SOP
1220-16A-HV 073	W23	16	PPMMEC	M	3	S	42344892	Skifte choke pga lekkasje....	M2	21970960	PPM
1220-16A-HV 078	W23	16	PPMAUT	L	2	S	42349337	P07 Rotork går, men ventil blir ikke med	M2	21979303	SOP
1220-16A-HV 083	W23	16	POMAUT	H	3	D	42349193	Choke vill ikke gå i fra kontrollrom.	M2	21978466	POM
1220-16A-HV 133	W23	16	POMAUT	M	3	S	42351105	Choke går ikke fra SKR	M2	21979809	POM
1220-16A-HV 133	W23	16	PPMAUT	M	3	S	42361309	P13. Choke stenger ikke fra SKR	M2	21988763	SOP
1220-16A-HV 233	W23	16	POMAUT	H	3	D	42349199	Choke vill ikke gå i fra kontrollrom.	M2	21978594	POM
1220-16A-HV 423	W43	16	PPMMEC	M	3	S	42418212	Ventilen går ikke skikkelig	M2	22026440	SOP
1220-16A-HV 433	W43	16	PPMMEC	U	3	U	42363629	Mistanke om feil på choke	M2	22001890	SOP
1220-16A-HV031A	W23	16	PPMMEC	U	2	U	42412838	Montere bonnet bleeder på SWAB ventil.	M2	22022357	SOP
1220-16A-HV081A	W23	16	PPMMEC	U	2	U	42412975	Montere bonnet bleeder på SWAB ventil.	M2	22022356	SOP
1220-16A-HV131A	W23	16	PPMMEC	U	2	U	42413003	Montere bonnet bleeder på SWAB ventil.	M2	22022353	SOP
1220-16A-HV141A	W23	16	PPMMEC	U	2	U	42413004	Montere bonnet bleeder på SWAB ventil.	M2	22022352	SOP
1220-16A-HV151A	W23	16	PPMMEC	U	2	U	42413005	Montere bonnet bleeder på SWAB ventil.	M2	22022351	SOP
1220-16A-HV152B	W23	16	POMMEC	H	3	D	42414348	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	21689936	POM
1220-16A-HV181A	W23	16	PPMMEC	U	2	U	42413008	Montere bonnet bleeder på SWAB ventil.	M2	22022349	SOP
1220-16A-HV231	W33	16	POMMEC	U	2	U	42415902	Manuel master lekker P23	M2	21689999	POM
1220-16A-HV231A	W33	16	PPMMEC	U	2	U	42413037	Montere bonnet bleeder på SWAB ventil.	M2	22022345	SOP
1220-16A-HV241A	W33	16	PPMMEC	U	2	U	42413038	Montere bonnet bleeder på SWAB ventil.	M2	22022358	SOP
1220-16A-HV261A	W33	16	PPMMEC	U	2	U	42413040	Montere bonnet bleeder på SWAB ventil.	M2	22022343	SOP
1220-16A-HV271A	W33	16	PPMMEC	U	2	U	42413041	Montere bonnet bleeder på SWAB ventil.	M2	22022342	SOP
1220-16A-HV352A	W33	16	POMMEC	L	2	S	42416245	Sternlekkasje i man.Wing brønn P35	M2	22023921	POM
1220-16A-HV401A	W33	16	PPMMEC	U	2	U	42413057	Montere bonnet bleeder på SWAB ventil.	M2	22022198	SOP
1220-16A-HV421A	W33	16	PPMMEC	U	2	U	42413059	Montere bonnet bleeder på SWAB ventil.	M2	22022197	SOP
1220-16A-HV441A	W33	16	PPMMEC	U	2	U	42413060	Montere bonnet bleeder på SWAB ventil.	M2	22022196	SOP
1220-16A-HZT 103	W23	16	PPMAUT	M	3	S	42355442	Feil på pos.tilbakemelding choke P-10	M2	21983423	SOP
1220-16A-PI 581	W43	16	PPMMEC	U	1	U	42342310	Eskevikventiler må smøres / moves.	M2	21969351	SOP
1220-16A-PT 076	W23	16	PPMAUT	U	3	U	42370333	Manglende motstand på frakoblede looper	M2	21996726	SOP
1220-16D-ESV 111	P26	16	POMAUT	M	3	S	42341342	Lekkasje fra hydraulikk til ESV111	M2	21968787	POM
1220-16D-ESV 845	P16	16	PPMAUT	M	3	S	42349426	Hydraulikklekkasje på 16D Esv 845	M2	21979313	SOP
1220-16D-PT 065	P23	16	POMAUT	U	3	U	42364004	Transmittere må kalibreres	M2	21675112	POM
1220-16D-TT 814	P16	16	PPMAUT	M	3	S	42436375	Overhale og isolere TI Vigdis linjer	M2	22043409	SOP
1220-16D-XV 840	P16	16	POMAUT	H	3	D	42354103	3M FV-G-AUT-F IOPS SYSTEM	M2	21681985	POM
1220-16F-ESV 422	W43	16	PPMMEC	M	N	S	42370814	Ving P-42 vil ikke gå helt i åpen.	M2	21997099	SOP
1220-17A		17	POMPRO	L	A	D	42432620	Vigdis vanninjeksjonstest brønn F-1 & G1	M2	22036506	SOP
1220-17A-FE 804	P13	17	POMPRO	U	2	U	42412031	Vanninjeksjonstesting Vigdis	M2	22021597	SOP
1220-17A-FT 804	P13	17	IMOAUTSA	L	2	S	42354118	Flowmåler gir alarmrras	M2		SOM
1220-17A-FT 804	P13	17	PPMAUT	M	2	D	42351577	Vigdis vanninj.flowmåler virker ikke	M2	21979873	SOP
1220-17B-ESV 021	W23	17	POMMEC	H	3	D	42417830	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	21690011	POM
1220-17B-FE 120	W23	17	PPMAUT	M	3	S	42408629	P-12: Ratemåler løper løpsk	M2	22007215	SOP
1220-17B-FT 450	W43	17	PPMELE	M	3	S	42354028	Defekt isolasjon, varmekabel synlig	M2	21982922	SOP
1220-17B-HV 163	W23	17	PPMAUT	M	3	S	42436521	Choke P16 vann. Åpner ikkje frå SKR.	M2	22043407	SOP
1220-17B-HV 223	W23	17	POMAUT	H	3	D	42349197	Choke vill ikke gå i fra kontrollrom.	M2	21978595	POM
1220-17B-HV021A	W23	17	PPMMEC	U	2	U	42412979	Montere bonnet bleeder på SWAB ventil.	M2	22022355	SOP
1220-17B-HV101A	W23	17	PPMMEC	U	2	U	42412981	Montere bonnet bleeder på SWAB ventil.	M2	22022354	SOP
1220-17B-HV102A	W23	17	POMMEC	M	2	D	42417826	6M FV-G-PRO TEST AV VENTILTRÆR	M2	21690012	POM
1220-17B-HV201A	W23	17	PPMMEC	U	2	U	42413010	Montere bonnet bleeder på SWAB ventil.	M2	22022348	SOP
1220-17B-HV211A	W23	17	PPMMEC	U	2	U	42413011	Montere bonnet bleeder på SWAB ventil.	M2	22022347	SOP

1220-17B-HV221A	W23	17	PPMMEC	U	2	U	42413033	Montere bonnet bleeder på SWAB ventil.	M2	22022346	SOP
1220-17B-HV251A	W33	17	PPMMEC	U	2	U	42413039	Montere bonnet bleeder på SWAB ventil.	M2	22022344	SOP
1220-17B-HV291A	W33	17	PPMMEC	U	2	U	42413052	Montere bonnet bleeder på SWAB ventil.	M2	22022341	SOP
1220-17B-HV341A	W33	17	PPMMEC	U	2	U	42413056	Montere bonnet bleeder på SWAB ventil.	M2	22022339	SOP
1220-17B-HV451A	W33	17	PPMMEC	U	2	U	42413061	Montere bonnet bleeder på SWAB ventil.	M2	22022195	SOP
1220-17C-HY 801	P13	17	PPMAUT	U	1	S	42346619	Kraftig korrosjon på spole&hyd.blokk	M2	21977952	SOP
1220-17C-VW01	P26	17	POMAUT	H	1	D	42462559	Lampe i styrepanel til piggslyse defekt	M2	22062617	POM
1220-17C-VW01	P26	17	PPMMEC	L	1	D	42351125	Slusen står uten rørspool, må blindes av	M2	21981497	SOP
1220-17D-BZSL 222	W23	17	PPMAUT	M	2	D	42354044	Kabel til endebrytere er frakoblet	M2	21982921	SOP
1220-17D-FE 320	W43	17	PPMAUTM	H	3	D	42346866	Koble opp Clampon flowmåler P-32 gassinj	M2	21973115	POM
1220-17D-FE 370	W43	17	PPMAUT	U	3	U	42415906	Løs ventil. P-37	M2	22023622	SOP
1220-17D-FE 370	W43	17	PPMMEC	U	3	U	42411078	Skifte techlok 52 blind ring + klammer	M2	22021598	SOP
1220-17D-FI 290	W43	17	PPMAUTM	L	N	U	42419546	P-10A og P-29A Clampon ratemåling	M2	22022436	SOP
1220-17D-FT 220	W23	17	PPMAUT	M	3	S	42354045	Slyfefeil på flowmåler GI brønn P22	M2	21984046	SOP
1220-17D-HIC 293	W43	17	PPMAUT	M	3	S	42411447	Choke viser -2,4% i SKR men er 100% åpen	M2	22019288	SOP
1220-17D-HV 026A	W23	17	PPMAUT	M	3	S	42351924	Ingen strøm på nedre rotork P-02	M2	21981486	SOP
1220-17D-HV 106A	W23	17	PPMAUT	U	3	U	42339926	Dårlige flammespalter på rotork, byttes	M2	21967986	SOP
1220-17D-HV 166B	W23	17	PPMMEC	U	3	U	42350446	Reparere pakkboks	M2	21981674	SOP
1220-17D-HV 206A	W43	17	PPMMEC	U	3	U	42351131	Skifte pakkboks til Chesterton	M2	21981671	SOP
1220-17D-HV 206B	W43	17	POMMEC	H	3	D	42347560	Pakkbokselekkasje på gass inj P20	M2	21977387	POM
1220-17D-HV 206B	W43	17	PPMAUT	U	3	U	42352394	Reparere aktuator	M2	21982983	SOP
1220-17D-HV 226A	W23	17	C32SUR	U	3	U	42339929	Vurdere behov utb overflatebeh. rotork	M2	21967985	SSF
1220-17D-HV 326A	W43	17	POMMEC	H	3	D	42363903	P-32 Lekkasje i bleedventiler.	M2	21991862	POM
1220-17D-HV 376A	W43	17	POMAUT	L	3	D	42415855	P-37. Gassmanifol vntiler fjærnet.	M2	22023406	POM
1220-17D-HV161A	W23	17	PPMMEC	U	2	U	42413007	Montere bonnet bleeder på SWAB ventil.	M2	22022350	SOP
1220-17D-HV321A	W43	17	PPMMEC	U	2	U	42413054	Montere bonnet bleeder på SWAB ventil.	M2	22022340	SOP
1220-17D-HZT 163	W23	17	PPMAUT	M	2	D	42355453	GI choke P-16 pos.tilbakemeldingsfeil	M2	21984051	SOP
1220-17D-HZT 223	W23	17	PPMAUT	M	2	D	42355494	Feil på pos.tilbakemelding GI choke P22	M2	21984049	SOP
1220-17D-TI 021	W23	17	PPMAUT	L	1	D	42351427	Temperaturindikator er knekt	M2	21981496	SOP
1220-18"-PT-20C804-CC3	P16	20	C32SUR	U	6	U	42435427	Korrosjon på sveis under isolasjon	M2	22042837	SSF
1220-19B-HV 201	S30	19	PPMSUB	M	2	D	42424838	Ventilen lekker internt.	M2	22029898	SSU
1220-19C-ESV 022	S02	19	PPMSUB	U	3	U	42422888	Lekkasje fra kontrollinje til annulus	M2	22031577	SSU
1220-19D-G21		19	PPMISPR	U	A	U	42408890	Rensepigg Vigdis Prod. linjer	M2	22004422	SOP
1220-19D-RE02A	P25	19	C01PIP	U	3	U	42432382	Inspeksjon av Coflon Spool fra UPA	M2	22036269	SVM
1220-19G		19	PPMAUT	L	A	U	42432721	Feilmerking UPA kontrollkabler etc	M2	22044019	SOP
1220-19G-CB 001B	P31	19	POMAUT	U	5	U	42408875	Drypplekk i filter til returtank	M2	22021642	POM
1220-19G-FT 530	P31	19	PPMAUT	U	5	S	42362165	FT viser ingenflow	M2	21989755	SOP
1220-19G-FT 580	P31	19	PPMAUT	U	5	S	42362166	FT viser ingen flow	M2	21989747	SOP
1220-19G-OD01A	G50	19	PPMSUB	U	6	U	42417409	Lekkasje i i umbilical snorre UPA	M2	22025733	SSU
1220-19G-OD05A	P41	19	PPMELE	U	6	U	42347726	Feilsøke elektrisk JB umb 1 Snorre UPA	M2	21977949	SOP
1220-19G-OD05B	P21	19	PPMELE	U	6	U	42347751	Feilsøke elektrisk JB umb 2 Snorre UPA	M2	21977948	SOP
1220-19G-OZ03A	S30	19	E00SUB	U	6	U	42445538	Spyle/frengjøre annulus bleed Snorre UPA	M2	22060521	SOP
1220-19G-PB02B	P31	19	PPMMEC	M	6	D	42430928	Leverer ikke trykk etter oppstart.	M2	22035751	SOP
1220-19G-PB02B(M)	P31	19	PPMELE	U	6	U	42435478	Bestille ny motor.	M2	22042834	SOP
1220-19G-VL02A	P31	19	POMMEC	M	6	D	42346887	Lekker N2 fra manometer.	M2	21972863	POM
1220-19H		19		A		D	42467114	Choke% & onstreamHRS falt ut på brønner	M2		POM
1220-19H-ESV 036	S03	19	POMPRO	U	3	U	42341923	Pumpe LVP i A-03 AHT3 for restrykkmåling	M2	21969399	SOP
1220-19H-OZ14B	S06	19	PPMSUB	U	3	U	42426777	Lekkasje ved UPA tre i slisse 6	M2	22032049	SSU
1220-19I-BZ01	P21	19	POMPRO	U	6	U	42408068	NPU pumper, nedgradert killsystem	M2	22003024	POM
1220-19I-HV 305	P21	19	PPMAUT	U	3	U	42422389	Utskiftning av gammelt utstyr	M2	22028343	SOP
1220-19I-HV 311	P21	19	PPMAUT	U	3	U	42422390	Utskiftning av gammelt utstyr	M2	22028344	SOP
1220-19I-PB01A	P21	19	POMMEC	L	6	S	42406288	Tilbakestrømning gjennom NPU pumpe A	M2	22001538	POM
1220-19I-PB01A	P21	19	PPMMEC	U	6	U	42342121	Teste A og B NPU pumpene før RS1 11	M2	21969213	SOP
1220-19I-PB01A	P21	19	PPMMEC	M	6	D	42344936	Forurenset olje i NPU pumpe A.	M2	21972543	SOP
1220-19I-PB01B	P21	19	POMAUT	M	6	D	42405592	NPU-pumper går ujevnt på turtall.	M2	22000980	POM
1220-19I-PB01B	P21	19	PPMMEC	L	6	S	42405795	Tilbakestrømning gjennom NPU pumpe B	M2	22001427	SOP

1220-19I-TA01	P21	19	POMMEC	L	6	S	42363572	KUI på Tank 19I-TA01	M2	21573113	POM
1220-2"BBK3-953	W23		PPMMEC	M	2	D	42462854	Intern lekkasje mot fakkel, brønn P-22	M2	22061727	SOP
1220-2"-PL-27 A839-CS1	P17	27	C32ISU	M	3	S	42348011	Skadet isolasjon og kapsling	M2	21979299	SSF
1220-2"-WD-53B049-CS1	N11	53	C01PIIP	U	6	U	42417926	VISUELL KONTR. AV FLENSER: KORRODERT	M2	22025729	PPM
1220-2"-WP-53C901-CK1	L40	53	PPMMEC	U	6	U	42465116	Mulig lekkasje i flens på vannventil	M2	22064272	SOP
1220-20A		20	PPMAUT	U	A	U	42427331	Gjennomgå ventil låser (U31)	M2	22032053	SOP
1220-20A-ESV 024	P35	20	POMMEC	H	3	D	42443816	Ventilen stenger ikke (ca.60%)	M2	22059914	POM
1220-20A-FC 001	P35	20	PPMAUT		N	U	42432764	IP21: Standard mapping	M2		SOP
1220-20A-FT 013	P35	20	PPMAUTM	U	2	U	42343315	Kraftig korrosjon mellom blokk og transm	M2	21970032	SOP
1220-20A-LI 008 P	P35	20	PPMAUT		N	U	42430300	Stort awik mellom sek. og primær måling	M2		SOP
1220-20A-LRE 008	P35	20	PPMAUT	U	3	U	42343813	Kontrollere tilstand på sintilatorer	M2	21970579	SOP
1220-20A-LRE 008	P35	20	PPMAUT	M	3	S	42414286	Nivåmåler testseparator har awik.	M2	22023621	SOP
1220-20A-LT 020	FS1	20	POMAUT	H	2	S	42405864	Sjekk av nivåtransmittere på testsep	M2	22001339	POM
1220-20A-LV 015A	P43	20	POMAUT	L	2	S	42469201		M2		SOP
1220-20A-VA01	P35	20	POMPRO	M	2	D	42432613	Sep.testing og prøver Vigdis C5/G3/D2	M2	22036505	SOP
1220-20A-ZI 015A	P43	20	PPMAUT	M	N	D	42435432	Mangler tilbakemelding 20A-LV015A	M2	22042945	SOP
1220-20B-CJ01	P35	20	POMPRO	M	3	S	42341315	Test "ny" H2S scavenger injeksjonsmikser	M2	21968789	SOP
1220-20B-HV 837	P16	20	PPMAUT	L	1	D	42444337	Ventil går ikke fra SKR	M2	22058994	SOP
1220-20B-LRE 012	P35	20	PPMAUT	U	3	U	42353991	Låse radioaktiv kilde i open posisjon.	M2	21982979	SOP
1220-20B-LRE 811	P16	20	PPMAUT	M	3	S	42414364	Awik gammamåler vig 1.trinn	M2	22023620	SOP
1220-20B-LV 015B	P43	20	PPMAUT	M	3	S	42361153	Ventil henger fast på 50% ventilstilling	M2	21988765	SOP
1220-20B-LV 015B	P43	20	PPMMEC	M	3	S	42421607	Ekstern lekkasje i stem 20B-LV015B	M2	22027657	SOP
1220-20B-LV 015C	P43	20	PPMMEC	M	3	S	42422357	Stor lekkasje ut sladreport/langs spinde	M2	22028381	SOP
1220-20C-AX 859	P23	20	PPMAUTM	M	2	D	42414566	Vann i oljemåler virker ikke. Crossover	M2	22022757	POM
1220-20C-AX 859	P23	20	PPMAUTM	L	2	S	42432596	Vann i olje-måler crossover, virker ikke	M2	22036594	PPM
1220-20C-LR 013	P35	20	PPMAUT	M	3	S	42414363	LAHH kom ikke inn med alarm sno 2.trinn	M2	22023619	SOP
1220-20C-LRT 810A	P16	20	PPMAUT	M	3	S	42370334	Loopfeil på transmitter for 20C-LIC 810B	M2	21996725	SOP
1220-20C-LV 015B	P43	20	PPMMEC	H	3	D	42403071	Vannventil 2. trinn Snorre står fast	M2	21998121	POM
1220-20C-PA60	P23	20	PPMMEC	U	2	U	42418326	Ha nødvendig deler på plass i tilfelle	M2	22025804	PPM
1220-20C-PSV 803	P16	20	PPMMEC	L	6	S	42417679	Blokkventil oppstrøms PSV lekker	M2	22025727	SOP
1220-20C-PSV 850	P25	20	POMMEC	H	3	D	42412271	Resertifisere PSV på X-over Olje	M2	22019722	POM
1220-20C-VA01	P35	20	C32ISU	U	3	U	42357003	Flytte luke for scanning	M2	21986158	SSF
1220-20C-VA01	P35	20	PPMMEC	U	3	U	42352926	Innekapslet smøre nippler.	M2		SOP
1220-20C-VA60	P16	20	PPMMEC	U	3	U	42352819	Innkapsling av smørepunkter.	M2		SOP
1220-21		21	POMPRO	U	A	U	42418678	Årsavtale med Proserv 2011	M2	22026198	SOP
1220-21A-PA60A	P16	21	PPMMEC	U	3	U	42466253	Ventil er tung og operere.	M2	22064988	SOP
1220-21A-PA60B	P16	21	PPMMEC	M	3	S	42462967	Ventil ut av pumpe lekker i giret	M2	22062603	SOP
1220-21A-PA61A	P17	21	PPMMEC	U	3	U	42466254	Ventil er tung og operere.	M2	22064987	SOP
1220-21A-PA61B	P17	21	POMMEC	H	3	D	42411060	Vigdis olje export ,mistat tettningsvæsk	M2	22018150	POM
1220-21B-AX 016A	P23	21	PPMAUTM	U	6	U	42421862	Bytte prøvetakerpumpe Snorre målestasjon	M2	22027857	SOP
1220-21B-AX 016B	P23	21	PPMAUTM	M	6	S	42342072	Bytte og overhale mnd prøvetaker SNO	M2	21969409	SOP
1220-21B-AX 016B	P23	21	PPMAUTM	M	6	S	42348419	Lekkasje i Haskel vann i olje mixerpumpe	M2	21978547	SOP
1220-21B-AX 016B	P23	21	PPMAUTM	U	6	U	42361155	Deler til miksepumpe Snorre oljeeksport	M2	21988467	SOP
1220-21B-AX 960	F15	21	PPMAUTM	L	6	S	42342694	Overhale daglig prøvetaker Vigdis olje	M2	21970025	SOP
1220-21B-AX 960	F15	21	PPMAUTM	M	6	S	42405603	Overhale daglig prøvetaker Vigdis olje	M2	22001088	PPM
1220-21B-AX 960	F15	21	PPMAUTM	U	6	U	42409729	Bygge om luft tur/retur på prøvetaker	M2	22021639	SOP
1220-21B-AX 964	F15	21	PPMAUTM	L	6	S	42408411	Overhale mnd. prøvetaker Vig.Olje	M2	22007211	SOP
1220-21B-FI 103	FN1	21	PPMAUTM	L	N	U	42342996	Oppgang av pulstog linje1 SNO olje	M2	21970038	SOP
1220-21B-FI 203	FN1	21	PPMAUTM	L	N	U	42343000	Oppgang av pulstog linje2 SNO olje	M2	21970037	SOP
1220-21B-FI 303	FN1	21	PPMAUTM	L	N	U	42343001	Oppgang av pulstog linje3 SNO olje	M2	21970036	SOP
1220-21B-FI 703	FN1	21	PPMAUTM	L	N	U	42343052	Oppgang av pulstog linje3 SNO olje	M2	21970035	SOP
1220-21B-FT 103A	P23	21	PPMAUTM	M	9	D	42355175	Vannspyling av turbinmåler.	M2	21983434	SOP
1220-21B-FT 103A	P23	21	PPMAUTM	U	9	U	42425624	Vannspyling av turbinmeter Linje 1	M2	22031127	SOP
1220-21B-FT 203A	P23	21	PPMAUTM	U	9	U	42425623	Vannspyling av turbinmeter Linje 2	M2	22031128	SOP
1220-21B-FT 303A	P23	21	PPMAUTM	M	9	D	42355177	Vannspyling av turbinmåler.	M2	21983431	SOP
1220-21B-FT 303A	P23	21	PPMAUTM	U	9	U	42425469	Vannspyling av turbinmeter Linje 3	M2	22030889	SOP

1220-21B-FT 403B	P23	21	PPMAUTM	M	9	D	42438474	Feil på pulstog B linje 4 Snorre olje.	M2	22044464	SOP
1220-21B-PDT 911	F15	21	PPMAUTM	U	5	U	42351032	Reingjøre filter. Vigdis oljemålestasjon	M2	21979612	PPM
1220-21B-PT 913	F15	21	PPMAUTM	U	5	S	42347337	Transmitter kom inn med alarm. Feilsøke	M2	21973118	SOP
1220-21B-TT 968	F15	21	IMOAUTFM	U	6	U	42419745	TT må sendes til kalibrering eller bytte	M2	22026836	SOM
1220-21B-XU01	P23	21	PPMAUTM	U	9	U	42340056	Generell AO. Snorre oljemålestasjon 2011	M2	21966179	SOP
1220-21B-XU01	P23	21	PPMAUTM	U	9	U	42344006	Bytte av mnd prøvesylindre SNO/VIG	M2	21970236	PPM
1220-21B-XU01	P23	21	PPMAUTM	U	9	U	42348310	OD Måleteknisk tilsyn Snorre A	M2	21978549	SOP
1220-21B-XU60	F15	21	PPMAUTM	U	6	U	42340057	Generell AO. Vigdis oljemålestasjon 2011	M2	21966180	SOP
1220-21B-XV 109	P23	21	PPMAUT	U	9	U	42414160	Teste ventiler på målepakken før RS11	M2	22022837	SOP
1220-21B-XV 212	P23	21	PPMMEC	L	9	S	42438783	Intern lekkasje i ventil	M2	22044249	PPM
1220-21B-XV 409	P23	21	PPMAUTM	L	9	S	42370849	Justere endebyttere på aktuator	M2	21997100	SOP
1220-21C	P18	21	POMPRO		A	U	42363304	Defekt flap rensepigg VG 7	M2	21971746	PPM
1220-21C-VW01	W33	21	POMMEC	U	2	U	42363200	Defekt flaps rensepigg	M2	21967291	POM
1220-23A-FIC 003	FN1	23	IMOAUTSA		Z	S	42420962	Feil på alle antisurgebilder	M2		SOM
1220-23A-FT 003	P45	23	PPMAUT	M	3	S	42417873	Ustabil flowmåling til antisurgekontroll	M2	22025723	SOP
1220-23A-FV 011	P45	23	PPMMEC	U	3	U	42462524	Overhale AS-ventil Snorre Rekompresor	M2	22061737	SOP
1220-23A-KA01	P45	23	POMMEC	H	3	D	42420371	Repp av rørbrudd smøreolje og Rengjøring	M2	22026741	POM
1220-23A-KA01	P45	23	PPMMEC	U	3	U	42352593	Skifte av rør-support.	M2	21982406	SOP
1220-23A-KA01	P45	23	PPMMEC	M	3	S	42438395	Oljen er forurenset og må skiftes.	M2	22044465	SOP
1220-23A-KA60	P16	23	PPMMEC	U	3	U	42342340	Tetninger: Varme eller skifte.(RS1_11_E)	M2	21969209	SOP
1220-23A-KZ60	P16	23	PPMMEC	U	3	U	42436253	48M ETTERSYN GIR utføres av Renk spes	M2	22043112	PPM
1220-23B-FCV 049	P45	23	PPMAUT	H	6	S	42360176	Miniflowen lager trykkstøt ut av pumpa.	M2	21989743	POM
1220-23B-FCV 049	P45	23	PPMMEC	L	6	S	42415117	Problemer med gass blowby i pumpe.	M2	22023250	PPM
1220-23B-FCV 844	P16	23	PPMMEC	M	6	D	42420967	Mistenker miniflow regass Vig kondensat	M2	22027658	SOP
1220-23B-LV 021	P45	23	POMAUT	M	3	S	42429341	Intern lekkasje i ventil	M2	22032921	POM
1220-23B-LV 827	P16	23	POMAUT	L	6	S	42344779	Ventil jager åpen/ stengt.	M2	21971160	POM
1220-23B-PA01A	P33	23	PPMMEC	M	6	D	42345303	Pumpen legger seg ut elektrisk.	M2	21971279	PPM
1220-23B-PA01B	P33	23	PPMMEC	L	6	S	42414799	Problemer med gass blowby i pumpe.	M2	22023629	PPM
1220-23B-PSV 824	P16	23	PPMMEC	U	6	U	42429106	Intern lekkasje over interlock ventil	M2	22035074	SOP
1220-23B-PSV 824	P16	23	PPMMEC	U	6	U	42432479	Oppstrøms bleed ventil defekt.	M2	22036596	SOP
1220-23B-PT 838	P16	23	PPMAUT	U	3	U	42349098	Bytte testnippel på manifold	M2	21979315	SOP
1220-24A-LV 017	P45	24	PPMAUT	U	3	U	42422391	Utskiftning av gammelt utstyr	M2	22028342	SOP
1220-24C-FE01	P41	24	PPMELE	U	3	U	42424345	Lav isolasjonsmotstand på element	M2	22030494	SOP
1220-24C-LSLL 168	FN1	24	PPMAUT	U	3	U	42426572	fv 6 TAG MÅ TESTE UNDER RS11	M2	22031575	SOP
1220-24C-PC01A	P41	24	PPMMEC	L	6	S	42462526	Lekker TEG ut av pumpen	M2	22061759	POM
1220-24C-PC01B	P41	24	POMMEC	L	6	S	42464875	Bytte pumpeenhet	M2	22063225	POM
1220-24C-PC01B	P41	24	PPMMEC	L	6	S	42343319	Teg pumpe tripper på overlast.	M2	21970031	SOP
1220-24C-PC01B	P41	24	PPMMEC	L	6	S	42463417	Skifte pumpe pga høy vibrasjon	M2	22062615	SOP
1220-24C-PT 174	P41	24	PPMAUT	U	2	U	42423324	Manuell stengeventil står stuck.	M2	22031576	SOP
1220-26A-ESV 014	P56	26	PPMMEC	M	3	S	42420979	Hydraulikk lekkasje Aktuator	M2	22027883	SOP
1220-26A-FT 227	P56	26	PPMAUT	L	2	S	42423480	Flowmåler støyer på alarmliste	M2	22030493	SOP
1220-26A-HV 015	W43	26	PPMMEC	L	2	S	42418104	Lekker internt	M2	22025726	SOP
1220-27A		27	POMPRO	U	A	U	42355256	Merkning av hjelpeutstyr på kompressorer	M2	21983463	SOP
1220-27A-CB60A	P17	27	PPMMEC	M	5	S	42404319	Turbineolje lekkasje, 1220-27A-CB60.	M2	22000998	SOP
1220-27A-GX62	P17	27	C32ISU	M	3	S	42423622	Rep av løse plater på topp av luftinntak	M2	22030484	SSF
1220-27A-KA01B	P45	27	PPMMEC	U	3	U	42352594	Defekte rør-support	M2	21982405	SOP
1220-27A-KA60	P17	27	PPMMEC	U	3	U	42342336	Tetninger: Varme eller skifte.(RS1_11_E)	M2	21969211	SOP
1220-27A-KA60	P17	27	PPMMEC	U	3	U	42342338	Tetninger: Varme eller skifte.(RS1_11_E)	M2	21969210	SOP
1220-27A-LIC 469	P45	27	PPMAUT	M	3	S	42349433	Ustabil nivåmåling	M2		SOP
1220-27A-LSHH 467	P45	27	PPMAUT	M	3	S	42351005	Difus gasslekkasje	M2	21981492	SOP
1220-27A-LSHH 467	P45	27	PPMMEC	M	3	S	42340322	Difus lekkasje fra flens. A-kompressor	M2	21967890	SOP
1220-27A-PCV 765	P45	27	PPMAUT	U	3	U	42433158	Gir alt for mye flow	M2	22036589	SOP
1220-27A-PV 471	P45	27	PPMMEC	M	3	S	42358031	Stemlekkasje, gass 125 bar system	M2	21986154	SOP
1220-27A-PV 473		27	PPMAUT	U	3	U	42422402	Utskiftning av gammelt utstyr	M2	22028341	SOP
1220-27A-PV 671	P45	27	PPMMEC	M	3	S	42358132	Stemlekkasje, gass 125 bar system	M2	21986153	SOP
1220-27A-PV 673		27	PPMAUT	U	3	U	42422403	Utskiftning av gammelt utstyr	M2	22028340	SOP

1220-27A-PY 478	P45	27	PPMAUT	U	3	U	42422404	Utskiftning av gammelt utstyr	M2	22028339	SOP
1220-27A-PY 678	FN1	27	PPMAUT	U	3	U	42422405	Utskiftning av gammelt utstyr	M2	22028338	SOP
1220-27A-XV 015	P45	27	PPMMEC	M	3	S	42358029	Stemlekkasje, gass 125 bar system	M2	21986156	SOP
1220-27A-XV 115	P45	27	PPMMEC	M	3	S	42358030	Stemlekkasje, gass 125 bar system	M2	21986155	SOP
1220-27A-YE 543B	P45	27	IMOMECTK	M	6	D	42465758	Overvåke kompressor pga def. vibr probe	M2	22064310	SOM
1220-27A-YE 543B	P45	27	PPMAUT	M	6	D	42465537	Vibrasjonssignal svinger unaturlig mye	M2	22064262	SOP
1220-27B-HA01A	P45	27	PPMMEC	U	3	U	42350808	Mye rust på kjøler/rør, inspiseres	M2		SOP
1220-27B-LT 813	P16	27	PPMAUT	U	3	U	42346945	Nivåmåler gikk i peak og trippet anlegg	M2	21977951	SOP
1220-27B-LV 005	P45	27	PPMAUT	U	3	U	42422406	Utskiftning av gammelt utstyr	M2	22028337	SOP
1220-27B-LV 025	P45	27	PPMAUT	U	3	U	42422407	Utskiftning av gammelt utstyr	M2	22028336	SOP
1220-27B-PSV 023	P45	27	PPMMEC	M	6	D	42424603	Ekstern lekkasje fra LP side(fakkell)	M2	22030479	SOP
1220-27B-TV 055	P45	27	PPMAUT	U	3	U	42422410	Utskiftning av gammelt utstyr	M2	22028334	SOP
1220-27B-TV 085	P45	27	POMMEC	U	3	U	42407210	Liten drypp lekkasje 27B-TV-085	M2		POM
1220-27B-TV 085	P45	27	PPMAUT	U	3	U	42422409	Utskiftning av gammelt utstyr	M2	22028335	SOP
1220-27B-TV 085	P45	27	PPMMEC	U	3	U	42429118	Pakkboks-drypplekkasje	M2	22035072	SOP
1220-27C		27	PPMAUTM	L	A	U	42437365	H2S onlinemåler for eksportgass	M2	22043914	SOP
1220-27C-AX 002	P45	27	PPMAUTM	M	6	D	42355272	Prøvetaker gasseksport virker dårlig.	M2	21983428	SOP
1220-27C-FE 103	P45	27	PPMAUTM	M	6	D	42358133	Stem lekkasje på man.ventil	M2	21986150	SOP
1220-27C-PSV 102	P45	27	POMMEC	U	3	U	42432264	Defekt kobling mellom interlock/ventil	M2	22036209	SOP
1220-27C-XU01	P45	27	PPMAUTM	U	6	U	42340059	Generell AO. Snorre gassmålestasjon 2011	M2	21966181	SOP
1220-27C-XV 301	P45	27	PPMAUTM	L	6	S	42405604	Gass innløpsventil linje3 feilet	M2	22001087	SOP
1220-27D-ZS 060	P28	27	PPMAUT	L	1	D	42355446	Feil på pigslusedetektor gasseksportlinj	M2	21984053	SOP
1220-3"-WF-71B088-CM1	P13	71	C32ISU	M	3	S	42407211	Mangler isolasjonskapsling på flens.	M2	22002630	SSF
1220-3/4"MX1LG7R-003	P35	20	PPMMEC	U	1	U	42437340	Mgl. plug i bleed. - (Testsep.)	M2	22043913	SOP
1220-4"BBDB-106	P43	44	PPMMEC	L	8	D	42362755	Ventil lar seg ikke operere.	M2	21991874	SOP
1220-4"BBK2-002	P56	26	PPMMEC	L	2	S	42424877	Gear defekt på ventil WAG	M2	22029892	SOP
1220-4"-DO-56A216-CC2	P33	56	C01PIP	M	3	S	42466105	Lekkasje 4"-DO-56A216-CC2 i P33	M2	22064980	SOP
1220-4"-DO-56B015-CC2	D36	56	PPMMEC	M	2	D	42421545	Tett drainlinje, renner ut i flens.	M2	22030488	SOP
1220-4"-FC-16A073-KC1	W43	16	PPMMEC	L	6	S	42407249	Midlertidig rep. av korodert rør.Kill sy	M2	22002625	SOP
1220-4"GAK2-009	W43	12	PPMMEC	M	N	S	42406563	Ventil står fast	M2	22001838	SOP
1220-4"GAK2-009	W43	12	PPMMEC		N	D	42410682	Ventil fra cementunit til killman. stukk	M2		SOP
1220-4"GAK2-026	W23	16	PPMMEC	H	2	S	42403597	Lekkasje i pakkboks, smørenippel	M2	21998401	SOP
1220-4"GAK2-050	W45	16	PPMMEC	M	2	D	42342362	Skadet rørspool av lasthadtering skiddec	M2	21969410	SOP
1220-40A-HB01B	D21	40	PPMMEC	U	3	U	42342303	Montere brannvannkob. på kjølevann,D21	M2	21969353	SOP
1220-40B-PV 011	D21	40	PPMAUT	U	6	U	42422411	Utskiftning av gammelt utstyr	M2	22028333	SOP
1220-420-PD02	P00	42	PPMAUT	U	2	U	42363385	Sertifisering/ kontroll av man. på testp	M2	21991882	SOP
1220-42A-CZ04	P33	42	PPMMEC	U	4	U	42445263	Sett inn strainere, mangler	M2	22065569	SOP
1220-42A-PA01A	P33	42	PPMMEC	U	4	U	42445266	Montere nye strainer, mangler	M2	22059905	SOP
1220-42A-PD02A	P33	42	PPMMEC	U	6	U	42342120	Teste A og B metanolpumpene før RS1 11	M2	21969356	SOP
1220-42A-PD02A	P33	42	PPMMEC	M	6	D	42415076	Smørolje lekkasje i krysshode tetning.	M2	22023625	SOP
1220-42A-PD02B	P33	42	PPMMEC	L	6	S	42415081	Lekker smøroljeolje ut av veihus.	M2	22023624	SOP
1220-42A-PD02B	P33	42	PPMMEC	L	6	S	42444893	Pakkbokselekkasje	M2	22058992	SOP
1220-42A-PV 324	P33	42	PPMAUT	U	6	U	42422413	Utskiftning av gammelt utstyr	M2	22028332	SOP
1220-42A-PV 385	P33	42	PPMAUT	U	6	U	42422414	Utskiftning av gammelt utstyr	M2	22028331	SOP
1220-42A-VL01	P33	42	C32CLE	M	3	S	42357931	Tett drain fra metanol oppsamlingskar.	M2	21987075	SSF
1220-42B-PD04A	P41	42	PPMMEC	U	5	S	42362850	Membran brud pumpehoved	M2	21990822	PPM
1220-42B-PD04B	P41	42	PPMMEC	U	5	U	42340312	Fikk indikasjon på membranbrudd i SKR.	M2	21967740	SOP
1220-42B-PD04B	P41	42	PPMMEC	L	5	D	42414849	Membranbrudd på pumpe.	M2	22022758	SOP
1220-42B-PD63A	P31	42	PPMMEC	L	5	D	42349769	Kalibreringsglasset er knust	M2	21979301	SOP
1220-42C-PD02A	P41	42	POMMEC	U	5	S	42419373	Defekt Pulsations dæmper	M2	21845540	POM
1220-42C-PD02A	P41	42	PPMMEC	U	5	U	42420519	Defekt pulsdemper	M2	22026834	SOP
1220-42C-PD60B	P31	42	PPMMEC	U	5	S	42362822	Defekt pulsdemper	M2	21991884	SOP
1220-42E-PD61A	P31	42	PPMAUT	M	6	D	42362788	Defekt manometer	M2	21991870	SOP
1220-42E-PIT 925	P31	42	PPMAUT	M	3	S	42423017	Emulsjonsbryter transmittere feil plass	M2	22030485	SOP
1220-43A-FE 063A	F32	43	PPMAUT	U	3	U	42359142	HP fakkell -FE 063A feil matrialkvalitet	M2	21987069	SOP
1220-43A-FI 063A	FN1	43	PPMAUTM		N	U	42411202	Feilsøke på HT-fakkellgassmåler	M2		PPM

1220-43A-FQI 063	FN1	43	PPMAUTM	U	3	U	42340060	Generell AO. Fakkelmåler 2011	M2	21966182	SOP
1220-43A-LT 054	F31	43	PPMAUT	U	3	U	42341934	Endre demping og funksjonsteste	M2	21969357	SOP
1220-43A-LV 056	F31	43	PPMAUT	U	3	U	42422415	Utskifting av gammelt utstyr	M2	22028330	SOP
1220-43B-FE 062A	F32	43	PPMAUTM	M	3	S	42351162	Fakkelmåler faller ut og gir alarm.	M2	21981278	SOP
1220-43B-LV 056	F31	43	PPMAUT	U	3	U	42422416	Utskifting av gammelt utstyr	M2	22028329	SOP
1220-43C-FI 001	P31	43	PPMAUT	U	1	S	42357998	Flow indikator på fakkelspyling defekt.	M2	21986157	SOP
1220-44A-CE01N	P43	44	PPMMEC	M	9	D	42350069	Ventil står fast, kan ikke åpnes	M2		SOP
1220-44A-CE01N	P43	44	PPMMEC	M	9	D	42351590	Ventil står fast, kan ikke åpnes	M2	21981489	SOP
1220-44A-CE63	P41	44	PPMMEC	U	3	U	42351348	Forkontaktiviteter oppstart VLQ	M2	21981669	SOP
1220-44A-CE64	P41	44	PPMMEC	M	3	S	42420593	Lekk pakkninger på skimmelinje	M2	22026826	SOP
1220-44A-CXD1	P43	44	PPMAUT	M	2	D	42355936	Kondensat lekkasje på prøvebord P33	M2	21984048	SOP
1220-44A-PDT 920B	P41	44	PPMAUT	M	3	S	42465319	Defekt equaliser på 5-way manifold	M2	22064270	SOP
1220-44B-HV 147	P43	44	PPMMEC	U	2	U	42351205	Smørenippel er umulig å bruke	M2	21981670	SOP
1220-44B-LRE 805	P43	44	PPMAUT	M	3	S	42406737	Sintilator er oppbrukt skiftes (RS11)	M2	22001777	SOP
1220-44B-LSHH 835	P43	44	POMAUT	U	2	U	42414327	Test av alternativ pakning for 4"150# fl	M2	22022478	SOP
1220-44B-LV 819C	P31	44	PPMMEC	M	3	S	42362163	For liten rate gjennom ventil	M2		SOP
1220-44C-FT 041	P31	44	POMAUT	H	3	D	42355425	Måler viser ikke flow	M2	21983419	POM
1220-44C-XV 821	P43	44	PPMAUT	U	3	U	42436534	Ventilen går sagte.	M2	22043413	SOP
1220-44D-LG 009	P45	44	POMAUT	H	7	D	42404341	Lekk pakkings på 12mm kuleventil seglass	M2	21999048	POM
1220-44D-LG 022	P45	44	PPMAUT	L	7	D	42362168	Floter i nivåkol. følger ikke nivå endri	M2	21991879	SOP
1220-44D-LT 009	P45	44	PPMAUT	L	9	S	42360043	Nivåmåleren henger og tripper c-tour	M2		SOP
1220-45A-FE61A	P17	45	PPMELE	L	6	S	42439566	Lav isolasjonsverdi på brenngassheater A	M2	22044804	SOP
1220-45A-LV 008	P45	45	PPMAUT	U	3	U	42422417	Utskifting av gammelt utstyr	M2	22028328	SOP
1220-50A-PS01B	N11	50	POMMEC	M	3	S	42433756	Olje i koblingshus for temp element,	M2		POM
1220-50A-PS01C(M)	N11	50	PPMELE	U	3	U	42467191	Feilsøke på alarmstatus vnedstopp aktiv	M2	22065565	SOP
1220-50A-PV 026	N11	50	PPMAUT	U	3	U	42422419	Utskifting av gammelt utstyr	M2	22028326	SOP
1220-50C		50				U	42343317	Lekkasje i ventil Se long tekst	M2		SOP
1220-50C-CX50	D35	50	POMMEC	U	3	U	42343378	Butterflyventil med blindlokk må demonte	M2	21969613	POM
1220-50C-TV 101	D11	50	PPMAUT	U	3	U	42422418	Utskifting av gammelt utstyr	M2	22028327	SOP
1220-51B-FV 216	D21	51	PPMAUT	U	3	U	42422420	Utskifting av gammelt utstyr	M2	22028325	SOP
1220-51C-AT 041	D21	51	POMAUT	M	2	D	42445720	O2 analysator viser feil.	M2	22060815	POM
1220-51C-KA60	W11	51	PPMMEC	L	N	S	42408853	Ventiler står fast.	M2	22007216	SOP
1220-51C-KA60B	W11	51	PPMMEC	L	6	S	42435957	Ekstern olie lekkasje fra Compressor	M2	22043415	SOP
1220-51C-PA02	D21	51	PPMMEC	U	3	U	42409408	Bytte smøreolje "D-dump pumpe"	M2	22021641	SOP
1220-51C-VC01	D21	51	PPMMEC	U	3	U	42352518	Palladium'en rengjøres og inspiseres	M2		SOP
1220-51D-PA02E	D21	51	PPMMEC	M	3	S	42437554	Oljen er forurenset med vann	M2	22043912	SOP
1220-51D-PA02E	D21	51	PPMMEC	M	3	S	42438394	Motor DE oljen er forurenset og må rense	M2	22044477	PPM
1220-51D-PA02E(M)	D21	51	PPMAUT	U	3	U	42408726	ON-SNA. Støy på signal til 51D-PA02E(M)	M2	22023627	SOP
1220-51D-PA61A(M)	P11	51	PPMAUT	U	3	U	42359765	Montere trykkregulator og manometer	M2	21987453	SOP
1220-51D-PA61B	P11	51	C01PIP	U	3	U	42416433	Visuell kontroll av flenser 2 stk	M2	22025760	PPM
1220-51D-PA61B(M)	P11	51	PPMMEC	M	3	S	42406345	Høyt vanninnhold på lager NDE.	M2	22001822	SOP
1220-51D-PI 801	FS1	51	POMAUT		N	S	42420619	Trykk-transmitteren er feil presentert p	M2		POM
1220-51D-PV 003	W13	51	PPMAUT	H	3	D	42409393	Stor intern lekkasje i ventil	M2		POM
1220-51D-TE 675A	D21	51	POMAUT	U	3	U	42363777	Defekt temperatursensor WIP D.	M2	21990889	POM
1220-51D-TT 675	D21	51	POMAUT	H	3	D	42363549	Instrument feil	M2	21991865	POM
1220-51D-XV 147	D21	51	PPMAUT	M	3	S	42404925	Tilbakemelding på ventil deffekt	M2	22000987	SOP
1220-51D-XV 157	D21	51	PPMMEC	M	3	S	42404280	Ekstern lekkasje på blind hub	M2	21998914	POM
1220-51D-XV 167	D21	51	PPMMEC	M	3	S	42404927	Bypassventil står fast.	M2	22000986	SOP
1220-51D-XV 187	D21	51	PPMMEC	M	3	S	42411615	Liten hydraulikkolje lekkasje	M2	22019285	SOP
1220-51D-YAHH 521A	D21	51	POMAUT	H	3	D	42422378	Vibrasjon kommer inn og tripper pumpen	M2	22028391	POM
1220-51D-YE 505A	D21	51	PPMAUT	U	3	U	42426790	Stripse fast kabel til vibrasjonsprobe.	M2	22031574	SOP
1220-51E-FT 800	P16	51	PPMAUT	M	3	S	42364145	FI viser for lav rate	M2	21996488	SOP
1220-51E-PV 001	P23	51	PPMAUT	U	3	U	42422432	Utskifting av gammelt utstyr	M2	22028324	SOP
1220-51E-PV 002	P23	51	PPMAUT	U	3	U	42422433	Utskifting av gammelt utstyr	M2	22028173	SOP
1220-51E-PV 011	P43	51	PPMAUT	U	3	U	42422434	Utskifting av gammelt utstyr	M2	22028323	SOP
1220-52A-HV 007	C14	52	POMAUT	H	3	D	42401640	Ventil åpner ikke.	M2	21997106	POM

1220-52A-HV 047	C14	52	POMAUT	H	3	D	42401641	Ventil åpner ikke.	M2	21997082	POM
1220-52A-HV 076	C14	52	PPMAUT	U	6	U	42422435	Utskifting av gammelt utstyr	M2	22028322	SOP
1220-52A-HV 226	C24	52	PPMAUT	U	3	U	42422437	Utskifting av gammelt utstyr	M2	22028321	SOP
1220-52A-HV 351	T31	52	PPMAUT	U	3	U	42362153	Lekker litt hydraulikkolje i aktuatoren.	M2		SOP
1220-52A-HV 365	N31	52	PPMAUT	U	6	U	42422438	Utskifting av gammelt utstyr	M2	22028320	SOP
1220-52A-HV 376	C34	52	PPMAUT	U	6	U	42422440	Utskifting av gammelt utstyr	M2	22028319	SOP
1220-52A-HV 452	T31	52	POMAUT	H	3	D	42401639	Ventil åpner ikke.	M2	21997083	POM
1220-52A-HV 515	N41	52	C32SUR	L	6	S	42360285	Korrosjon på ventil	M2	21955829	SSF
1220-52A-HV 515	N41	52	PPMAUT	U	6	U	42362428	Korrosjon på ventil	M2	21991886	SOP
1220-52A-HV 526	C44	52	PPMAUT	U	6	U	42422441	Utskifting av gammelt utstyr	M2	22028258	SOP
1220-52A-LT 023	C12	52	POMAUT	H	3	D	42434021	Feil på nivåmåling operasjons tank.	M2		POM
1220-52A-LT 451	C44	52	PPMAUT	M	3	S	42426930	Instrumentet flakker	M2	22031956	SOP
1220-52A-PT 100	C12	52	PPMAUT	L	5	D	42435225	Feil på ballast nivå målinger i søyle 1	M2	22042680	SOP
1220-52A-TB41	N41	62	C32SUR	U	4	U	42362492	Korroderte bolter manlokk dreneringstank	M2	21989877	SSF
1220-53		53	M09SASAI		A	U	42462577	Merking av drikkevannsystemet	M2		SPI
1220-53A-PA02B	D11	53	PPMMEC	M	5	S	42443458	Liten drypp lekkasje fra tettning	M2	22059913	SOP
1220-53B-AI 346	D11	53	PPMAUT		N	S	42445545	Viser for høy PH	M2		SOP
1220-53B-TB01A	N11	53	C32SUR	U	6	U	42361951	FUNN:Rustgjennomslag i Ferskvannstank	M2		SPI
1220-53B-TB01A	N11	53	C32SUR	L	6	S	42362254	Korrosjon på utvendig stuss	M2	21991877	SSF
1220-53B-TB01A	N11	53	PPMISPS	U	6	U	42408150	FUNN:Rustgjennomslag i vannstank 53B-TB01	M2		SSF
1220-53C-GW12	U31	53	POMELE	U	6	U	42418351	Sikkerhetsventil står og lekker	M2		POM
1220-53C-GZ02	D36	53	PPMMEC	U	1	S	42439487	Vannlekkasje i rør inne i vegg	M2	22044783	POM
1220-56A-LT 803	W07	56	PPMAUT	M	3	S	42362810	Trenger FMU-kort ----->	M2	21991869	SOP
1220-56A-PB01	P31	56	POMMEC	M	3	S	42401557	Open drain pumpe P31 defekt	M2	21997027	POM
1220-56B-PB01	D51	56	POMMEC	M	2	D	42363775	Open drain sample pump P31 defekt	M2		POM
1220-57B-PH01A	P31	57	PPMMEC	M	6	D	42444692	Det kommer ulyd i fra pumpen	M2	22045429	POM
1220-58A-CX01A	D15	58	C01STE	U	4	U	42431099	Løs strukturplate på toppen av klorpakke	M2	22035752	SOP
1220-58A-LT 027	D15	58	PPMAUT	U	2	U	42347946	Kalibrere nivåmåler klortank	M2	21978550	SOP
1220-58B-FI 801	P17	58	PPMAUTM	M	N	U	42432594	Kalibrere flowmåler for Biocide	M2	22036595	PPM
1220-58B-PD01	D23	58	POMMEC	M	2	D	42432623	Pumpe leverer ikke (leverer igjen)	M2		POM
1220-58D-PD01A	D23	58	C32CLE	U	6	U	42339860	Reingjøring av draintrau under skumpumpe	M2	21966141	SSF
1220-58H-PD01A	D23	58	POMMEC	H	3	D	42353255	Membranbrudd. SCAVENGER INJ.PUMP	M2	21982400	PPM
1220-58H-PD60B	D23	58	PPMMEC	M	3	S	42352208	Pumpe leverer for lite.	M2	21981485	SOP
1220-58H-PI 013	D23	58	PPMAUT	U	1	S	42413717	Lekkasje i pluggger manometeruttak OR-13	M2	22022425	SOP
1220-58H-PT 028	D23	58	PPMAUT	U	3	U	42354094	Skifte trykktransmitter	M2	21982938	SOP
1220-58I-XB01	D21	58	C32CLE	U	1	U	42342438	Rengjøring av kjemikalie tanker i D-21	M2	21969349	SSF
1220-6"BBBC11-801	P16	44	PPMMEC	M	3	S	42409078	Oljelekk ut av endeflens på avkoblet rør	M2		SOP
1220-6"BBH3-100	W43	17	PPMMEC	M	Z	S	42404772	Manifolventil vanninj. P16. Knekt gir	M2	22001081	SOP
1220-6"-ML-11B014-CC1	U53	11	PPMMEC	M	N	S	42351276	Ventilratt mangler mudlinje sl.stasjon N	M2	21981661	SOP
1220-6"-ML-11B041-CC1	D43	11	C43ISP	M	N	S	42462316	Utvasking & lekkasje i rør.	M2	22065325	SIP
1220-6"-PT-19I903-KM3	P21	19	PPMMEC	M	3	S	42353072	Veldig rustet tech-lock	M2	21997553	SOP
1220-6"-PT-19I905-KM3	C44	19	PPMMEC	M	3	S	42353076	Veldig rustet tech-lock	M2	21997554	SOP
1220-6"-PV-17D504-KC3	W23	17	PPMMEC	U	3	U	42348761	Lekkasje i tech lock flens.	M2	21978544	PPM
1220-6"-PV-26A812-KC3	P26	26	PPMISP	U	3	U	42409031	FUNN: Manglende supporterer syst 26	M2		SPI
1220-62A-TB02B	N41	62	C32SUR	L	4	D	42360270	Korroderte bolter manlokk dreneringstank	M2	21955829	SSF
1220-63A-FE01A	D51	63	PPMELE	L	4	D	42421919	Element lufttørke A må byttes	M2	22028386	SOP
1220-63A-JB02A	D51	63	PPMAUT	U	6	U	42436835	Rette opp feilkoblinger luftørke A	M2	22043410	SOP
1220-63A-JB02A	D51	63	PPMAUT	U	6	U	42444763	Utst. etter omb. ikke i drift må fjernes	M2	22059908	SOP
1220-63A-JB02B	D51	63	PPMAUT	L	6	S	42467101	Jordfeil kabinett 63A-JB02B node M119	M2	22065560	SOP
1220-63A-KA60	U51	63	PPMMEC	M	6	D	42429338	Vig luftkompr. slår seg ut på vern.	M2	22032751	SOP
1220-63A-KZ01C	D51	63	POMMEC	U	6	U	42346455	Får ikke startet luftkompr C.	M2		POM
1220-63A-MT 438	D51	63	PPMAUT	U	5	U	42450981	Sjekk kalibrering på Duggpunktsmålere	M2	22060491	SOP
1220-63A-PT 369	D51	63	PPMAUT	U	5	U	42435450	Transmitter utenfor område, må byttes	M2	22042835	SOP
1220-63A-VK60A	U51	63	POMMEC	L	6	S	42433201	lekker i flens ved innløp fra heater	M2		POM
1220-63A-XV 315	D51	63	PPMAUT	U	6	U	42418414	Problemer med endebrytere på ventil	M2	22026838	SOP
1220-63A-XV 321A	D51	63	POMAUT	U	6	U	42416584	Feil på tilbakemelding i lukket posisjon	M2		POM

1220-63A-XY 417	D51	63	PPMAUT	U	6	U	42444773	Sleide i solenoide henger	M2	22059907	SOP
1220-63A-ZSH 315	D51	63	PPMAUT	M	2	D	42391028	Endebryter defekt	M2	21997102	SOP
1220-63B-PV 708	D33	63	PPMAUT	U	3	U	42422462	Utskiftning av gammelt utstyr	M2	22028257	SOP
1220-63B-PV 710	D33	63	PPMAUT	U	3	U	42422463	Utskiftning av gammelt utstyr	M2	22028256	SOP
1220-63B-PV 712	D33	63	PPMAUT	U	3	U	42422464	Utskiftning av gammelt utstyr	M2	22028255	SOP
1220-63B-PV 713	D33	63	PPMAUT	U	3	U	42422472	Utskiftning av gammelt utstyr	M2	22028249	SOP
1220-63B-PV 715	D33	63	PPMAUT	U	3	U	42422469	Utskiftning av gammelt utstyr	M2	22028251	SOP
1220-63B-PV 722	D33	63	PPMAUT	U	3	U	42422465	Utskiftning av gammelt utstyr	M2	22028254	SOP
1220-63B-PV 723	D51	63	PPMAUT	U	3	U	42422466	Utskiftning av gammelt utstyr	M2	22028253	SOP
1220-63B-PV 724	D33	63	PPMAUT	U	3	U	42422468	Utskiftning av gammelt utstyr	M2	22028252	SOP
1220-63B-PV 725	D51	63	PPMAUT	U	3	U	42422471	Utskiftning av gammelt utstyr	M2	22028250	SOP
1220-64A-AE 910	P23	64	PPMAUT	M	3	S	42404681	64A-AS910A ligger i alarm i SKR.	M2	22000997	SOP
1220-64A-FCV 913	P23	64	PPMAUT	U	3	U	42422473	Utskiftning av gammelt utstyr	M2	22028248	SOP
1220-64A-FV 035	P23	64	PPMAUT	U	3	U	42422475	Utskiftning av gammelt utstyr	M2	22028247	SOP
1220-64A-KB01A	P23	64	PPMMEC	U	3	U	42346898	Kompressoren mangler lydtemper.	M2	21977373	SOP
1220-64A-PCV 046	P23	64	PPMAUT	U	3	U	42422478	Utskiftning av gammelt utstyr	M2	22028244	SOP
1220-64A-PV 041A	P23	64	PPMAUT	U	3	U	42422476	Utskiftning av gammelt utstyr	M2	22028246	SOP
1220-64A-PV 041B	P23	64	PPMAUT	U	3	U	42422477	Utskiftning av gammelt utstyr	M2	22028245	SOP
1220-64A-VZ01	P23	64	PPMAUT	L	6	S	42346616	Bygge om N2-fyllestasjon P23	M2	21978474	SOP
1220-64A-VZ01	P23	64	PPMMEC	U	6	U	42407792	10 års resetifisering av trykkbeholdere	M2	22004190	SOP
1220-64B-PI 001A	P21	64	Q01PIP	U	1	U	42341504	Fjerne gammelt rørsystem for N2 fylling	M2	22000997	SPI
1220-65A-CT03	W11	65	PPMMEC	L	2	S	42361911	Skifte olje etter varmgang ---->	M2	21989882	SOP
1220-65A-PB04	W11	65	PPMMEC	U	2	U	42354114	Skifte sirkulasjonspumpe hydr.unit W-11	M2	21982937	SOP
1220-65A-PB62	P17	65	PPMMEC	U	3	U	42468264	Sjekk av lagre til pumpe	M2	22065775	SOP
1220-65B-VL07A	W51	65	PPMMEC	U	3	U	42414636	Etterfylle N2 på akkumulator (lekkasje)	M2	22022835	SOP
1220-65B-VL08B	W11	65	PPMMEC	U	3	U	42414674	N2 Akkumulator med lavt tryk HPU WHS	M2	22022834	SOP
1220-65C-PB01B	C14	65	PPMAUT	M	6	S	42444040	Feil MWP på instrument kulevent på HPU	M2	22058997	SOP
1220-65C-PB03B	C34	65	PPMAUT	U	6	U	42460971	Alarm inne på panel: motorfeil	M2	22060488	SOP
1220-680-PCV 026	P41	68	PPMAUT	L	2	S	42344935	Ulyder fra PCV. Virker ikke som den skal	M2	21978539	SOP
1220-70D-FS 020	U41	70	POMAUT	M	2	D	42422347	Detektor ligger med feil.	M2	22028172	POM
1220-70D-FS 021	U41	70	POMAUT	M	2	D	42422348	Detektor ligger med feil.	M2	22028171	POM
1220-70D-FS 701	L21	70	POMAUT	M	2	D	42427350	Detektor ligger med feil.	M2	22032040	POM
1220-70D-FS 701	L21	70	PPMAUT	M	2	D	42404680	Flowswitch i L-21 ligger i alarm.	M2	22000988	SOP
1220-70D-FS 708	L31	70	POMAUT	H	2	D	42413150	Kule står fast i flowmeter	M2	22022177	POM
1220-70D-FS 803	W11	70	POMAUT	M	2	D	42427349	Detektor ligger med feil.	M2	22032041	POM
1220-71A-CT01A(D)	M10	71	PPMMEC	U	3	U	42362201	Skifte slanger fra kontrollpanel	M2	21989746	SOP
1220-71A-CT01C	M10	71	POMMEC	H	3	D	42422388	Dieselmotor på brannpumpe C starter ikke	M2	22028390	POM
1220-71A-CT01C(D)	M10	71	PPMMEC	U	3	U	42362366	Skifte slanger fra kontrollpanel	M2	21991888	SOP
1220-71A-CT01D(D)	M50	71	PPMMEC	U	3	U	42362367	Skifte slanger fra kontrollpanel	M2	21991887	SOP
1220-71A-JB01E	U11	71	PPMAUT	M	3	S	42469515	Jordfeil brannpumpe E	M2	22066400	SOP
1220-71A-PA01E	U11	71	PPMAUT	U	3	U	42423433	Brannpumpe E kommer inn med feilmelding	M2	22031923	SOP
1220-71A-PA02A	M10	71	PPMMEC	M	3	S	42343855	Oljelekkasje i simering	M2	21970581	SOP
1220-71A-PA02B	M50	71	POMMEC	M	3	S	42358000	Brannvannpumpe B lekker kjølevæske.	M2	21985069	POM
1220-71A-PA02C	M10	71	PPMMEC	M	3	S	42343452	Oljelekkasje i simering Bytt status til M	M2	21969797	SOP
1220-71A-PA02D	M50	71	PPMMEC	M	3	S	42343859	Oljelekkasje i simering	M2	21970963	SOP
1220-71A-PA04A	M10	71	PPMMEC	L	6	S	42434075	Lekker ut av sladre hull på pumpe	M2	22042833	SOP
1220-71A-TAL 451	M10	71	PPMAUT	M	2	D	42421608	Brannpumpe A ligger inne med TAL	M2	22028177	SOP
1220-71A-TB02D	M50	71	PPMMEC	U	3	U	42438398	Oljen har for høyt partikkel innhold	M2	22044469	SOP
1220-71A-XY 632	M10	71	POMAUT	H	3	D	42343073	Soleniod åpner ikke for nødstart	M2	21969605	POM
1220-71A-XY 728	M50	71	PPMAUT	M	3	S	42402552	Tar lang tid før startrele åpner.	M2	21997547	SOP
1220-71A-XY 732	M50	71	PPMAUT	U	3	U	42362106	Ventil vil ikke operere normalt	M2	21989751	SOP
1220-71D-PI 173	F41	71	PPMAUT	U	1	U	42341350	Lekkasje i NPT til manometer	M2	21968862	SOP
1220-71D-SW05H	W55	71	POMLOG	U	3	U	42418146	Skilt på skap ikke lesbar	M2	22026442	POM
1220-71D-SW06A	P15	71	PPMMEC	M	3	S	42418003	Drain ventil lekker	M2	22025720	SOP
1220-71F-SQ02	U11	71	PPMMEC	M	3	S	42350632	Lekkasje i fittings på N2 flaske	M2	21981495	SOP
1220-71F-TI 001	U13	71	POMAUT	H	3	D	42424117	TI viser feil temperatur	M2	22029874	POM

1220-71F-XY 151	D55	71	PPMAUT	L	3	U	42343436	Funksjonstest av solenoider til vanntåke	M2	21970029	SOP
1220-71G-SN03A	U31	71	PPMMEC	M	3	S	42341605	Lekkasje i flens på ventil	M2	21968786	SOP
1220-71H-SJ04A	D07	71	PPMMEC	U	3	U	42349732	Brannkanoner mangler plombering	M2	21979310	SOP
1220-71J-ZS 701	W15	71	PPMAUT	M	3	S	42340934	Feil på tilbakemelding på AFFF.	M2	21967889	SOP
1220-71K-PCV 003	M50	71	PPMMEC	M	3	S	42403696	Lekk. gjennom stengt ventil brannhydrant	M2	22000995	SOP
1220-71K-SP03C	U13	71	PPMMEC	M	3	S	42411118	Lekker i begge munnstykker	M2	22019258	SOP
1220-71K-SP03G	U36	71	PPMMEC	M	3	S	42411119	Mangler et munnstykke	M2	22019257	SOM
1220-71K-SP04F	D15	71	PPMMEC	M	3	S	42411120	lekkasje/stenger ikke PCV 029	M2	22019255	SOP
1220-71K-SP05E	W15	71	PPMMEC	M	3	S	42411121	lekker/stenger ikke + Høyt trykk pcv 043	M2	22019254	SOP
1220-71K-SP05F	W55	71	PPMMEC	M	3	S	42411152	Lekkasje/stenger ikke 71K-SP05F	M2	22019253	SOP
1220-71K-SP06A	P11	71	PPMMEC	M	3	S	42411153	lekkasje/stenger ikke PCV 047	M2	22019251	SOP
1220-71K-SP06D	P53	71	PPMMEC	M	3	S	42411154	lekkasje/stenger ikke PCV 053	M2	22019250	SOP
1220-71K-SP06E	P25	71	PPMMEC	M	3	S	42411157	lekkasje/stenger ikke PCV 056	M2	22019249	SOP
1220-71K-SP06F	P55	71	PPMMEC	M	3	S	42411158	lekkasje/stenger ikke PCV 057	M2	22019248	SOP
1220-71K-SP10C	C34	71	PPMMEC	M	3	S	42411159	Lekkasje/stenger ikke PCV 067	M2	22019246	SOP
1220-72B-SL01A	L27	72	PPMMEC	M	3	S	42418811	N2 flaske 22l må fylles.	M2	22026439	PPM
1220-72D-SH02	D45	72	PPMMEC	M	3	S	42405293	Ødelagt gjenger på tilkobling CO2 flaske	M2	22000985	SOP
1220-73		73	PPMPRO	L	A	S	42353077	Gullfaks piggsender, ny piggvogn/løftein	M2	21982933	SOP
1220-73A-CA54	D55	73	PPMMEC	U	2	U	42463198	Lekkasje fra filter	M2		SOP
1220-73A-CX02 (G1)	D15	73	POMMEC	M	3	S	42444972	RC Stor klaring mellom tannhjul/krans	M2	22058986	SOP
1220-73A-CX02 (G1)	D15	73	PPMMEC	U	3	U	42427295	Skifte brems og motor til svingmaskineri	M2	22032045	SOP
1220-73A-CX02 (G2)	D15	73	PPMMEC	U	3	U	42427299	Skifte brems og motor til svingmaskineri	M2	22032044	SOP
1220-73A-CX02 (G3)	D15	73	PPMMEC	U	3	U	42427301	Skifte brems og motor til svingmaskineri	M2	22032043	SOP
1220-73A-CX08A	D15	73	PPMMEC	M	3	S	42341790	Lekkasje på hydr.rørkobling brems sørkr	M2	21969218	SOP
1220-73A-CX17	D15	73	CO1STE	M	3	S	42431123	Montere sikringsskinne A-ramme	M2	22036347	SOP
1220-73A-CX32 (M)	D15	73	POMLOG	U	2	U	42429625	Skifte av vindusviskerarm	M2	22035066	SOP
1220-73A-CX33 (M)	D15	73	POMLOG	M	2	D	42339930	Spylervæske kommer ikke på vinduer	M2	21968792	POM
1220-73A-CX52 (G3)	D55	73	POMMEC	M	3	S	42445142	RC Stor klaring mellom tannhjul/krans	M2		SOP
1220-73A-CX52 (H1)	D55	73	PPMMEC	U	3	U	42355992	RC 2011 Svingmotorer må byttes	M2	21984056	SOP
1220-73A-CX55A	D55	73	POMMEC	U	3	U	42363158	Bremser på bomwinch	M2	21990824	POM
1220-73A-CX55A	D55	73	PPMMEC	M	3	S	42343114	Hydr.lekkasje fra rør mellom motorer	M2	21970022	SOP
1220-73A-CX60	D55	73	POMLOG	M	3	S	42340076	Oppflising på noen tråder på ståltau	M2	21967895	PPM
1220-73A-CX65	D55	73	PPMISPS	M	3	S	42339910	Rustutslag i kranbom	M2	21968132	SIP
1220-73A-CX67	D55	73	CO1STE	M	3	S	42431045	Synergi, Montere sikringsskinne A-ramme	M2	22036349	SOP
1220-73A-CX67	D55	73	C32SUR	U	3	U	42340072	Gravrust på bufferplater i A-ramme	M2	21967983	SSF
1220-73A-EC51	D55	73	POMAUT	H	3	D	42339973	Feil med bomfunksjon nordkran	M2	21965975	POM
1220-73A-EC51	D55	73	PPMAUT	M	3	S	42341933	Hugging når brems går på etter sving	M2	21969216	SOP
1220-73A-EJ52	D55	73	IMOTEL	U	3	U	42354567	Bestille ny optisk rotary joint	M2	21983081	SOM
1220-73A-GK01A	D15	73	POMMEC	H	3	D	42359441	Motor til kjølevifte hydraulikk er def.	M2	21987091	POM
1220-73A-MA01	D55	73	POMMEC	U	3	U	42344411	Ising i kran, Ttopp og pikke is	M2	21970456	POM
1220-73A-MA01	D55	73	PPMAUT	U	3	U	42445238	MO Feil på turtallet i display kranecabin	M2	22059906	SOP
1220-73A-MA01	D55	73	PPMELE	U	3	U	42361471	Ekstra Stikkontakt i kran	M2	21989753	SOP
1220-73A-MA01	D55	73	PPMMEC	U	3	U	42346998	Feil styrestikke/funksjon heis, Sør kran	M2	21977375	SOP
1220-73A-MA01 (G1)	D55	73	PPMMEC	U	3	U	42372733	Boreskop insp. av pumpefordelingsgji	M2	21997103	SOP
1220-73A-MA02	D15	73	PPMELE	U	3	U	42361468	Ekstra Stikkontakt i kran	M2	21989754	SOP
1220-73A-MA02 (G1)	D15	73	PPMMEC	U	3	U	42358938	Boroskop insp. pumpefordelingsgir	M2	21987072	SOP
1220-73A-MB05	D15	73	PPMMEC	U	3	U	42414006	Utskiftning av deler til bom vinsj	M2	22022838	SOP
1220-73A-MB05 (G1)	D15	73	PPMMEC	M	3	S	42344399	Ingen kontroll med nivå i giret	M2	21972547	SOP
1220-73A-MB06 (G2)	D15	73	PPMMEC	U	3	U	42462062	Anbefaling: Bytte olje	M2	22062099	SOP
1220-73A-ZS 098	D55	73	POMLOG	U	3	U	42359252	Justere endebryster	M2	21987066	POM
1220-73B-MA60	P11	73	PPMMEC	U	1	S	42464351	Traverskran går ikke	M2	22062967	PPM
1220-73B-MA60	P11	73	PPMMEC	U	1	U	42465488	Dårlig stand på traverskran	M2	22064276	SOP
1220-73B-MA61	P17	73	PPMMEC	U	1	U	42356054	Sertifisering av talje /løfteutstyr.	M2	21984055	SOP
1220-73B-MB53B	P51	73	PPMMEC	U	1	U	42414524	Demontering/ general overhaling	M2	22022836	SOP
1220-73C-MC01	D35	73	PPMELE	U	3	U	42359461	Programering av Alimakheis søyle 1	M2	21987070	SOP
1220-73C-MC01	D35	73	PPMELE	U	3	U	42413152	Utbedring av heis D-omr. etter siste FV	M2	22022429	SOP

1220-73C-MC02	L36	73	PPMELE	U	3	U	42413155	Utbedring av heis LQ-omr. etter siste FV	M2	22022428	SOP
1220-73C-MC02	L36	73	PPMELE	U	3	U	42429153	Forbedre logikk på heis. Pasientlåsing	M2		SOP
1220-73C-MC03	C30	73	PPMELE	U	3	U	42413156	Utbedring av heis søyle 3 etter siste FV	M2	22022427	SOP
1220-74		74	L-OPS	L	A	U	42405594	Rive noen vegger i PV kontormodul	M2	22001089	SOP
1220-74A		74	PPMMEC	U	A	U	42346129	Defekt dør inn til antennenårm L37	M2	21972555	SOP
1220-74A-CX01	C13	74	PPMMEC	U	3	U	42345238	Hyd.olje drypp lekkasje på vannrett dør	M2	21972552	SOP
1220-74A-CX09	D35	74	POMMEC	H	3	D	42422300	Dør ut fra tungtlayer ut av drift	M2	22028410	POM
1220-74A-CX09	D35	74	PPMMEC	U	3	U	42423601	Rep. dør på tungtlayer	M2	22031130	SOP
1220-74A-CX14	D25	74	PPMMEC	U	3	U	42423413	Luftstyrt brannør 74A-CX14 defekt	M2	22031134	SOP
1220-74A-CX14	D25	74	PPMMEC	M	3	S	42467054	Dør går treigt og har ulyd	M2		SOP
1220-74A-CX32	W33	74	PPMMEC	M	3	S	42419240	Reim på dør inn til riserrom W-33	M2	22029689	SOP
1220-74A-CX34	W33	74	PPMMEC	M	3	S	42462751	Brannør i W-33-03 Nord / Sør	M2	22062604	SOP
1220-74A-CX51 (M)	L52	74	PPMELE	U	3	U	42429201	Reparere el. dørmotor L52	M2	22035067	SOP
1220-74A-CX77	D17	74	PPMMEC	M	3	S	42350968	Dør kan ikke opererast	M2	21981494	SOP
1220-74A-MX65	P17	74	PPMMEC	M	3	S	42465493	Dør til Lur P17 i ustand	M2	22064979	SOP
1220-74A-VX02	N11	74	PPMMEC	U	3	U	42407828	10 års resertifisering av trykkbeholdere	M2	22004191	SOP
1220-74A-VX06	N31	74	PPMMEC	U	3	U	42407830	10 års resertifisering av trykkbeholdere	M2	22004192	SOP
1220-74D-MX01B	L00	74	PPMAUT	U	1	U	42353154	Defekte lager på tredemølle nr. 2	M2	21982982	SOP
1220-74E		74	L-OPS	L	A	U	42412793	Utbedre isolasjon på fryseeanlegg	M2	22021584	SOP
1220-74E		74	PPMELE	U	A	U	42361017	Manglende tagskilt på kjøkkenutstyr.	M2	21988710	SOP
1220-74E		74	PPMELE	M	A	D	42426899	Glo ray overvarme defekt	M2	22032055	SOP
1220-74E-MM01	M50	74	POMMEC	L	1	D	42405386	Montere kniver i matkvern	M2	22000921	POM
1220-74E-PS18	L53	74	PPMELE	U	1	S	42434914	Bytte tilt motorstekepanne bysse.	M2	22042941	SOP
1220-74E-PS52	L53	74	PPMELE	U	1	U	42356318	Montere permanent stikk varmeskap bysse	M2	21986163	SOP
1220-74E-PS84F	L53	74	PPMELE	U	1	S	42347156	Utskifting av dampovn i byssa	M2	21977339	SOP
1220-76A-MF01C	M30	76	POMMEC	H	3	D	42424923	Hydr styring sviktet på LB 3	M2		POM
1220-76A-MF01E	M50	76	PPMELE	M	3	S	42370550	Libbåt 5: navigasjonslys virker ikke	M2	21996485	SOP
1220-76A-MF01F	F41	76	PPMELE	M	3	S	42370551	Navigasjonslys virker ikke på libbåt 6	M2	21996483	PPM
1220-76A-SA01A	M10	76	PPMMEC	U	3	U	42353401	Dårlig siket gjennom vinduene	M2	21982981	SOP
1220-76A-SA01B	M30	76	CO1STE	U	3	U	42359726	Re-installere 2 seter i LB2 og i LB3.	M2	21987403	PPM
1220-76A-SA01B	M30	76	PPMELE	M	3	S	42353398	Håndholdt lyskaster virker ikke	M2	21982926	SOP
1220-76A-SA01B	M30	76	PPMMEC	M	3	S	42353463	Synergi. Vridde seler i 15 stoler	M2	21982924	SOP
1220-76A-SA01C	M30	76	PPMMEC	U	3	U	42356855	Løse vololister på fotbrett i libbåt 3.	M2	21986160	SOP
1220-76A-SA01D	M50	76	PPMELE	M	3	S	42353400	Håndholdt lyskaster virker ikke	M2	21982925	SOP
1220-76A-SA01D	M50	76	PPMELE	U	3	U	42414622	Syn.1208593 Kabel til motorvarmer kappet	M2	22022831	SOP
1220-76F-SC02A	D21	76	PPMMEC	U	3	U	42421361	Løst sikkerhetsutstyr	M2		SOP
1220-76F-SC12A	W07	76	PPMMEC	M	3	S	42435679	Deksel til nøddusj er ødelagt	M2	22042827	SOP
1220-77A-EC03	L53	77	POMELE	H	3	D	42424863	Jordfeil på UV systemet	M2	22029886	POM
1220-77A-EC03	L53	77	PPMELE	U	3	U	42354172	Stadig alarmer fra kjøkkenavtrekksystem	M2	21982934	SOP
1220-77A-GK04A	L26	77	PPMMEC	U	3	U	42465661	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064269	SOP
1220-77A-GK04B	L26	77	PPMMEC	U	3	U	42465773	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064268	SOP
1220-77A-GK06A	L36	77	PPMMEC	U	3	U	42465775	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064267	SOP
1220-77A-GK07A	L46	77	PPMELE	U	1	U	42428162	Strømforsbruk avtrekksvifte	M2	22032175	SOP
1220-77A-TAHH 589	L24	77	PPMELE	M	2	D	42434947	Defekt TAHH til heater lugar 2420B	M2	22042829	SOP
1220-77A-XV 139	L41	77	PPMELE	U	3	U	42416807	Brannspjeld går tregt	M2	22025735	SOP
1220-77B-GK01A	U43	77	PPMMEC	U	2	U	42465777	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064266	SOP
1220-77B-GK07A	U43	77	PPMMEC	U	5	U	42465780	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064265	SOP
1220-77B-GK08A	U43	77	PPMAUT	U	5	U	42351845	Viften bruker 3 minutter på å stoppe	M2	21981668	SOP
1220-77B-GK18B	U43	77	PPMMEC	U	5	U	42465842	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064994	SOP
1220-77B-GK70A	D43	77	PPMMEC	U	5	U	42465844	Høy vibrasjon Sjøkk reimer /oppretting	M2	22064995	SOP
1220-77B-HV 250B	FN1	77	PPMAUT	L	5	D	42353811	Ventil feiler under kjøring	M2	21982927	SOP
1220-77B-TSHH 310	D25	77	PPMAUT	M	3	S	42351510	Heater kommer inn med TAHH	M2	21981491	SOP
1220-77B-TT 310A	D25	77	PPMAUT	L	2	S	42421443	Flytte temp.transmitter til nytt målepun	M2	22027881	SOP
1220-77B-XV 030	U23	77	PPMELE	M	3	S	42402272	Brannspjeld i U23 henger avogtil i åpen.	M2	21997551	SOP
1220-77B-XV 213	U43	77	PPMELE	M	3	S	42405086	B.spjeld åpner ikke/går tregt	M2	22000996	PPM
1220-77B-XY 030	U23	77	POMAUT	H	3	D	42401591	Brannspjeld lukker ikke	M2	21997088	POM

1220-77B-XY 030	U23	77	POMELE	H	3	D	42401578	Brannspjeld lukker ikke	M2	21714060	POM
1220-77B-XY 049	U23	77	POMELE	H	3	D	42401581	Brannspjeld lukker ikke	M2	21714060	POM
1220-77B-XY 049	U23	77	PPMMEC	M	3	S	42401592	Brannspjeld lukker ikke	M2	21997086	SOP
1220-77B-XY 213	U43	77	PPMELE	U	3	U	42401587	Brannspjeld åpner ikke på kommando	M2	21997101	SOP
1220-77B-XY 214	U43	77	POMAUT	H	3	D	42401554	KV tilbakermeldingsfeil brannspjeld	M2	21714060	POM
1220-77B-XY 295	U23	77	PPMELE	H	3	D	42401584	Brannspjeld lukker ikke ved 1. forsøk	M2	21714060	POM
1220-77B-ZSL 061	U43	77	PPMAUT	U	1	U	42343323	Endebryter må justeres	M2	21970030	SOP
1220-77B-ZSL 214	U43	77	PPMAUT	L	1	D	42401588	Tilbakemeldingsfeil brannspjeld	M2	21997093	SOP
1220-77C-GK03A	W07	77	PPMAUT	U	5	U	42444231	Ødelagt kabel til vibrasjonsovervåkning	M2	22059910	SOP
1220-77C-GK04A	W07	77	PPMELE	L	5	D	42461588	Vifte vil ikke starte	M2	22061039	SOP
1220-77C-OV 002	W07	77	PPMAUT	U	5	U	42444691	Sjekk spjeld.Mangler stengt-signal i SKR	M2	22059909	SOP
1220-77C-PDSL 099A	W07	77	PPMAUT	M	3	S	42356775	Trykkbryteren virker ikke.	M2	21986141	SOP
1220-77C-PDSL 101A	W07	77	POMAUT	H	3	D	42356773	12M FV-G-AUT-F HVAC STRØMNINGSVAKTER	M2	21670102	POM
1220-77C-PDSL 101A	W07	77	POMAUT	H	3	D	42358387	Bryteren ga ikke alarm i kontrollrom	M2	21986058	POM
1220-77C-XY 076	W07	77	POMAUT	H	3	D	42404217	Brannspjeld feiler å lukke på 1. forsøk	M2	21714059	POM
1220-77C-XY 109	W07	77	POMAUT	H	3	D	42404215	Brannspjeld feiler å lukke.	M2	21714059	POM
1220-77C-XY 109	W07	77	POMAUT	H	3	D	42404221	Brannspjeld feiler å lukke.	M2	21999039	POM
1220-77D-GK04A	FN1	77	PPMMEC	U	2	U	42465846	Høy vibrasjon Sjekk reimer /oppretting	M2	22064993	SOP
1220-77D-GK07B	U23	77	PPMMEC	U	2	U	42465848	Høy vibrasjon Sjekk reimer /oppretting	M2	22064992	SOP
1220-77D-GK08A	U23	77	PPMMEC	U	2	U	42465850	Høy vibrasjon Sjekk reimer /oppretting	M2	22064990	SOP
1220-77D-OV 101	C13	77	PPMMEC	U	2	U	42407932	10 års resertifisering av trykkbeholdere	M2	22004199	SOP
1220-77D-OV 102	C24	77	PPMMEC	U	2	U	42407934	10 års resertifisering av trykkbeholdere	M2	22004188	SOP
1220-77D-OV 103	C33	77	PPMMEC	U	2	U	42407935	10 års resertifisering av trykkbeholdere	M2	22004187	SOP
1220-77D-OV 104	C44	77	PPMMEC	U	2	U	42407936	10 års resertifisering av trykkbeholdere	M2	22004185	SOP
1220-77D-TT 001	U43	77	PPMAUT	M	2	D	42343308	Defekt transmitter	M2		SOP
1220-78		78	PPMMEC	L	A	U	42411956	Test pumper må overhales/kalibreres	M2	22019546	SOP
1220-78A-CX26	D25	78	PPMMEC	U	1	U	42345912	10 års resertifisering av trykkbeholdere	M2	21971109	PPM
1220-78A-CX52	D21	78	PPMMEC	U	1	S	42372717	Akkumulator ødelagt.Byttes.	M2	21997104	SOP
1220-78A-CX52	D21	78	PPMMEC	U	1	S	42425706	Spylepistol 13 og 29 defekt	M2	22031110	SOP
1220-8"BBD7-005	P35	20	PPMMEC	M	2	D	42467376	Ventil oppstrøms PSV er lekk.	M2	22065660	SOP
1220-8"CKH5-056	W43	16	POMMEC	H	3	D	42469161	Defekt Chekventil P-44 mot test	M2	22066217	POM
1220-8"-DO-56A009-CC2	P31	56	CO1PIP	U	3	U	42364192	3/4" prøvpunkt knekket i sveis.	M2	21990777	SVM
1220-8"-PL-21A801-CC3	P16	21	CO1PIP	U	3	U	42414884	Permanent utbedring av reparert rør	M2	22022833	SOP
1220-8"-PL-21A801-CC3	P16	21	POMMEC	U	3	U	42414883	Permanent utbedring av reparert rør	M2		POM
1220-8"-PL-21A801-CC3	P16	21	PPMISUR	H	3	D	42412574	FUNN: På linje 8"-PL-21A801-CC3 i P16	M2	22021750	SOP
1220-8"-PV-27D130-HC4	P21	27	C32SUR	U	1	U	42345886	Funn Utvendig korrosjon på rør	M2	21971697	SSF
1220-8"-WF-71A022-CM1	M10	71	CO1PIP	U	3	U	42465109	Brannvannventil plassert under dekk.	M2	22064273	SOP
1220-80		80	PPMELE	L	A	U	42340794	Bytte hjelm og visir i tavlerom.	M2	21968798	SOP
1220-800-EG01C(G)	D45	80	PPMMEC	U	6	U	42360883	Inspeksjon av gear utføres av Renk	M2	21988364	SOP
1220-800-EZ01B	D45	80	PPMELE	L	6	S	42417732	Spondeteksjonsalarm sump D turbin B	M2	22025561	PPM
1220-80A-EG01B(T)	D45	80	PPMELE	U	6	U	42361879	Thermocouple feiler på B- turbin	M2	21989937	SOP
1220-80A-EG01B(T)	D45	80	PPMMEC	U	6	U	42371952	Bytte thermocoupler Hovedkraft B	M2		SOP
1220-80A-EG01C(T)	D45	80	PPMMEC	U	6	U	42437995	Inspeksjon av 1 stg comp blades Turbin C	M2	22044471	SOP
1220-80A-JB01A	U43	80	PPMELE	L	6	S	42353382	Alarmskriver virker ikke	M2	21982288	SOP
1220-80A-TE 335A	D45	80	PPMELE	M	6	D	42370867	Brudd i thermocouple T5.4, turbin B	M2	21997096	SOP
1220-80B-PC01D	D45	80	PPMMEC	L	6	S	42407799	Smøreljep. for gear gir lite trykk genC	M2	22004179	SOP
1220-82D		82	PPMELE	L	A	S	42345882	Overhaling av opptrekkbare Siemens bryte	M2	21972556	SOP
1220-82D		82	PPMELE	U	A	U	42362598	Ny 125A stikkontakt i P51	M2	21991885	SOP
1220-82D-EL14	FS1	82	PPMELE	U	1	S	42430137	Defekte jordfeilbrytere	M2	22035063	SOP
1220-82D-EL25	P43	82	PPMELE	U	3	U	42360274	RUH: Bytte et deksel på EX-tavle P-43	M2	21987452	SOP
1220-82D-EL27	P33	82	PPMELE	U	3	U	42353326	Oppdatere kursoversikt i tavle 82D-EL27	M2	21982399	SOP
1220-82D-EL29 070	P23	82	PPMELE	U	N	U	42364493	Melding om jordfeil fra tavle	M2	21996527	SOP
1220-82D-EL32 070	P45	82	PPMELE	U	N	U	42364494	Melding om jordfeil fra tavle	M2	21996525	SOP
1220-82D-EL60	P17	82	PPMELE	U	3	U	42364492	Melding om jordfeil fra tavle	M2	21996531	SOP
1220-82D-EL60	P17	82	PPMELE	U	3	U	42430182	Defekte jordfeilautomater	M2	22035065	SOP
1220-82D-EL63	L53	82	PPMELE	U	3	U	42427965	82D-EL63 kurs 40	M2	22032176	SOP

1220-82D-EL83	L33	82	PPMELE	U	3	U	42435014	Koble opp vaskemaskin og tørketrommel	M2	22042940	SOP
1220-82D-EN02	U21	82	PPMELE	U	3	U	42370304	Sjekk Jording skjerm av Profibuskabler	M2	21996528	SOP
1220-82D-EN53	D31	82	POMELE	U	3	U	42424539	3M FV-G-ELE KOPL BRYTERE 82D-EN51/2/3/4	M2	21954896	POM
1220-82D-EN71	L41	82	PPMELE	M	3	S	42352682	Kontaktor i avgang til 82C-ET73 må bytte	M2	21982287	SOP
1220-84B-XV 090		84	PPMAUT	M	N	S	42360715	Manglende tilbakemelding fra ventil	M2	21988761	SOP
1220-84D		84	PPMELE	M	A	D	42341313	Knust lysarmatur EA-AU-84D-0105-01	M2	21968796	SOP
1220-84D-EL30	P45	84	PPMELE	U	3	U	42364429	Melding om jordfeilfra tawle	M2	21996728	SOP
1220-84D-EL31	P35	84	PPMELE	M	3	S	42428712	84D-EL31 Jordfeil kurs 1 Nødlys F15	M2	22035059	SOP
1220-84D-EL82	L53	84	PPMELE	M	3	S	42431213	84D-EL82 Jordfeil kurs 3	M2	22035740	SOP
1220-85D-ED76	L25	85	PPMELE	U	3	U	42402224	Merking og tegninger samsvarer ikke.	M2	21997557	SOP
1220-85D-JB01	W07	85	E-BOR	U	3	U	42417688	Oppdatere dokumentasjon ifm riving	M2	22025732	SDW
1220-86		86	IMOTEL	L	A	U	42436967	Flotell periode - assistanse Tele	M2	22043915	POM
1220-86A-JE01B	L52	86	IMOTEL	U	6	U	42465128	Reinstallere/bytte CPU enhet	M2	22064271	SOM
1220-86A-JE02	L52	86	IMOTEL	L	6	S	42464723	Reinstallere/bytte CPU enhet	M2	22063205	SOM
1220-86A-JE04	L25	86	IMOTEL	L	6	S	42464724	Reinstallere/bytte CPU enhet	M2	22064264	SOM
1220-86A-JR02B	L25	86	IMOTEL	H	3	D	42462099	Radioswitch har stoppet opp	M2	22061726	POM
1220-86A-JR02C	L25	86	IMOTEL	H	3	D	42361445	Com4500, defekt power	M2	21988728	SOM
1220-86A-JR03C	L25	86	IMOTEL	U	3	U	42417868	Sjette feltstyrke "Leaky feeder" SNA	M2	22025730	SOM
1220-86A-JR05B	D15	86	IMOTEL	H	3	D	42427414	Defekt VHF radio	M2	22031953	POM
1220-86A-JR05B	D15	86	IMOTEL	H	3	D	42431181	Defekt VHF radio	M2	22035862	SOM
1220-86B-JC01	L25	86	IMOTEL	U	3	U	42403762	Omprogrammering av telefonapparat mot 2.	M2	21999075	SOM
1220-86B-JC01	L25	86	IMOTEL	U	3	U	42467250	Rette opp feil i dkumentasjon og kabling	M2	22065113	SOM
1220-86B-JC02	L25	86	IMOTEL	U	3	U	42425684	Feil på 4-wire E&M i pos.61 Lim2	M2	22031126	SOM
1220-86E-JC11	L25	86	IMOTEL	M	3	S	42347798	Manglende dekning PA ved alarm	M2	21977406	SOM
1220-86E-JC11	L25	86	IMOTEL	U	3	U	42350914	Feil på Ampl. A5	M2	21981277	SOM
1220-86E-JC11	L25	86	IMOTEL	M	3	U	42437578	PA system A - jordfeil	M2	22043879	POM
1220-86E-JC11	L25	86	IMOTEL	U	3	U	42439440	PA meldinger klipper -Synergi-1213656	M2	22044806	SOM
1220-86E-JC13	L25	86	IMOTEL	U	3	U	42421914	Linjefeil på forsterker 86E-JC22Q	M2	22028547	SOM
1220-86E-JC19E	L25	86	IMOTEL	U	3	U	42343553	Alarm på forsterker 86e-jc19e, sjekkes	M2	21970026	SOM
1220-86E-JC22J	L25	86	IMOTEL	U	3	U	42362459	Jordfeil på forsterker B22	M2	21989992	SOM
1220-86F		86	IMOTEL	L	A	U	42363211	Skifte av EXTRON møterom2/L32	M2	21990791	IMO
1220-86F-JC11	L25	86	IMOTEL	U	3	U	42420762	Bytte HD i SNO-W07	M2	22027884	SOM
1220-86F-JL25	U31	86	IMOTEL	U	3	U	42408011	Oppdatere brannmur lisenser teknisk nett	M2	22002985	SOM
1220-86J-JC03	L25	86	IMOTEL	U	1	U	42345408	Bestille TV for Odffjell Elektro D17	M2	21971140	SOM
1220-86J-JC07	L25	86	IMOTEL	U	1	U	42423093	Feil på Gyrosphere i STD22	M2	22028513	SOM
1220-86M-JB03C	L35	86	IMOTEL	U	3	U	42354695	Assistere Servicesenter, ny TMS	M2	21983460	SOM
1220-86M-JB06	L37	86	IMOTEL	U	3	U	42344854	Defekt bryter til vindusvisker i helibua	M2		SOM
1220-86M-JB06	L37	86	POMAUT	M	3	S	42361563	Vindusvisker helibu	M2	21989740	SOM
1220-86M-JR03D	L37	86	IMOTEL	M	3	S	42344624	Støy på LOG freq, sjekke Radio	M2	21970765	SOM
1220-86M-JR05	L37	86	IMOTEL	U	3	U	42405047	Skifte kjølevifte på front	M2	21999154	SOM
1220-86M-JR10K	A00	86	IMOTEL	U	3	U	42431228	Høg SWR på VHF antenne i livbåt 5	M2	22035606	SOM
1220-86M-JR10M	A00	86	IMOTEL	U	3	U	42444081	VHF i MOB-båt, skifte kabel/antenne	M2	22059911	SOM
1220-86N-JC60	U41	86	IMOTEL	U	3	U	42350623	Ende til ende loop for telemetrisignal	M2	21981673	SOM
1220-86P-JC02	L25	86	IMOTEL	U	3	U	42349185	Swidd kontakt på plint 10A 505A	M2	21979314	SOM
1220-86Q-EB04	L26	86	PPMELE	U	3	U	42425325	Skifte batteri 17A i batteribank A	M2	22031129	SOP
1220-86U		86	IMOTEL	L	A	U	42431833	Feil verdi på vindmåler	M2	22036210	SOM
1220-86U-JB08A	L35	86	IMOTEL	U	6	U	42422221	Feil på avleseing i radiatorom	M2	22028382	SOM
1220-86Z-JC60	U41	86	IMOTEL	U	3	U	42356700	Hakkete bilde på CCTV monitor i CCR	M2	21986161	SOM
1220-87		87	PPMAUT	L	A	U	42431202	Div arbeide ifm med nye mingass målere	M2	22035755	SOP
1220-87		87	PPMAUT	L	A	U	42436651	sjekk jekker/kraner/hydralikk aggergater	M2	22043408	SOP
1220-87		87	PPMAUT	L	A	U	42444649	llandsendelse av utstyr for kalibrering	M2	22054901	PPM
1220-87B-H076	L21	87	IMOAUTSA	U	2	U	42354115	HVAC node, CP kort i stopp, må startes i	M2	21982935	SOM
1220-87B-JB15	FN1	87	PPMAUT	U	2	U	42467100	Jordfeil kabinett 87B-JB15 node P018	M2	22065568	SOP
1220-87B-JB81	F51	87	IMOAUTSA	M	3	S	42351791	Feil på Profibus komm. mot HIMA-IOPS	M2	21981487	POM
1220-87B-JE24A	U31	87	POMAUT	H	3	D	42444956	Feil på WinCC servere A-servere	M2	22058859	POM
1220-87B-JF20	W23	87	PPMAUT	M	3	S	42358163	Operatørstasjon i W23 virker ikke. WHCP	M2	21986140	SOP

1220-87B-JU46B	L52	87	IMOAUTSA	U	3	U	42360228	CCTV-bilde på storskjerm hakker	M2	21987420	POM
1220-87B-JU99A	U31	87	IMOAUTSA	L	2	S	42422879	Slette gamle backupfiler fra PIMAG	M2	22030489	SOM
1220-87B-JU99A	U31	87	IMOAUTSA	M	2	D	42439290	Manglende signaler i IP21	M2	22044803	SOM
1220-87B-JU99A	U31	87	PPMAUT	U	2	U	42342301	"Generell" PO levranderstøtte IMS Siemen	M2	21970034	SOP
1220-87B-JU99A	U31	87	PPMAUT	L	2	S	42406845	Ving og masterstatus i IP21	M2	22002627	SOP
1220-87B-JU99A	U31	87	PPMAUT	M	2	D	42412076	Choke signal til P-29	M2	22021580	SOP
1220-87B-JU99A	U31	87	PPMAUT	M	2	D	42412191	P45WI viser feil i IP21	M2	22021579	SOP
1220-87B-JU99A	U31	87	PPMAUT	L	2	S	42426084	Ventilsignaler P-45 og P-16	M2		SOP
1220-87B-JU99A	U31	87	PPMAUT	L	2	S	42433324	Tag "16D-HIC_006" oppdateres ikke	M2		SOP
1220-87B-M126	D21	87	IMOAUTSA	H	3	D	42406823	Feilsøke tripp av vanninjeksjon -utkall	M2	22001917	POM
1220-87B-S031		87	IMOAUTSA	H	3	D	42405299	PAS system ute av funksjon - link feil	M2	21999114	POM
1220-87B-U022	FS1	87	IMOAUTSA		Z	S	42354119	Profibus DP slave feil UPA	M2		POM
1220-87C-JG11	U21	87	IMOAUTSA	H	3	D	42422650	I/O feil på B&G node LER1A/B	M2	22028738	POM
1220-87C-JG11	U21	87	IMOAUTSA	M	3	S	42353891	Feil alarmer på B&G pls A i LUR 1	M2	21982923	SOM
1220-87C-JG41	FN1	87	PPMAUT	U	3	U	42445425	Diverse mangler mimikk-panel.	M2	22061045	SOP
1220-87C-JG41	FN1	87	PPMAUT	U	3	U	42461133	Lampetest på brannspjeld-matrise virker	M2		PPM
1220-87C-JG42A	U31	87	IMOAUTSA	M	3	S	42347924	Feilalarm på både NIU A og B i LUR 4.	M2	21977941	SOM
1220-87C-JG58	W07	87	PPMAUT	U	3	U	42461134	Mimikk-panel, borer - Mangler flere lys.	M2	22061042	SOP
1220-87C-JG59	D36	87	PPMAUT	U	3	U	42461136	Div feil, Mimikkpanel_toolpushers office	M2	22061041	SOP
1220-87C-JG80	L32	87	PPMAUT	U	3	U	42461081	Mangler lysdiode i panel	M2	22061043	SOP
1220-87C-JG88	L56	87	PPMAUT	M	3	S	42406363	Feilmelding autrosafe sentral LQE	M2	22001796	SOP
1220-87C-JG88	L56	87	PPMAUT	M	3	S	42426844	Fellesfeil på Autronica sentral LQE	M2	22031566	SOP
1220-87G-JU62	U21	87	POMAUT	H	3	D	42461075	Feil på Vigdis ext. modem /TEM	M2	22060654	POM
1220-87H-JB07	U31	87	IMOAUTSA	H	3	D	42444953	Feil på Ballast PCUer i søyler	M2	22057715	POM
1220-87H-JE02	L52	87	IMOAUTSA	U	3	U	42350803	Ballast OS2 fryser stadig oftere	M2	21981672	SOM
1220-87H-JE05	U31	87	IMOAUTSA	U	3	U	42423075	Feilsøke på SVC-OPC server ballast	M2	22037206	POM
1220-87J-JY60	U31	87	IMOAUTSA	L	1	D	42425943	TTO server henger - må restarter	M2	22031107	POM
1220-87N-XV_008	C43	87	PPMELE	U	3	U	42460970	Alarm åpning/lukking av dør virker ikke	M2	22060489	SOP
1220-90B		90	C01STE	M	A	S	42351054	Syn1202089 defekt rekkverk dropphull W15	M2	21981667	SOP
1220-90B		90	C01STE	L	A	S	42351275	Defekt strukturamme, Utility stasjon U55	M2	21981662	SOP
1220-90B	D53	90	C01STE	L	A	U	42351285	Sparkelist defekt rundt dropphull. D53.	M2	21982726	SOP
1220-90B	F11	90	C01STE	L	A	U	42425707	Løs grating i området F11 mess.Må festes	M2	22031108	PPM
1220-92A-PC71	C13	92	PPMMEC	U	2	U	42411619	Liten olje lekkasje på compressoren	M2	22019282	SOP
1220-92A-PI_535A	C13	92	PPMAUT	U	2	U	42411618	Måler viser feil verdi	M2	22019284	SOP
1220-92A-PZ74	C43	92	PPMMEC	M	2	D	42415874	Lekkasje mellom kompressor og stag	M2	22023623	SOP
1220-99		99	C01STE	L	A	S	42356113	Montere fysisk beskyttelse for manometer	M2	21986145	SOP
1220-99		99	E00SPE	L	A	U	42433522	Defekt risernett sør	M2	22037471	SOP
1220-99		99	E00SPE	L	A	S	42435028	FUNN:Risernett nord defekt inspenningsl.	M2		SPI
1220-99		99	PPMMEC	L	A	S	42356522	Skifte risernett fairleads over vann	M2	21987076	SOP
1220-99A-C10	C10	99	C32SUR	L	A	U	42341010	FUNN: Påvist korrosjon i hovedstruktur	M2	21970367	SSF
1220-99A-C20	C20	99	C32SUR	L	A	U	42341055	FUNN: Påvist korrosjon i hovedstruktur	M2	21970366	SSF
1220-99A-C30	C30	99	C32SUR	L	A	U	42341058	FUNN: Påvist korrosjon i hovedstruktur	M2	21970365	SSF
1220-99A-C40	C40	99	C32SUR	L	A	U	42341059	FUNN: Påvist korrosjon i hovedstruktur	M2	21970364	SSF
1220-C13	C13	00	PPMMEC		A	U	42411613	Mannlokk ned mot søyla mangler handtak	M2		SOP
1220-C32	C32	00	C32SUR	L	A	U	42358733	Korrosjon i pumperom søyle 3	M2	21955829	SSF
1220-C32	C32	00	C32SUR	U	A	U	42362495	Korrosjon i pumperom søyle 3	M2	21990161	SSF
1220-D07	D07	00	PPMELE		A	U	42348796	Oppkobling av Deepwell wireline vinsj	M2		SOP
1220-D07-DG333	D07	87	POMAUT	H	3	D	42426845	Feil på kontainer 3, BJ	M2	22031565	POM
1220-D11	D11	00	C32SCA	L	A	U	42417280	Bygge stillaslager D11	M2	22025763	SSF
1220-D11-DM001A	D11	87	PPMAUT	U	3	U	42466691	Kabel for manuellmelder må stripses	M2	22064986	SOP
1220-D15	D15	00	PPMMEC		A	S	42355570	Korroderte hengsler Sonsub kontainer	M2		SOP
1220-D15-DG001	D15	87	POMAUT	H	3	D	42427455	Detektor ligger med feil.åpen sløyfe	M2	22031950	POM
1220-D15-DG001	D15	87	PPMAUT	M	3	S	42450975	Utestående testing av Gassdetektor på FV	M2	22060496	SOP
1220-D15-DG401	D15	87	POMAUT	H	3	D	42422373	Detektor ligger med feil.(-24)	M2	22028392	POM
1220-D15-DG401	D15	87	POMAUT	H	3	D	42427452	Detektor ligger med feil.(-24)	M2	22031952	POM
1220-D15-DS003J	D15	87	POMAUT	H	3	D	42466756	24M FVG-AUT-F700-FLER5, Defekt detektor	M2	22033671	POM

1220-D15-TC652A	D15	86	PPMAUT	M	3	S	42347294	Kamera bomtupp er feil vinklet	M2	21973116	SOP
1220-D16-CT001	D16	86	IMOTEL	U	1	U	42353087	Sjekk nivå i antenneuttak i D17	M2	21982402	SOM
1220-D16-NP051	D16	86	IMOTEL	D	2	U	42463143	Montere telefonapparat i VKM 2.etg.	M2	22062681	SOM
1220-D25	D25	00	C01STE	L	A	U	42429831	Tilrettelegging for nytt PSV verksted.	M2	22035076	SVM
1220-D25	D25	00	IMOTEL	U	A	U	42462039	Installasjon av PC'er i V&M oppholdsrom	M2	22061735	SOM
1220-D25	D25	00	POMLOG	U	A	U	42368796	Lager telling	M2	21996530	POM
1220-D26	D26	00	C01STE	U	A	U	42409378	Lage brakett for infoTV i kaffebar.	M2	22009462	SVM
1220-D26	D26	00	IMOTEL	L	A	U	42404184	Inst. videokonferanse utstyr i V&M kont.	M2	22001086	SOM
1220-D31	D31	00	PPMMEC	M	A	D	42405623	Dør D31-01 er defekt.	M2	22002310	SOP
1220-D31	D31	00	PPMMEC		A	S	42432754	Dør no D31-01 er revet av hengslene	M2		POM
1220-D31-DS016B	D31	87	PPMAUT	U	3	U	42466760	Detektoren mangler tagskilt	M2	22064982	SOP
1220-D33	D33	00	IMOAUTSA	U	A	U	42417016	Utvidet DCDA-tilgang MCR D33 --->>	M2		SOM
1220-D35	D35	00	C01STE	U	A	U	42420517	Innredning nytt PSV verksted D-35	M2	22026835	SOP
1220-D36-PX001	D36	86	PPMAUT	M	2	D	42444645	Skade på kabel til telefonledning i heis	M2	22058989	SOP
1220-D41	D41	00	C32SUR	L	A	U	42341113	Synergi: Male dørk i pumperom	M2	21968794	SSF
1220-D41-DM003B	D41	87	PPMAUT	U	3	U	42466737	Feil text inne på skjerm	M2	22064991	SOP
1220-D41-DM003R	D41	87	IMOAUTSA	U	3	U	42466740	Feil text inne på skjerm	M2	22064984	SOM
1220-D43	D43	00	C33SUR	U	A	U	42339944	Male markering for mud tanker.	M2	21968860	SSF
1220-D43-DG002	D43	87	PPMAUT	M	3	S	42450976	Dødt display på transmitter	M2	22060492	SOP
1220-D51	D51	00	PPMAUT	L	A	U	42408623	Løs kabelgate D51	M2	22022439	SOP
1220-D53	D53	00	C01STE	L	A	U	42424600	Feste vinkeljern for kjemikalielager D53	M2	22044480	SOP
1220-D53-DM001R	D53	87	IMOAUTSA	U	3	U	42466741	Feil text inne på skjerm	M2	22064983	SOM
1220-D55	D55	00	C32SUR	L	A	U	42355429	D55, Flytte gulstripe 30 cm mot syd	M2	21984054	SSF
1220-EA-AB-82D-EL14-0004-07	P21	82	PPMELE	U	1	S	42364370	Reparere normalt lys armatur P21 (ny)	M2	21996533	SOP
1220-EA-AB-82D-EL14-0004-09	P21	82	PPMELE	U	1	S	42364410	Reparere normalt lys armatur P21 (ny)	M2	21996532	SOP
1220-EA-AB-82D-EL14-0016-07	FS1	82	PPMELE	L	1	D	42360313	Defekt lysarmatur må repareres	M2	21987477	SOP
1220-EA-AB-82D-EL34-0003-22	D25	82	PPMELE	L	1	D	42426053	Lysarmatur defekt i sveiseverksted	M2	22031573	SOP
1220-EA-AD-84D-EL43-0001-05	C12	84	POMELE	H	3	D	42437833	Lys virker ikke, trapp søyle 1	M2	22043909	POM
1220-EA-AD-84D-EL52-0016-11	D35	84	PPMELE	U	3	U	42432810	Reparere mørk nødlysmatør D35	M2	22036591	SOP
1220-EA-AT-82D-EL15-0004-13	D21	82	PPMELE	L	1	D	42363820	Reparere 3 Mørke lysarmaturer i D omr.	M2	21991871	SOP
1220-EA-AU-84D-EL82-0003-01	M50	84	POMELE	H	3	D	42364428	Kursutfall på lys	M2	21996480	POM
1220-EA-AU-84D-EL82-0003-01	M50	84	PPMELE	M	3	S	42424866	Jordfeil på lyskurs liv&stasjon M50	M2	22029885	SOP
1220-EA-CB-84D-EL22-0009-01	W33	84	PPMELE	M	3	S	42370822	Defekt lyskaster W43 Nord	M2	21997097	SOP
1220-EA-CH-82D-EL25-0001-02	P43	82	PPMELE	L	1	D	42354431	Lyskaster er mørk i P43	M2	21983422	SOP
1220-EA-CH-82D-EL26-0004-01	P13	82	PPMELE	L	1	D	42430138	Legger seg ut på sikring	M2	22035060	SOP
1220-EA-CH-82D-EL34-0016-03	D45	82	PPMELE	L	1	D	42435606	Lyskaster er mørk	M2	22042830	SOP
1220-EA-CL-73A-EL03-Q03-01	D15	73	PPMELE	M	3	S	42347292	Feste til lyskaster bøyd	M2	21973117	SOP
1220-EJ-EM-82D-EL15-0006-02	D23	82	PPMELE	L	1	D	42370317	Defekt lyskaster D23	M2	21996519	SOP
1220-FN1-DG002	FN1	87	PPMAUT	M	3	S	42433170	Lav brigd verdi på filament, må skiftes	M2	22037474	SOP
1220-JJE-D15-06	D15	87	PPMAUT	M	3	S	42461986	Innfesting til skap iferd med å løsne.	M2	22061728	SOP
1220-JJE-D55-02	D55		PPMAUT	U	3	U	42344605	Turtall jager på display i kran hytte.	M2	21972308	SOP
1220-JJE-N11-62	N11	87	PPMAUT	M	3	S	42418430	Olje i koblingsboks	M2	22026441	SOP
1220-L00	L00	00	C01MAN	U	A	U	42467478	Aker For best utst Snorre A	M2	22066513	SVM
1220-L20-SZ001A	L20	86	PPMAUT	M	6	D	42436601	Jordfeil PA loop, utkoplet 4 høytalere	M2	22043406	SOP
1220-L21-DG001	L21	87	POMAUT	U	3	U	42413147	Filament må byttes.	M2	22022432	SOP
1220-L21-DG003	L21	87	PPMAUT	U	3	U	42413145	Feil på treveis ventil til gassdetektor	M2	22022433	SOP
1220-L26-DM001C	L26	87	PPMAUT	U	3	U	42412888	Detektorer & man. meld i LQ mangler tag	M2	22022434	SOP
1220-L30	L30	00	PPMMEC	U	A	U	42345851	2011 Stående ordre for PV i boligkvarter	M2	21972549	SOP
1220-L30	L30	00	PPMMEC	U	A	U	42347778	2011 Stående ordre vdl i boligkvarter	M2	21457905	SOP
1220-L31	L31	00	IMOTEL	L	A	U	42404439	Skifte harddisk til graveringsmaskin.	M2	22001085	SOM
1220-L31-PS011	L31	86	PPMAUT	M	2	D	42359830	Død telefon L31-PS011 / 3374	M2	21987445	SOP
1220-L34	L34	00	PPMAUT	L	A	U	42405045	InternetCafe - PC rom L34	M2	22001083	SOP
1220-L37-AU001	L37	86	IMOTEL	U	6	U	42404205	Skifte defekt antenne	M2	21691591	SOM
1220-L37-AU001	L37	86	IMOTEL	U	6	U	42404211	Defekt antenne skiftes	M2	22001079	SOM
1220-L43	L43	00	C01MEC	L	A	U	42465947	Montere gittervegg m/dør på lasterampe.	M2	22065005	SVM
1220-L43	L43	00	IMOTEL	L	A	U	42405215	Ny printer til "kokeknesse" L53	M2	22001082	SOM

1220-L43-NP011A	L43	86	POMAUT	U	2	U	42411297	Etablere telefon i Møterom/Hobbyrom L43	M2	22018991	POM
1220-L44	L44	00	C01STE	L	A	U	42423993	Strukturlyd mot lugarer ved dårlig vær	M2	22031122	PPM
1220-L46-DM007R	L46	87	PPMAUT	U	3	U	42343282	Manuell melder mangler lokk	M2	21970033	SOP
1220-L50	L50	00	E20ISU	U	A	U	42410432	Skifte ut dusjskinner/forheng Synergi	M2	22018178	PRO
1220-L52	L52	00	C01STE	L	A	S	42431379	Lekkasje i vegg ved uvær	M2	22036211	SOP
1220-L53-DH003AM	L53	70	POMAUT	H	3	D	42412887	feil på heat detektor etter test	M2	21691589	POM
1220-L53-DH003AM	L53	70	PPMAUT	M	3	S	42412823	Heat detektor ligger i feil etter test	M2	22022178	SOP
1220-L53-DS003AN	L53	70	PPMAUT	U	3	U	42428868	Flytte detektor pga av feil deteksjon	M2	22035075	SOP
1220-L53-SX008J	L53	86	PPMAUT	U	6	U	42467131	Høytaler har falt ned, henger i ledning	M2	22065566	SOP
1220-L55	L55	00	PPMMEC	L	A	U	42429485	Defekt luftinntak L55	M2	22035077	SOP
1220-M10	M10	00	C01STE	L	A	U	42420237	Brolanding for flotel M10	M2	22026832	SOP
1220-M50	M50	00	C32CLE	L	A	U	42352997	Søyle 2 må spyles ned	M2	21982293	SSF
1220-N41	N41	00	C32SUR	L	A	U	42360265	Korrosjon i pumperom søyle 4	M2	21955829	SSF
1220-OPR			L-OPS		A	U	42407324	Månedsanalyse Snorre og Vigdis	M2	22002397	SOP
1220-P11	P11	00	C32SUR	L	A	U	42358016	Luke sitter fast	M2	21986142	SSF
1220-P17	P17	00			A	S	42436198	Sprekk i gelænder P17 sørside	M2		POM
1220-P18-DG002R	P18	87	PPMAUT	M	3	S	42461682	Uren linse	M2	22060811	SOP
1220-P18-DG003R	P18	87	POMAUT	H	3	D	42408365	Feil på detektor, sjekk B&G skjerm	M2	22004114	POM
1220-P18-DG004R	P18	87	POMAUT	H	3	D	42349867	Detektoren kommer stadig i feil.	M2	21978974	POM
1220-P21-DG111R	P21	87	POMAUT	H	3	D	42410105	Linjegass ligger med feilkode.	M2	22019279	POM
1220-P27-DF001R	P27	87	POMAUT	H	3	D	42349013	Feil på Flammedetektor	M2	21978467	POM
1220-P28-DG003	P28	87	POMAUT	H	3	D	42422372	Detektor ligger med feil. (-18)	M2	22028393	POM
1220-P33-DG007	P33	87	POMAUT	H	3	D	42342331	04M FV-G-AUT-F 700-GLER3 Katalytiske DG	M2	21657243	POM
1220-P33-DG007	P33	87	POMAUT	H	3	D	42342442	Detektor feilet unders FV test	M2	21969215	POM
1220-P43	P43	00	PPMMEC	L	A	U	42463554	Synergi:Skyvedører vanskelige å åpne	M2	22062610	SOP
1220-P43-DG003	P43	87	POMAUT	H	3	D	42433222	P43-DG 003 virker ikke.	M2	21959920	POM
1220-P43-DG003	P43	87	POMAUT	H	3	D	42433229	P43-DG 003 Triggert ikke alarm	M2	22037473	POM
1220-P45-DG038	P45	87	POMAUT	H	3	D	42408366	Sløyfe feil, sjekk B&G skjerm	M2	22004111	POM
1220-P47-DG012R	P47	87	POMAUT	H	3	D	42356871	Linjegass detektor ligger feil(åpen sløy	M2	21985064	POM
1220-PS-16A-0031		23	C01PIP	L	Z	U	42444131	Merke fjærstøtter i feil	M2	22061051	SOP
1220-R38	R38	00	POMPRO	L	A	S	42348466	P-38 CT Pull EVO mm, ref act. ID 09040	M2	21978542	SOP
1220-R42	R42	00	POMPRO	L	A	S	42402818	P-42A Mill LUB Valve&PLT logg. Ref 09160	M2	21997875	SOP
1220-SJZ-P45-03	P45	87	PPMAUT	U	3	U	42411479	Montere tag skilt på koblingsboks	M2	22019172	PPM
1220-TJE-D15-02	D55	86	PPMAUT	M	3	S	42362457	Jordfeil på PA loop - Forsterker B22	M2	21991650	SOP
1220-TJE-W13-01	W13	86	PPMAUT	U	6	U	42451004	Funn etter FV, tele W-området	M2	22060490	SOP
1220-TJZ-D55-101	D55	86	POMAUT	H	3	D	42413420	Vindmåler virker ikke - Nordkran	M2	22022174	POM
1220-U00	U00	00			A	U	42469504	Stillas i Maritim sine D-M-U og L Område	M2		SOP
1220-U13-DS001A	U13	87	PPMAUT	M	3	S	42352870	Falsk alarm på detektor!	M2	21982286	SOP
1220-U15	U15	00	C01STE	U	A	U	42468030	Skadet rekkverk U15	M2	22066144	SOP
1220-U15	U15	00	PPMMEC	U	A	U	42342332	RS1 11-kontainer på U-dekk.	M2	21969407	SOP
1220-U21	U21	00	PPMAUT		A	U	42424915	Tredemølle no 2 Snart havari!!	M2		SOP
1220-U31-AX003A	U31	86	POMAUT	U	1	U	42432583	Løst veggfeste på TV.	M2	22037052	POM
1220-U33-NP027A	U33	86	PPMAUT	U	2	U	42436009	PC 387052 trenger ny PSU eller CPU vifte	M2	22043414	SOP
1220-U36	U36	00	C32SUR	M	A	U	42461677	Feste antisklibelegg i trapp U-36 - D-07	M2	22061047	SSF
1220-U41-DG003	U41	87	PPMAUT	M	3	S	42359641	Skifte filament i gassdetektor.	M2	21986758	SOP
1220-U45-DG004	U45	87	POMAUT	H	3	D	42427351	Detektor ligger med feil. (-7)	M2	22031954	POM
1220-U45-DG017	U45	87	POMAUT	M	3	S	42362763	Bytte filament i gassdetektor.	M2	21990170	POM
1220-U45-DG017	U45	87	POMAUT	H	3	D	42359637	Detektor når ikke HØY-alarm ved test	M2	21986753	POM
1220-U45-DG020	U45	87	POMAUT	M	3	S	42362700	Bytte filament i gassdetektor.	M2	21990169	POM
1220-U45-DG020	U45	87	POMAUT	H	3	D	42359640	Gassdetektor ga ikke alarm ved test	M2	21986752	POM
1220-U45-TG011	U45	87	PPMAUT	U	3	U	42466974	Må ha nytt tagskilt - helt ødelagt	M2	22064981	SOP
1220-U51-DG004	U51	70	POMAUT	H	3	D	42363008	Gassdetek ligger med feil. (-4,8)	M2	21991799	POM
1220-U51-DG004	U51	70	POMAUT	H	3	D	42408363	Åpen sløyfe, sjekk B&G skjerm	M2	22004105	POM
1220-U51-DG004	U51	70	POMAUT	H	3	D	42422345	Detektor ligger med feil. (-4,8)	M2	22028396	POM
1220-W06-DG006	W06	87	PPMAUT	M	3	S	42353393	Displayet på transmitter er dødt.	M2	21982298	SOP
1220-W07	W07	00	C01STE	L	A	S	42351883	Rep. bøyed rekkverk	M2	21981660	SOP

1220-W07	W07	00	C01STE	M	A	S	42351884	Rep. port i V-dør boredekk	M2	21981498	SOP
1220-W07	W07	00	C01STE	M	A	S	42432655	Vannlekasje i tak i LUR 6	M2	22036593	SVM
1220-W07	W07	00	C32ISU	U	A	U	42421436	Lekk vindu W-07. Synergi 1204743	M2	22027886	PPM
1220-W07	W07	00	C32SUR	U	A	U	42345416	Maling av 2 stk elektromotorer	M2	21972599	SSF
1220-W07	W07	00	IMOTEL	L	A	U	42404172	Kjøpe inn og installere printer.	M2	22001090	SOM
1220-W07	W07	00	IMOTEL	M	A	D	42430091	Monitor W07-TM002, monitor #7 er død.	M2	22035062	SOM
1220-W07	W07	00	IMOTEL	L	A	S	42434245	Dårlig UHF forbindelse i loggerom W07	M2	22042947	SOM
1220-W07	W07	00	PPMMEC	L	A	S	42435680	Feste til pulverapp. er ødelagt	M2	22042943	SOP
1220-W07	W07	00	PPMMEC	L	A	S	42435681	Skyvedør W07-04 ut fra shaker er skadet	M2	22042942	SOP
1220-W07-DG050	W07	87	POMAUT	H	3	D	42353399	Gassdetektor var død ved test.	M2	21982284	POM
1220-W07-DG063	W07	87	PPMAUT	M	3	S	42353396	Display på Gass detektor er dødt	M2	21982297	SOP
1220-W07-DM005R	W07	87	PPMAUT	U	3	U	42435370	Brannmelder W07-DM-005R mangler lokk	M2	22042838	SOP
1220-W07-PX010	W07	86	PPMAUT	L	2	S	42410557	Defekt telefon BoP dekk sør.	M2	22021585	SOP
1220-W07-PX011	W07	86	PPMAUT	U	2	U	42356984	Defekt telefon, POB dekk sør	M2	21986159	SOP
1220-W08-TC002	W08	86	IMOTEL	M	3	S	42409534	Dårlig bilde fra kamera i boreårn.	M2	22019280	SOM
1220-W21	W21	00	C01STE		A	S	42421810	Flytte innfesting prod-riser nett ----->	M2		SOP
1220-W21-DF003	W21	87	PPMAUT	M	3	S	42404673	Flammetektor ligger med feil. -25	M2	22000990	SOP
1220-W21-DG003R	W21	87	POMAUT	H	3	D	42422291	Detektor har uren linse	M2	22028400	POM
1220-W23-DF011	W23	87	POMAUT	H	3	D	42350549	Flammetektor ligger med feil	M2	21979804	POM
1220-W31-DG004R	W31	87	PPMAUT	M	3	S	42404561	Ligger i feil, uren linse.	M2	22001826	SOP
1220-W35	W35	00	C32SUR	L	A	U	42401969	Markere rødsone W-35	M2	21998293	SSF
1220-W41-DG003R	W41	87	PPMAUT	M	3	S	42404557	Ligger i feil, uren linse.	M2	22001829	SOP
1220-W41-DG004R	W41	87	POMAUT	H	3	D	42422342	Detektor har uren linse	M2	22028398	POM
1220-W41-DG004R	W41	87	PPMAUT	M	3	S	42404558	Ligger i feil, uren linse.	M2	22001828	SOP
1220-W41-DG004R	W41	87	PPMAUT	M	3	S	42461591	Uren linse	M2	22060812	SOP
1220-W41-DG006R	W41	87	POMAUT	H	3	D	42422343	Detektor har uren linse	M2	22028399	POM
1220-W41-DG006R	W41	87	PPMAUT	M	3	S	42404556	Ligger i feil, uren linse.	M2	22001831	SOP
1220-W41-DG007R	W41	87	POMAUT	H	3	D	42422344	Detektor har uren linse	M2	22028397	POM
1220-W43	W43	00	PPMMEC	M	A	S	42405321	Feil på sikringsnett på P-32 og P-37	M2	22001080	SOP
1220-W43-DG002R	W43	87	POMAUT	H	3	D	42408361	Ligger inne med uren linse.	M2	22004110	POM
1220-W43-DG002R	W43	87	POMAUT	H	3	D	42422349	Detektor har uren linse	M2	22028395	POM
1220-W43-DG002R	W43	87	PPMAUT	M	3	S	42443733	Gasdetektor - Må siktes på nytt.	M2	22058990	SOP
1220-W43-DG003R	W43	87	POMAUT	H	3	D	42422351	Detektor har uren linse	M2	22028394	POM
1220-W43-DG008R	W43	87	PPMAUT	M	3	S	42404560	Ligger i feil, uren linse.	M2	22001827	SOP
1220-W45	W45	00	C32CLE	M	A	S	42421263	Tette drainer må åpnes på W45 --->>	M2	22027887	SSF
1220-W45	W45	00	C32SUR	M	A	S	42423784	Glatt gulstripe, trenger mere sand --->>	M2	22029852	PPM
1220-W45	W45	00	C43ISP	L	A	U	42362922	Halliburton kaks HSB-tanker ---->>	M2	21991881	SIP
1220-W51	W51	00	C01STE	L	A	U	42457472	Reparere rekkverk på lasteområde	M2	22060522	SOP
1220-W53	W53	00	C32CLE	D	A	U	42446164	Nedvasking etter mudsøl.	M2	22062067	POM
1220-W60-PX004	W60	86	PPMAUT	L	2	S	42355751	Telefon virker ikke, må repareres.	M2	21984052	SOP
1220-W60-SZ001A	W60	86	PPMAUT	M	6	S	42437573	Jordfeil PA-Loop - A system	M2	22043910	SOP
1240-19H-ESV 253	J24	19	POMPRO	U	3	U	42355893	Vigdís brønn D-2. PLT logging	M2	21983890	SOP
1240-19H-ESV 980	J22	19	POMPRO	U	3	U	42445497	Pumpe 70 m3 LVP i C-4 og åpne DHSV/M	M2	22060485	SOP

A.2 Oversikt over høykritiske notifikasjoner i perioden 1.januar til 31.mars

Functional loc.	Location	System	Main WorkCtr	Priority	ABC indic.	Failure Impact	Created on	Notification	Description	Notifictn type	Item	Order	Planner group
1220-1 1/2"-WF-71C116-CM1	W41	71	POMMEC	H	3	D	40628	42464877	Delugere er brukt i unionkobling.	M2	0001	22064263	POM
1220-13C-RT33	W43	13	POMMEC	H	3	D	40604	42427197	P33 Tensionsylinder C lekker ut PSV.	M2	0001	22031791	POM
1220-13C-RV39	W43	13	PPMMEC	H	3	D	40587	42411212	Lekkasje i bleedport i HYD.ving huset	M2	0001	22019240	POM
1220-16A-ESV 131	W23	16	POMMEC	H	3	D	40591	42414968	6M FV-G-PRO TEST AV VENTILTRÆR 2.	M2	0001	21689934	POM
1220-16A-ESV 132	W23	16	POMMEC	H	3	D	40591	42414971	6M FV-G-PRO TEST AV VENTILTRÆR 2.	M2	0001	21689934	POM
1220-16A-ESV 241	W33	16	POMMEC	H	3	D	40590	42414661	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	0001	21690000	POM
1220-16A-HV 083	W23	16	POMAUT	H	3	D	40558	42349193	Choke vill ikke gå i fra kontrollrom.	M2	0001	21978466	POM
1220-16A-HV 233	W23	16	POMAUT	H	3	D	40558	42349199	Choke vill ikke gå i fra kontrollrom.	M2	0001	21978594	POM
1220-16A-HV152B	W23	16	POMMEC	H	3	D	40590	42414348	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	0001	21689936	POM
1220-16D-XV 840	P16	16	POMAUT	H	3	D	40561	42354103	3M FV-G-AUT-F IOPS SYSTEM	M2	0001	21681985	POM
1220-17B-ESV 021	W23	17	POMMEC	H	3	D	40594	42417830	6M FV-G-PRO TEST AV VENTILTRÆR 1.	M2	0001	21690011	POM
1220-17B-HV 223	W23	17	POMAUT	H	3	D	40558	42349197	Choke vill ikke gå i fra kontrollrom.	M2	0001	21978595	POM
1220-17C-VW01	P26	17	POMAUT	H	1	D	40625	42462559	Lampe i styrepanel til piggslyse defekt	M2	0001	22052617	POM
1220-17D-FE 320	W43	17	PPMAUTM	H	3	D	40553	42346866	Koble opp Clampon flowmåler P-32 gassinj	M2	0001	21973115	POM
1220-17D-HV 206B	W43	17	POMMEC	H	3	D	40554	42347560	Pakkbokselekkasje på gass inj P20	M2	0001	21977387	POM
1220-17D-HV 326A	W43	17	POMMEC	H	3	D	40573	42363903	P-32 Lekkasje i bleedventiler.	M2	0001	21991862	POM
1220-20A-ESV 024	P35	20	POMMEC	H	3	D	40620	42443816	Ventilen stenger ikke (ca 60%)	M2	0001	22059914	POM
1220-20A-LT 020	FS1	20	POMAUT	H	2	S	40581	42405864	Sjekk av nivåtransmittere på testsep	M2	0001	22001339	POM
1220-20C-LV 015B	P43	20	PPMMEC	H	3	D	40577	42403071	Vannventil 2. trinn Snorre står fast	M2	0001	21998151	POM
1220-20C-PSV 850	P25	20	POMMEC	H	3	D	40588	42412271	Resertifisere PSV på X-over Olje	M2	0001	22019722	POM
1220-21A-PA61B	P17	21	POMMEC	H	3	D	40587	42411060	Vigdís olje export_mistat tettningsvæsk	M2	0001	22018150	POM
1220-23A-KA01	P45	23	POMMEC	H	3	D	40596	42420371	Repp av rørbrudd smørelje og Rengjøring	M2	0001	22026741	POM
1220-23B-FCV 049	P45	23	PPMAUT	H	6	S	40568	42360176	Miniflowen lager trykkstøt ut av pumpa.	M2	0001	21989743	POM
1220-4"GAK2-026	W23	16	PPMMEC	H	2	S	40578	42403597	Lekkasje i pakkboks, smørenippel	M2	0001	21998401	SOP
1220-44C-FT 041	P31	44	POMAUT	H	3	D	40563	42355425	Måler viser ikke flow	M2	0001	21983419	POM
1220-44D-LG 009	P45	44	POMAUT	H	7	D	40579	42404341	Lekk pakkboks på 12mm kuleventil seglass	M2	0001	21999048	POM
1220-51D-PV 003	W13	51	POMAUT	H	3	D	40585	42409393	Stor intern lekkasje i ventil	M2	0001		POM
1220-51D-TT 675	D21	51	POMAUT	H	3	D	40573	42363549	Instrument feil	M2	0001	21991865	POM
1220-51D-YAHH 521A	D21	51	POMAUT	H	3	D	40598	42422378	Vibrasjon kommer inn og tripper pumpen	M2	0001	22028391	POM
1220-52A-HV 007	C14	52	POMAUT	H	3	D	40575	42401640	Ventil åpner ikke.	M2	0001	21997106	POM
1220-52A-HV 047	C14	52	POMAUT	H	3	D	40575	42401641	Ventil åpner ikke.	M2	0001	21997082	POM
1220-52A-HV 452	T31	52	POMAUT	H	3	D	40575	42401639	Ventil åpner ikke.	M2	0001	21997083	POM
1220-52A-LT 023	C12	52	POMAUT	H	3	D	40613	42434021	Feil på nivåmåling operasjons tank.	M2	0001		POM
1220-58H-PD01A	D23	58	POMMEC	H	3	D	40561	42353255	Membranbrudd. SCAVENGER INJ.PUMP	M2	0001	21982400	PPM
1220-70D-FS 708	L31	70	POMAUT	H	2	D	40589	42413150	Kule står fast i flowmeter	M2	0001	22022177	POM
1220-71A-CT01C	M10	71	POMMEC	H	3	D	40598	42422388	Dieselmotor på brannpumpe C starter ikke	M2	0001	22028390	POM
1220-71A-XY 632	M10	71	POMAUT	H	3	D	40548	42343073	Solenoid åpner ikke for nødstart	M2	0001	21969605	POM
1220-71F-TI 001	U13	71	POMAUT	H	3	D	40601	42424117	Ti viser feil temperatur	M2	0001	22029874	POM
1220-73A-EC51	D55	73	POMAUT	H	3	D	40544	42339973	Feil med bomfunksjon nordkran	M2	0001	21965975	POM
1220-73A-GK01A	D15	73	POMMEC	H	3	D	40568	42359441	Motor til kjølevifte hydraulikk er def.	M2	0001	21987091	POM
1220-74A-CX09	D35	74	POMMEC	H	3	D	40598	42422300	Dør ut fra tungt lager ut av drift	M2	0001	22028410	POM
1220-76A-MF01C	M30	76	POMMEC	H	3	D	40602	42424923	Hydr styring sviktet på LB 3	M2	0001		POM
1220-77A-EC03	L53	77	POMELE	H	3	D	40602	42424863	Jordfeil på UV systemet	M2	0001	22029886	POM
1220-77B-XY 030	U23	77	POMAUT	H	3	D	40575	42401591	Brannspjeld lukker ikke	M2	0001	21997088	POM
1220-77B-XY 030	U23	77	POMELE	H	3	D	40575	42401578	Brannspjeld lukker ikke	M2	0001	21714060	POM
1220-77B-XY 049	U23	77	POMELE	H	3	D	40575	42401581	Brannspjeld lukker ikke	M2	0001	21714060	POM
1220-77B-XY 214	U43	77	POMAUT	H	3	D	40575	42401554	KV tilbakemeldingsfeil brannspjeld	M2	0001	21714060	POM
1220-77B-XY 295	U23	77	PPMELE	H	3	D	40575	42401584	Brannspjeld lukker ikke ved 1. forsøk	M2	0001	21714060	POM
1220-77C-PDSL 101A	W07	77	POMAUT	H	3	D	40564	42356773	12M FV-G-AUT-F HVAC STRØMNINGSVAKTER	M2	0001	21670102	POM
1220-77C-PDSL 101A	W07	77	POMAUT	H	3	D	40566	42358387	Bryteren ga ikke alarm i kontrolrom	M2	0001	21986058	POM
1220-77C-XY 076	W07	77	POMAUT	H	3	D	40578	42404217	Brannspjeld feiler å lukke på 1. forsøk	M2	0001	21714059	POM
1220-77C-XY 109	W07	77	POMAUT	H	3	D	40578	42404215	Brannspjeld feiler å lukke.	M2	0001	21714059	POM
1220-77C-XY 109	W07	77	POMAUT	H	3	D	40578	42404221	Brannspjeld feiler å lukke.	M2	0001	21999039	POM
1220-8"CKH5-056	W43	16	POMMEC	H	3	D	40633	42469161	Defekt Chekventil P-44 mot test	M2	0001	22066217	POM
1220-8"-PL-21A801-CC3	P16	21	PPMISP	H	3	D	40588	42412574	FUNN: På linje 8"-PL-21A801-CC3 i P16	M2	0001	22021750	SOP

1220-86A-JR02B	L25	86	IMOTEL	H	3	D	40625	42462099	Radioswitch har stoppet opp	M2	0001	22061726	POM
1220-86A-JR02C	L25	86	IMOTEL	H	3	D	40570	42361445	Com4500, defekt power	M2	0001	21988728	SOM
1220-86A-JR05B	D15	86	IMOTEL	H	3	D	40604	42427414	Defekt VHF radio	M2	0001	22031953	POM
1220-86A-JR05B	D15	86	IMOTEL	H	3	D	40609	42431181	Defekt VHF radio	M2	0001	22035862	SOM
1220-87B-JE24A	U31	87	POMAUT	H	3	D	40622	42444956	Feil på WinCC servere A-servere	M2	0001	22058859	POM
1220-87B-M126	D21	87	IMOAUTSA	H	3	D	40582	42406823	Feilsøke tripp av vanninjeksjon -utkall	M2	0001	22001917	POM
1220-87B-S031		87	IMOAUTSA	H	3	D	40580	42405299	PAS system ute av funksjon - link feil	M2	0001	21999114	POM
1220-87C-JG11	U21	87	IMOAUTSA	H	3	D	40599	42422650	I/O feil på B&G node LER1A/B	M2	0001	22028738	POM
1220-87G-JU62	U21	87	POMAUT	H	3	D	40624	42461075	Feil på Vigdis ext. modem /TEM	M2	0001	22060654	POM
1220-87H-JB07	U31	87	IMOAUTSA	H	3	D	40622	42444953	Feil på Ballast PCUer i søyler	M2	0001	22057715	POM
1220-D07-DG333	D07	87	POMAUT	H	3	D	40604	42426845	Feil på kontainer 3, BJ	M2	0001	22031565	POM
1220-D15-DG001	D15	87	POMAUT	H	3	D	40604	42427455	Detektor ligger med feil.åpen sløyfe	M2	0001	22031950	POM
1220-D15-DG401	D15	87	POMAUT	H	3	D	40598	42422373	Detektor ligger med feil.(-24)	M2	0001	22028392	POM
1220-D15-DG401	D15	87	POMAUT	H	3	D	40604	42427452	Detektor ligger med feil.(-24)	M2	0001	22031952	POM
1220-D15-DS003J	D15	87	POMAUT	H	3	D	40630	42466756	24M FVG-AUT-F700-FLER5, Defekt detektor	M2	0001	22033671	POM
1220-EA-AD-84D-EL43-0001-05	C12	84	POMELE	H	3	D	40618	42437833	Lys virker ikke. trapp søyle 1	M2	0001	22043909	POM
1220-EA-AU-84D-EL82-0003-01	M50	84	POMELE	H	3	D	40574	42364428	Kursuffall på lys	M2	0001	21996480	POM
1220-L53-DH003AM	L53	70	POMAUT	H	3	D	40589	42412887	feil på heat detektor etter test	M2	0001	21691589	POM
1220-P18-DG003R	P18	87	POMAUT	H	3	D	40584	42408365	Feil på detektor, sjekk B&G skjerm	M2	0001	22004114	POM
1220-P18-DG004R	P18	87	POMAUT	H	3	D	40556	42349867	Detektoren kommer stadig i feil.	M2	0001	21978974	POM
1220-P21-DG111R	P21	87	POMAUT	H	3	D	40585	42410105	Linjegass ligger med feilkode.	M2	0001	22019279	POM
1220-P27-DF001R	P27	87	POMAUT	H	3	D	40555	42349013	Feil på Flammedetektor	M2	0001	21978467	POM
1220-P28-DG003	P28	87	POMAUT	H	3	D	40598	42422372	Detektor ligger med feil.(-18)	M2	0001	22028393	POM
1220-P33-DG007	P33	87	POMAUT	H	3	D	40547	42342331	04M FV-G-AUT-F 700-GLER3 Katalytiske DG	M2	0001	21657243	POM
1220-P33-DG007	P33	87	POMAUT	H	3	D	40547	42342442	Detektor feilet unders FV test	M2	0001	21969215	POM
1220-P43-DG003	P43	87	POMAUT	H	3	D	40612	42433222	P43-DG 003 virker ikke.	M2	0001	21959920	POM
1220-P43-DG003	P43	87	POMAUT	H	3	D	40612	42433229	P43-DG 003 Trigget ikke alarm	M2	0001	22037473	POM
1220-P45-DG038	P45	87	POMAUT	H	3	D	40584	42408366	Sløyfe feil, sjekk B&G skjerm	M2	0001	22004111	POM
1220-P47-DG012R	P47	87	POMAUT	H	3	D	40565	42356871	Linjegass detektor ligger feil(åpen sløy	M2	0001	21985064	POM
1220-TJZ-D55-101	D55	86	POMAUT	H	3	D	40589	42413420	Vindmåler virker ikke - Nordkran	M2	0001	22022174	POM
1220-U45-DG004	U45	87	POMAUT	H	3	D	40604	42427351	Detektor ligger med feil.(-7)	M2	0001	22031954	POM
1220-U45-DG017	U45	87	POMAUT	H	3	D	40568	42359637	Detektor når ikke HØY-alarm ved test	M2	0001	21986753	POM
1220-U45-DG020	U45	87	POMAUT	H	3	D	40568	42359640	Gassdetektor ga ikke alarm ved test	M2	0001	21986752	POM
1220-U51-DG004	U51	70	POMAUT	H	3	D	40572	42363008	Gassdetek ligger med feil. (-4,8)	M2	0001	21991799	POM
1220-U51-DG004	U51	70	POMAUT	H	3	D	40584	42408363	Åpen sløyfe, sjekk B&G skjerm	M2	0001	22004105	POM
1220-U51-DG004	U51	70	POMAUT	H	3	D	40598	42422345	Detektor ligger med feil.(-4,8)	M2	0001	22028396	POM
1220-W07-DG050	W07	87	POMAUT	H	3	D	40561	42353399	Gassdetektor var død ved test.	M2	0001	21982284	POM
1220-W21-DG003R	W21	87	POMAUT	H	3	D	40598	42422291	Detektor har uren linse	M2	0001	22028400	POM
1220-W23-DF011	W23	87	POMAUT	H	3	D	40557	42350549	Flammedetektor ligger med feil	M2	0001	21979804	POM
1220-W41-DG004R	W41	87	POMAUT	H	3	D	40598	42422342	Detektor har uren linse	M2	0001	22028398	POM
1220-W41-DG006R	W41	87	POMAUT	H	3	D	40598	42422343	Detektor har uren linse	M2	0001	22028399	POM
1220-W41-DG007R	W41	87	POMAUT	H	3	D	40598	42422344	Detektor har uren linse	M2	0001	22028397	POM
1220-W43-DG002R	W43	87	POMAUT	H	3	D	40584	42408361	Ligger inne med uren linse.	M2	0001	22004110	POM
1220-W43-DG002R	W43	87	POMAUT	H	3	D	40598	42422349	Detektor har uren linse	M2	0001	22028395	POM
1220-W43-DG003R	W43	87	POMAUT	H	3	D	40598	42422351	Detektor har uren linse	M2	0001	22028394	POM

A.3 Notifikasjoner - System

A.31 Notifikasjoner/høykritiske notifikasjoner - System

System	Antall	Prosent
13	72	7
16	49	5
17	45	5
20	35	4
21	41	4
23	19	2
44	17	2
51	27	3
52	14	1
58	10	1
70	12	1
71	40	4
73	43	4
74	22	2
76	12	1
77	44	4
84	10	1
86	57	6
87	97	10
Andre system	327	33
Totalt	993	100

System	Antall	Prosent
13	2	2
16	9	9
17	6	6
20	4	4
21	2	2
23	2	2
44	2	2
51	3	3
52	4	4
58	1	1
70	5	5
71	4	4
73	2	2
74	1	1
76	1	1
77	11	11
84	2	2
86	5	5
87	34	34
Totalt	100	100

System	Antall Tag	Tag, krit 3	Prosentandel krit 3
13	1568	734	46,81
16	7294	2247	30,81
17	5746	2374	41,32
20	2839	763	26,88
21	1737	242	13,93
23	1483	308	20,77
44	3576	811	22,68
51	2464	866	35,15
52	1689	452	26,76
58	589	90	15,28
70	606	348	57,43
71	5246	3207	61,13
73	2876	505	17,56
74	518	289	55,79
76	400	298	74,50
77	6369	998	15,67
84	3434	2966	86,37
86	5769	1736	30,09
87	8675	4939	56,93
Andre System	54950	10016	18,23
Totalt	117828	34189	29,02

Andre system = System som ikke er presentert med høykritiske notifikasjoner, samt system som er blanke. Det samme gjelder Andre Lokasjoner, Andre Arbeidssenter og Andre Planleggingsgruppe.

A.32 Notifikasjoner/høykritiske notifikasjoner - System, statistikk

System	Totalt	Krit 3	% Høykritiske	μ notifikasjoner	μ Høykritiske	Differanse notifikasjoner	Differanse Høykritiske	% Differanse notifikasjoner	% Diff Høykritiske
13	72,00	2,00	2,78	13,21	2,15	-58,79	0,15	-444,86	6,84
16	49,00	9,00	18,37	61,47	6,57	12,47	-2,43	20,29	-36,94
17	45,00	6,00	13,33	48,42	6,94	3,42	0,94	7,07	13,59
20	35,00	4,00	11,43	23,93	2,23	-11,07	-1,77	-46,29	-79,23
21	41,00	2,00	4,88	14,64	0,71	-26,36	-1,29	-180,08	-182,55
23	19,00	2,00	10,53	12,50	0,90	-6,50	-1,10	-52,02	-122,01
44	17,00	2,00	11,76	30,14	2,37	13,14	0,37	43,59	15,69
51	27,00	3,00	11,11	20,77	2,53	-6,23	-0,47	-30,02	-18,44
52	14,00	4,00	28,57	14,23	1,32	0,23	-2,68	1,64	-202,56
58	10,00	1,00	10,00	4,96	0,26	-5,04	-0,74	-101,46	-279,88
70	12,00	5,00	41,67	5,11	1,02	-6,89	-3,98	-134,97	-391,22
71	40,00	4,00	10,00	44,21	9,38	4,21	5,38	9,52	57,36
73	43,00	2,00	4,65	24,24	1,48	-18,76	-0,52	-77,41	-35,40
74	22,00	1,00	4,55	4,37	0,85	-17,63	-0,15	-403,96	-18,30
76	12,00	1,00	8,33	3,37	0,87	-8,63	-0,13	-255,98	-14,73
77	44,00	11,00	25,00	53,67	2,92	9,67	-8,08	18,03	-276,83
84	10,00	2,00	20,00	28,94	8,68	18,94	6,68	65,45	76,95
86	57,00	5,00	8,77	48,62	5,08	-8,38	0,08	-17,24	1,53
87	97,00	34,00	35,05	73,11	14,45	-23,89	-19,55	-32,68	-135,36
Andre syster	327,00	0,00	0,00	463,09	29,30	136,09	29,30	29,39	100,00

A.33 Oversikt over Systemer - Beskrivelse

00 GENERAL	61 HELICOP. FUEL
10 DRILLING	62 DIESEL
11 DRILLING PROC.	63 COMPRESSED AIR
12 DRILLING WELL	64 INERT GAS
13 RISER & WELL	65 HYDRAUL. POWER
14 RISER OPER.	66 SEWAGE
16 WELL REL PROD	67 MARINE OPER.
17 GAS&WATER INJ	68 GLYCOL ST&DIST
18 SUBSEA PRODUCT	70 FIRE&GAS DETEC
19 SUBSEA PROD.	71 FIRE WATER
20 SEPARATION	72 MISC FIRE FGHT
21 CRUDE EXPORT	73 MATERIAL HAND.
23 GAS RECOMPR.	74 ACCOMADATION
24 GAS DEHYDRAT.	75 PASS.FIRE PROT
25 GAS CONDITION.	76 ESCAPE & PERS.
26 GAS REINJECT.	77 HVAC
27 GAS EXPORT	78 WORKSHOP&STOR.
28 GAS SWEETENING	79 SHUT DOWN
30 CRUDE OIL PIPE	80 MAINPWR > 11KV
31 DENSE GAS PIPE	82 MAINPWR < 690V
40 COOLING	83 ESSENTI < 690V
41 HEATING	84 EMERPWR < 690V
42 CHEMICAL INJEC	85 BATTERY & UPS
43 FLARE/VENT/BLD	86 TELECOM
44 OILY WATER TR.	87 INSTRUMENT
45 FUEL GAS	88 EARTHING
50 SEAWATER	89 RES INST/TELE
51 SEAWAT HI PRES	90 STRUCTURE DECK
52 BALLAST WATER	91 CONCRETE FOUND
53 FRESH WATER	92 TETHER
54 HOT WATER	96 STRUC., SUBSEA
55 STEAM&CONDENS.	97 AUX STRUCTURE
56 OPEN DRAIN	98 PROTECTION
57 CLOSED DRAIN	99 STRUC ST FLOAT
58 CHEM INJ.NON-H	
59 EXHAUST CLEAN	
60 DRY BULK LOAD	

A.4 Notifikasjoner - Lokasjon

A.41 Notifikasjoner/høykritiske notifikasjoner - Lokasjon

Lokasjon	Antall	Prosent
W23	86	8,66
P16	24	2,42
W33	23	2,32
P26	4	0,40
FS1	5	0,50
P25	3	0,30
P35	16	1,61
P43	20	2,01
P17	15	1,51
P45	42	4,23
P31	17	1,71
D21	23	2,32
W13	4	0,40
T31	4	0,40
C14	4	0,40
C12	3	0,30
D23	7	0,70
U51	5	0,50
L53	11	1,11
L31	3	0,30
M10	11	1,11
U13	3	0,30
W41	9	0,91
D55	24	2,42
D15	28	2,82
D35	7	0,70
M30	5	0,50
W07	30	3,02
U43	11	1,11
U23	8	0,81
M50	14	1,41
L25	19	1,91
Ukjent	51	5,14
U21	5	0,50
U31	17	1,71
P33	16	1,61
P27	1	0,10
P18	4	0,40
P47	1	0,10
U45	7	0,70
P21	17	1,71
W21	4	0,40
P28	2	0,20
D07	3	0,30
W43	54	5,44
Andre lokasjoner	323	32,53
Totalt	993	100,00

Lokasjon	Antall	Prosent
W23	9	9
P16	2	2
W33	1	1
P26	1	1
FS1	1	1
P25	1	1
P35	1	1
P43	3	3
P17	1	1
P45	4	4
P31	1	1
D21	3	3
W13	1	1
T31	1	1
C14	2	2
C12	2	2
D23	1	1
U51	3	3
L53	2	2
L31	1	1
M10	2	2
U13	1	1
W41	4	4
D55	2	2
D15	7	7
D35	1	1
M30	1	1
W07	6	6
U43	1	1
U23	4	4
M50	1	1
L25	2	2
Ukjent	1	1
U21	2	2
U31	2	2
P33	2	2
P27	1	1
P18	2	2
P47	1	1
U45	3	3
P21	1	1
W21	1	1
P28	1	1
D07	1	1
W43	9	9
Andre lokas	0	0
Totalt	100	100

Lokasjon	Antall tag	Tag, krit 3	Prosentandel krit 3
Andre lokasjoner	65481	14462	22,09
C12	114	24	21,05
C14	553	130	23,51
D07	529	190	35,92
D15	987	476	48,23
D21	2761	742	26,87
D23	379	113	29,82
D35	431	120	27,84
D55	932	446	47,85
FS1	1884	279	14,81
L25	687	303	44,10
L31	382	112	29,32
L53	572	213	37,24
M10	696	276	39,66
M30	101	71	70,30
M50	824	338	41,02
P16	2082	917	44,04
P17	2819	1018	36,11
P18	701	344	49,07
P21	996	330	33,13
P25	627	251	40,03
P26	666	200	30,03
P27	113	38	33,63
P28	159	39	24,53
P31	1698	483	28,45
P33	1015	346	34,09
P35	1646	580	35,24
P43	2130	648	30,42
P45	2127	946	44,48
P47	166	103	62,05
T31	105	56	53,33
U13	689	269	39,04
U21	852	187	21,95
U23	565	163	28,85
U31	1144	633	55,33
U43	1402	182	12,98
U45	234	101	43,16
U51	630	133	21,11
W07	3911	1264	32,32
W13	193	86	44,56
W21	739	166	22,46
W23	4430	1900	42,89
W33	4151	1318	31,75
W41	631	143	22,66
W43	3894	1729	44,40
Ukjent	9242	1321	14,29
Totalt	52347	19727	37,69

A.42 Notifikasjoner/høykritiske notifikasjoner - Lokasjon, statistikk

Lokasjon	Generelt	High	Andel høykritiske %	μ notifikasjoner	μ Høykritiske	Differanse notifikasjoner	Differanse Høykritisk	% Differanse notifikasjoner	% Diff Høykritisk
Andre lokasjoner	323	0	22,09	551,87	42,30	228,87	42,30	41,47	100,00
C12	3	2	21,05	0,96	0,07	-2,04	-1,93	-212,24	-2749,00
C14	4	2	23,51	4,66	0,38	0,66	-1,62	14,18	-425,97
D07	3	1	35,92	4,46	0,56	1,46	-0,44	32,71	-79,94
D15	28	7	48,23	8,32	1,39	-19,68	-5,61	-236,60	-402,77
D21	23	3	26,87	23,27	2,17	0,27	-0,83	1,16	-38,23
D23	7	1	29,82	3,19	0,33	-3,81	-0,67	-119,15	-202,55
D35	7	1	27,84	3,63	0,35	-3,37	-0,65	-92,71	-184,90
D55	24	2	47,85	7,85	1,30	-16,15	-0,70	-205,54	-53,31
FS1	5	1	14,81	15,88	0,82	10,88	-0,18	68,51	-22,54
L25	19	2	44,10	5,79	0,89	-13,21	-1,11	-228,15	-125,66
L31	3	1	29,32	3,22	0,33	0,22	-0,67	6,82	-205,25
L53	11	2	37,24	4,82	0,62	-6,18	-1,38	-128,18	-221,01
M10	11	2	39,66	5,87	0,81	-5,13	-1,19	-87,52	-147,74
M30	5	1	70,30	0,85	0,21	-4,15	-0,79	-487,39	-381,52
M50	14	1	41,02	6,94	0,99	-7,06	-0,01	-101,59	-1,15
P16	24	2	44,04	17,55	2,68	-6,45	0,68	-36,77	25,44
P17	15	1	36,11	23,76	2,98	8,76	1,98	36,86	66,42
P18	4	2	49,07	5,91	1,01	1,91	-0,99	32,30	-98,77
P21	17	1	33,13	8,39	0,97	-8,61	-0,03	-102,52	-3,60
P25	3	1	40,03	5,28	0,73	2,28	-0,27	43,23	-36,21
P26	4	1	30,03	5,61	0,59	1,61	-0,42	28,74	-70,94
P27	1	1	33,63	0,95	0,11	-0,05	-0,89	-5,00	-799,69
P28	2	1	24,53	1,34	0,11	-0,66	-0,89	-49,25	-776,62
P31	17	1	28,45	14,31	1,41	-2,69	0,41	-18,79	29,22
P33	16	2	34,09	8,55	1,01	-7,45	-0,99	-87,04	-97,62
P35	16	1	35,24	13,87	1,70	-2,13	0,70	-15,34	41,06
P43	20	3	30,42	17,95	1,90	-2,05	-1,10	-11,41	-58,28
P45	42	4	44,48	17,93	2,77	-24,07	-1,23	-134,29	-44,56
P47	1	1	62,05	1,40	0,30	0,40	-0,70	28,52	-231,92
T31	4	1	53,33	0,88	0,16	-3,12	-0,84	-352,01	-510,50
U13	3	1	39,04	5,81	0,79	2,81	-0,21	48,34	-27,09
U21	5	2	21,95	7,18	0,55	2,18	-1,45	30,37	-265,65
U23	8	4	28,85	4,76	0,48	-3,24	-3,52	-68,00	-738,97
U31	17	2	55,33	9,64	1,85	-7,36	-0,15	-76,32	-8,02
U43	11	1	12,98	11,82	0,53	0,82	-0,47	6,91	-87,85
U45	7	3	43,16	1,97	0,30	-5,03	-2,70	-254,94	-915,49
U51	5	3	21,11	5,31	0,39	0,31	-2,61	5,83	-671,16
W07	30	6	32,32	32,96	3,70	2,96	-2,30	8,99	-62,28
W13	4	1	44,56	1,63	0,25	-2,37	-0,75	-145,91	-297,54
W21	4	1	22,46	6,23	0,49	2,23	-0,51	36,78	-105,95
W23	86	9	42,89	37,34	5,56	-48,66	-3,44	-130,34	-61,94
W33	23	1	31,75	34,98	3,86	11,98	2,86	34,26	74,06
W41	9	4	22,66	5,32	0,42	-3,68	-3,58	-69,23	-856,31
W43	54	9	44,40	32,82	5,06	-21,18	-3,94	-64,54	-77,96
Ukjent	51	1	14,29	77,89	3,86	26,89	2,86	34,52	74,12

A.43 Oversikt over Lokasjoner - Beskrivelse

Location	Name				
A00	General Deck, General, General	A31	General Deck, Interm, Cellar Deck	C02	Column, General
A01	General Deck, General, Cellar Deck	A32	General Deck, Interm, Cellar Mezzanine	C03	Column, General
A02	General Deck, General, Cellar Mezzanine	A33	General Deck, Interm, Intermediate	C04	Column, General
A03	General Deck, General, Intermediat	A34	General Deck, Interm, Intermediate	C10	Column no.1 South/West - General
A04	General Deck, General, Intermediat	A35	General Deck, Interm, Upper Deck	C11	Column no.1 South/West
A05	General Deck, General, Upper Deck	A36	General Deck, Interm, Upper Mezzanine	C12	Column no.1 South/West - Lower P
A06	General Deck, General, Upper Mezzanine	A37	General Deck, Interm	C13	Column no.1 South/West - Medium
A07	General Deck, General	A38	General Deck, Interm	C14	Column no.1 South/West - Upper P
A08	General Deck, General	A39	General Deck, Interm	C15	Juksekolonne
A09	General Deck, General	A40	General Deck, Interm/North, General	C16	Innlagt kolonne
A10	General Deck, South, General	A41	General Deck, Interm/North, Cellar	C20	Column no.2 North/West - General
A11	General Deck, South, Cellar Deck	A42	General Deck, Interm/North, Cellar	C21	Column no.2 North/West
A12	General Deck, South, Cellar Mezzanine	A43	General Deck, Interm/North, Intermediate	C22	Column no.2 North/West - Lower P
A13	General Deck, South, Intermediat	A44	General Deck, Interm/North, Intermediate	C23	Column no.2 North/West - Medium
A14	General Deck, South, Intermediat	A45	General Deck, Interm/North, Upper Deck	C24	Column no.2 North/West - Upper P
A15	General Deck, South, Upper Deck	A46	General Deck, Interm/North, Upper Deck	C30	Column no.3 North/East - General
A16	General Deck, South, Upper Mezzanine	A47	General Deck, Interm/North	C31	Column no.3 North/East
A17	General Deck, South	A48	General Deck, Interm/North	C32	Column no.3 North/East - Lower P
A18	General Deck, South	A49	General Deck, Interm/North	C33	Column no.3 North/East - Medium
A19	General Deck, South	A50	General Deck, North, General	C34	Column no.3 North/East - Upper P
A20	General Deck, South/Interm, General	A51	General Deck, North, Cellar Deck	C40	Column no.4 South/East - General
A21	General Deck, South/Interm, Cellar Deck	A52	General Deck, North, Cellar Mezzanine	C41	Column no.4 South/East
A22	General Deck, South/Interm, Cellar Deck	A53	General Deck, North, Intermediate	C42	Column no.4 South/East - Lower P
A23	General Deck, South/Interm, Interm	A54	General Deck, North, Intermediate	C43	Column no.4 South/East - Medium
A24	General Deck, South/Interm, Interm	A55	General Deck, North, Upper Deck	C44	Column no.4 South/East - Upper P
A25	General Deck, South/Interm, Upper Deck	A56	General Deck, North, Upper Mezzanine	D00	Drilling, General, General
A26	General Deck, South/Interm, Upper Deck	A57	General Deck, North	D01	Drilling, General, Cellar Deck
A27	General Deck, South/Interm	A58	General Deck, North	D02	Drilling, General, Cellar Mezzanine
A28	General Deck, South/Interm	A59	General Deck, North	D03	Drilling, General, Intermediate Deck
A29	General Deck, South/Interm	C00	Column, General, General	D04	Drilling, General, Intermediate Mezz.
A30	General Deck, Interm, General	C01	Column, General	D05	Drilling, General, Upper Deck

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

D06	Drilling, General, Upper Mezzanine	D37	Drilling, Interm	E40	Oil Export Pipeline,SNA to SNB
D07	Drilling, General	D38	Drilling, Interm	F00	Flare, General, General
D08	Drilling, General	D39	Drilling, Interm	F01	Flare, General, Cellar Deck
D09	Drilling, General	D40	Drilling, Interm/North, General	F02	Flare, General, Cellar Mezzanine
D10	Drilling, South, General	D41	Drilling, Interm/North, Cellar Deck	F03	Flare, General, Intermediate Deck
D11	Drilling, South, Cellar Deck	D42	Drilling, Interm/North, Cellar Mezzanine	F04	Flare, General, Intermediate Mezzanine
D12	Drilling, South, Cellar Mezzanine	D43	Drilling, Interm/North, Intermedia	F05	Flare, General, Upper Deck
D13	Drilling, South, Intermediate Deck	D44	Drilling, Interm/North, Intermediate	F06	Flare, General, Upper Mezzanine
D14	Drilling, South, Intermediate Mezz.	D45	Drilling, Interm/North, Upper Deck	F10	Flare, South, General
D15	Level 1 Workshop and office module.	D46	Drilling, Interm/North, Upper Mezzanine	F11	Flare, South, Cellar Deck
D16	Level 2 Workshop and office module.	D47	Drilling, Interm/North	F12	Flare, South, Cellar Mezzanine
D17	Level 3 Workshop and office module.	D48	Drilling, Interm/North	F13	Flare, South, Intermediate Deck
D18	Level 4 Workshop and office module.	D49	Drilling, Interm/North	F14	Flare, South, Intermediate Mezzanine
D19	Drilling, South	D50	Drilling, North, General	F15	Flare, South, Upper Deck
D20	Drilling, South/Interm, General	D51	Drilling, North, Cellar Deck	F16	Flare, South, Upper Mezzanine
D21	Drilling, South/Interm, Cellar Deck	D52	Drilling, North, Cellar Mezzanine	F20	Flare, South/Interm, General
D22	Drilling, South/Interm, Cellar Mezzanine	D53	Drilling, North, Intermediate Deck	F21	Flare, South/Interm, Cellar Deck
D23	Drilling, South/Interm, Intermedia	D54	Drilling, North, Intermediate Mezz	F22	Flare, South/Interm, Cellar Mezzanine
D24	Drilling, South/Interm, Intermedia	D55	Drilling, North, Upper Deck	F23	Flare, South/Interm, Intermediate
D25	Drilling, South/Interm, Upper Deck	D56	Drilling, North, Upper Mezzanine	F24	Flare, South/Interm, Intermediate
D26	Drilling, South/Interm, Upper Mezzanine	D57	Drilling, North	F25	Flare, South/Interm, Upper Deck
D27	Drilling, South/Interm, Intermediate	D58	Drilling, North	F26	Flare, South/Interm, Upper Mezzanine
D28	Drilling, South/Interm.	D59	Ingen tekst	F30	Flare, Interm, General
D29	Drilling, South/Interm.	E00	Export Pipelines	F31	Flare, Interm, Cellar Deck
D30	Drilling, Interm, General	E01	Export Pipelines, General, Pull-In	F32	Flare, Interm, Cellar Mezzanine
D31	Drilling, Interm, Cellar Deck	E10	Export Gas Pipeline, General	F33	Flare, Interm, Intermediate Deck
D32	Drilling, Interm, Cellar Mezzanine	E11	Export Gas Pipeline, Pull-In/Comm	F34	Flare, Interm, Intermediate Mezzanine
D33	Drilling, Interm, Intermediate Deck	E20	Export Oil Pipeline, General	F35	Flare, Interm, Upper Deck
D34	Drilling, Interm, Intermediate Mezzanine	E21	Export Oil Pipeline, Pull-In/Comm	F36	Flare, Interm, Upper Mezzanine
D35	Drilling, Interm, Upper Deck	E30	Export Oil Pipeline, Vigdis, General	F37	Flare Boom
D36	Drilling, Interm, Upper Mezzanine	E31	Export Oil Pipeline, Vigdis, Pull	F40	Flare, Interm/North, General

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

F41	Flare, Interm/North, Cellar Deck	H03	General Hull, General	L02	Living Quarter, General, Second Flo
F42	Flare, Interm/North, Cellar Mezzanine	H04	General Hull, General	L03	Living Quarter, General, Third Flo
F43	Flare, Interm/North, Intermediate	H10	General Hull	L04	Living Quarter, General, Fourth Floor
F44	Flare, Interm/North, Intermediate	H11	General Hull	L05	Living Quarter, General, Fifth Floor
F45	Flare, Interm/North, Upper Deck	H12	General Hull	L06	Living Quarter, General, Roof Area
F46	Flare, Interm/North, Upper Mezzanine	H13	General Hull	L07	Living Quarter, General
F50	Flare, North, General	H14	General Hull	L10	Living Quarter, , General
F51	Flare, North, Cellar Deck	H21	General Hull	L11	Living Quarter, , First Floor
F52	Flare, North, Cellar Mezzanine	H22	General Hull	L12	Living Quarter, , Second Floor
F53	Flare, North, Intermediate Deck	H23	General Hull	L13	Living Quarter, , Third Floor
F54	Flare, North, Intermediate Mezzanine	H24	General Hull	L14	Living Quarter, , Fourth Floor
F55	Flare, North, Upper Deck	H30	General Hull	L15	Living Quarter, , Fifth Floor
F56	Flare, North, Upper Mezzanine	H31	General Hull	L20	Living Quarter, South, General
F90	Flare, General, General	H32	General Hull	L21	Living Quarter, South, First Floor
FLORØ	FLORØ	H33	General Hull	L22	Living Quarter, South, Second Floor
FN1	LER/HVAC Room - North	H34	General Hull	L23	Living Quarter, South, Third Floor
FOR	Forus	H40	General Hull	L24	Living Quarter, South, Fourth Floor
FS1	LER/HVAC Room - South	H41	General Hull	L25	Living Quarter, South, Fifth Floor
G00	Flowlines, General, General	H42	General Hull	L26	Living Quarter, South, Roof Area
G10	Flowline, Bundle Template A, General	H43	General Hull	L27	Helideck
G11	Flowline 1 Production Bundle Tem	H44	General Hull	L30	Living Quarter, Intermediate, General
G12	Flowline 2 Production Bundle Tem	J00	Vigdis, General	L31	Living Quarter, Intermediate, First Floo
G13	Flowlines Water Injection Line	J20	Vigdis Templ.Struct., General	L32	Living Quarter, Intermediate, Second Flo
G14	Flowlines TLF/Service Line 1	J30	Vigdis Manifold, General	L33	Living Quarter, Intermediate, Third Floo
G15	Flowline Bundle TFL/Service Line	J31	Vigdis Prod. Manifold 1 (1220)	L34	Living Quarter, Intermediate, Fourth Flo
G50	Umbilical Template A, General	J32	Vigdis Prod. Manifold 2	L35	Living Quarter, Intermediate, Fifth Floo
G90	Flowlines, General	J33	Vigdis Water Injection Manifold 1	L36	Living Quarter, Intermediate, Roof Area
GF1	Gullfaks C	J50	OMR+DE J50	L37	Roof on L36
H00	General Hull, General, General	K00	KKK	L40	Living Quarter, North, General
H01	General Hull, General	L00	Living Quarter, General, General	L41	Living Quarter, North, First Floor
H02	General Hull, General	L01	Living Quarter, General, First Flo	L42	Living Quarter, North, Second Floor

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

L43	Living Quarter, North, Third Floor	N10	Node no.1	P13	Process, South, Intermediate Deck
L44	Living Quarter, North, Fourth Floor	N11	Node no.1 South/West	P14	Process, South, Intermediate Mezzanine
L45	Living Quarter, North, Fifth Floor	N12	Node no.1	P15	Process, South, Upper Deck
L46	Living Quarter, North, Roof Area	N13	Node no.1	P16	Vigdis Module, Main Deck
L47	Roof on L46	N14	Node no.1	P17	Vigdis Module, Mezzanine Deck
L50	Living Quarter, , General	N20	Node no.2	P18	Vigdis Module, Weather Deck
L51	Living Quarter, , First Floor	N21	Node no.2 North/West	P20	Process, South/Interm, General
L52	Living Quarter, , Second Floor	N22	Node no.2	P21	Process, South/Interm, Cellar Deck
L53	Living Quarter, , Third Floor	N23	Node no.2	P22	Process, South/Interm, Cellar Mezzanine
L54	Living Quarter, , Fourth Floor	N24	Node no.2	P23	Process, South/Interm, Intermediate
L55	Living Quarter, , Fifth Floor	N30	Node no.3	P24	Process, South/Interm, Intermediate
L56	Living Quarter, Sixth Floor	N31	Node no.3 North/East	P25	Process, South/Interm, Upper Deck
L57	Living Quarter, HVAC room, top of L56	N32	Node no.3	P26	Process, South/Interm, Upper Mezzanine
LMV	Maint. Vessel Area	N33	Node no.3	P27	Process, South/Interm, Roof
LWR	Workover Rig Area	N34	Node no.3	P28	Nytt område ifm Snorre B,TLP modifik.
M00	Marshalling Area, General, General	N40	Node no.4	P30	Process, Interm, General
M01	Marshalling Area, General, Cellar Deck	N41	Node no.4 South/East	P31	Process, Interm, Cellar Deck
M10	Marshalling Area, South, General	N42	Node no.4	P32	Process, Interm, Cellar Mezzanine
M11	Marshalling Area, South, Cellar Deck	N43	Node no.4	P33	Process, Interm, Intermediate Deck
M13	Marshalling Area, South, Intermediate	N44	Node no.4	P34	Process, Interm, Intermediate Mezzanine
M20	Marshalling Area, South/Interm, General	P00	Process, General, General	P35	Process, Interm, Upper Deck
M21	Marshalling Area, South/Interm, Cellar	P01	Process, General, Cellar Deck	P36	Process, Interm, Upper Mezzanine
M30	Marshalling Area, Interm, General	P02	Process, General, Cellar Mezzanine	P37	Process, Interm, Roof
M31	Marshalling Area, Interm, Cellar Deck	P03	Process, General, Intermediate Deck	P40	Process, Interm/North, General
M40	Marshalling Area, Interm/North, General	P04	Process, General, Intermediate Mezzanine	P41	Process, Interm/North, Cellar Deck
M41	Marshalling Area, Interm/North, Cellar	P05	Process, General, Upper Deck	P42	Process, Interm/North, Cellar Mezzanine
M50	Marshalling Area, North, General	P06	Process, General, Upper Mezzanine	P43	Process, Interm/North, Intermediate Deck
M51	Marshalling Area, North, Cellar Deck	P07	Process, General, Roof	P44	Process, Interm/North, Intermediate
M53	Marshalling Area, North, Interm. Deck	P10	Process, South, General	P45	Process, Interm/North, Upper Deck
MV1	Maint Vessel Area	P11	Process, South, Cellar Deck	P46	Process, Interm/North, Upper Mezzanine
N00	Node, General	P12	Process, South, Cellar Mezzanine	P47	Process, Interm/North, Roof

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

P50	Process, North, General	R14	TLP Rigid Risers, Prod./Inj. P14	R45	TLP Rigid Risers, Prod./Inj. P45
P51	Process, North, Cellar Deck	R15	TLP Rigid Risers, Prod./Inj. P15	R46	TLP Rigid Risers, Prod./Inj. P46
P52	Process, North, Cellar Mezzanine	R16	TLP Rigid Risers, Prod./Inj. P16	R47	TLP Rigid Risers, Oil Export Ris
P53	Process, North, Intermediate Deck	R17	TLP Rigid Risers, Prod./Inj. P17	R48	TLP Rigid Risers, Gas Export Ris
P54	Process, North, Intermediate Mezzanine	R18	TLP Rigid Risers, Prod./Inj. P18	R49	TLP Rigid Risers, Drilling Ris
P55	Process, North, Wag Compr. Area	R19	TLP Rigid Risers, Prod./Inj. P19	R70	TLP Rigid Risers
P56	Process, North, Upper Mezzanine	R20	TLP Rigid Risers, Prod./Inj. P20	R81	TLP Rigid Risers
P57	Process, North, Roof	R21	TLP Rigid Risers, Prod./Inj. P21	R82	TLP Rigid Risers
P60	Re-comp. and injection comp. module	R22	TLP Rigid Risers, Prod./Inj. P22	S00	General
P88	Vigdis Processing Modul, General	R23	TLP Rigid Risers, Prod./Inj. P23	S01	Template, Wellbays 01
Q00	Well Template, General	R24	TLP Rigid Risers, Prod./Inj. P24	S02	Template, Wellbays 02
Q47		R25	TLP Rigid Risers, Prod./Inj. P25	S03	Template, Wellbays 03
Q48		R26	TLP Rigid Risers, Prod./Inj. P26	S04	Template, Wellbays 04
Q70	Well Template, Pipeline Porch	R27	TLP Rigid Risers, Prod./Inj. P27	S05	Template, Wellbays 05
Q71	Well Template, Gas Spool Piece	R28	TLP Rigid Risers, Prod./Inj. P28	S06	Template, Wellbays 06
Q72	Well Template, Oil Spool Piece	R29	TLP Rigid Risers, Prod./Inj. P29	S07	Template, Wellbays 07
Q73	Well Template, Structure	R30	TLP Rigid Risers, Prod./Inj. P30	S08	Template, Wellbays 08
R00	TLP Rigid Risers,General	R31	TLP Rigid Risers, Prod./Inj. P31	S09	Template, Wellbays 09
R01	TLP Rigid Risers, Prod./Inj. P01	R32	TLP Rigid Risers, Prod./Inj. P32	S1	Snorre plattform, uspesifisert område
R02	TLP Rigid Risers, Prod./Inj. P02	R33	TLP Rigid Risers, Prod./Inj. P33	S10	Template, Wellbays 10
R03	TLP Rigid Risers, Prod./Inj. P03	R34	TLP Rigid Risers, Prod./Inj. P34	S20	Template Structure General
R04	TLP Rigid Risers, Prod./Inj. P04	R35	TLP Rigid Risers, Prod./Inj. P35	S21	Production Manifold 1
R05	TLP Rigid Risers, Prod./Inj. P05	R36	TLP Rigid Risers, Prod./Inj. P36	S22	Production Manifold 2
R06	TLP Rigid Risers, Prod./Inj. P06	R37	TLP Rigid Risers, Prod./Inj. P37	S23	Water Injection Manifold
R07	TLP Rigid Risers, Prod./Inj. P07	R38	TLP Rigid Risers, Prod./Inj. P38	S24	Subsea Production, Template A
R08	TLP Rigid Risers, Prod./Inj. P08	R39	TLP Rigid Risers, Prod./Inj. P39	S25	Subsea Production, Template A
R09	TLP Rigid Risers, Prod./Inj. P09	R40	TLP Rigid Risers, Prod./Inj. P40	S26	Subsea Production, Template A
R10	TLP Rigid Risers, Prod./Inj. P10	R41	TLP Rigid Risers, Prod./Inj. P41	S27	Subsea Production, Template A
R11	TLP Rigid Risers, Prod./Inj. P11	R42	TLP Rigid Risers, Prod./Inj. P42	S28	Subsea Production, Template A
R12	TLP Rigid Risers, Prod./Inj. P12	R43	TLP Rigid Risers, Prod./Inj. P43	S29	Subsea Production, Template A
R13	TLP Rigid Risers, Prod./Inj. P13	R44	TLP Rigid Risers, Prod./Inj. P44	S30	Manifold, General

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

S31	Production Manifold 1	U03	Utilities, General, Intermediate Deck	U35	Utilities, Interm, Upper Deck
S32	Production Manifold 2	U04	Utilities, General, Intermediate Mezz.	U36	Utilities, Interm, Upper Mezzanine
S40	ROMV	U05	Utilities, General, Upper Deck	U37	Utilities, Interm
S50	Completion and Workover Rig	U07	Utilities, General	U38	Utilities, Interm
S60	Invervention System and Tools	U08	Utilities, General	U39	Utilities, Interm
T00	Pontoon, General, General	U09	Utilities, General	U40	Utilities, Interm/North, General
T01	Pontoon, General	U10	Utilities, South, General	U41	Utilities, Interm/North, Cellar Deck
T10	Pontoon no.1	U11	Utilities, South, Cellar Deck	U42	Utilities, Interm/North, Cellar Mezzanin
T11	Pontoon no.1 - West	U12	Utilities, South, Cellar Mezzanine	U43	Utilities, Interm/North, Intermediate De
T12	Pontoon no.1	U13	Utilities, South, Intermediate Deck	U44	Utilities, Interm/North, Intermediate Me
T13	Pontoon no.1	U14	Utilities, South, Intermediate Mezz.	U45	Utilities, Interm/North, Upper Deck
T14	Pontoon no.1	U15	Utilities, South, Upper Deck	U46	Utilities, Interm/North, Upper Mezzanine
T20	Pontoon no.2	U16	Utilities, South, Upper Mezzanine	U47	Utilities, Interm/North
T21	Pontoon no.2 - North	U17	Utilities, South	U48	Utilities, Interm/North
T22	Pontoon no.2	U18	Utilities, South	U49	Utilities, Interm/North
T23	Pontoon no.2	U19	Utilities, South	U50	Utilities, North, General
T24	Pontoon no.2	U20	Utilities, South/Interm, General	U51	Utilities, North, Cellar Deck
T30	Pontoon no.3	U21	Utilities, South/Interm, Cellar Deck	U52	Utilities, North, Cellar Mezzanine
T31	Pontoon no.3 - East	U22	Utilities, South/Interm, Cellar Mezz.	U53	Utilities, North, Intermediate Deck
T32	Pontoon no.3	U23	Utilities, South/Interm, Intermediate	U54	Utilities, North, Intermediate Mezzanine
T33	Pontoon no.3	U24	Utilities, South/Interm, Intermediate	U55	Utilities, North, Upper Deck
T34	Pontoon no.3	U25	Utilities, South/Interm, Upper Deck	U56	Utilities, North, Upper Mezzanine
T40	Pontoon no.4 - South	U26	Utilities, South/Interm, Upper Mezzanine	U57	Utilities, North
T41	Pontoon no.4	U27	Utilities, South/Interm	U58	Utilities, North
T42	Pontoon no.4	U28	Utilities, South/Interm	U59	Utilities, North
T43	Pontoon no.4	U29	Utilities, South/Interm	W00	Wellbay, General, General
T44	Pontoon no.4	U30	Utilities, Interm, General	W01	Wellbay, General, Cellar Deck
TCM	Temporary Control Module, Outside	U31	Utilities, Interm, Cellar Deck	W02	Wellbay, General, Cellar Mezzanine
U00	Utilities, General, General	U32	Utilities, Interm, Cellar Mezzanine	W03	Wellbay, General, Intermediate Deck
U01	Utilities, General, Celler Deck	U33	Utilities, Interm, Intermediate Deck	W05	Wellbay, General, Upper Deck
U02	Utilities, General, Celler Mezzanine	U34	Utilities, Interm, Intermediate Mezz.	W06	Skid Base (El.519.500)

A.43 Fortsettelse: Oversikt over Lokasjoner - Beskrivelse

W07	Drilling Sub-Substruc./BOP Deck	W68	WORKOVER RIG DRILLING DERRICK/SUB-SUBSTR	Y33	Foundation Template 3, Conn.3
W08	Drilling Derrick	WR1	Workover Rig Area	Y34	Foundation Template 3, Conn.3
W09	Skid Frame for Workover Rig	X00	Flexible Risers and Jumpers, General	Y40	Foundation Template 4, South/East
W10	Wellbay, South, General	X10	Flexible Risers Template A, General	Y41	Foundation Template 4, South/East
W11	Wellbay, South, Cellar Deck	X11	Flexible Production Riser 1 Temp.	Y42	Foundation Template 4, Conn.2
W12	Wellbay, South, Cellar Mezzanine	X12	Flexible Production Riser 2 Temp.	Y43	Foundation Template 4, Conn.3
W13	Wellbay, South, Intermediate Deck	X13	Flexible Riser - Water Injection	Y44	Foundation Template 4, Conn.3
W15	Wellbay, South, Upper Deck	X14	Flexible Riser 1 Service Line Te	Y73	Foundation Template
W20	Wellbay, South/Interm, General	X15	Flexible Riser 2 Service Line Te	Y83	Foundation Template
W21	Wellbay, South/Interm, Cellar Deck	X16	Umbilical 1 Snorre SPS	Z00	Tether, General, General
W22	Wellbay, South/Interm, Cellar Mezzanine	X17	Umbilical 2 Snorre SPS	Z11	Tether String Gr.1 no.1 (South/West)
W23	Wellbay, South/Interm, Intermediate Deck	X18	Umbilical 3 Snorre SPS	Z12	Tether String Gr.1 no.2 (South/West)
W25	Wellbay, South/Interm, Upper Deck	X21	Ingen tekst	Z13	Tether String GR 1 no.3 (South/West)
W30	Wellbay, Interm, General	X22	Ingen tekst	Z14	Tether String Gr.1 no.4 (South/West)
W31	Wellbay, Interm, Cellar Deck	X23	Ingen tekst	Z21	Tether String Gr.2 no.1 (North/West)
W32	Wellbay, Interm, Cellar Mezzanine	X24	Ingen tekst	Z22	Tether String Gr.2 no.2 (North/West)
W33	Wellbay, Interm, Intermediate Deck	X60	Flexible Risers and Jumpers	Z23	Tether String Gr.2 no.3 (North/West)
W35	Wellbay, Interm, Upper Deck	Y00	Foundation Template, General, General	Z24	Tether String Gr.2 no.4 (North/West)
W40	Wellbay, Interm/North, General	Y10	Foundation Template 1, South/West	Z31	Tether String Gr.3 no.1 (North/East)
W41	Wellbay, Interm/North, Cellar Deck	Y11	Foundation Template 1, Conn.1	Z32	Tether String Gr.3 no.2 (North/East)
W42	Wellbay, Interm/North, Cellar Mezzanine	Y12	Foundation Template 1, Conn.2	Z33	Tether String Gr.3 no.3 (North/East)
W43	Wellbay, Interm/North, Intermediate Deck	Y13	Foundation Template 1, Conn.3	Z34	Tether String GR 3 no.4 (North/East)
W45	Wellbay, Interm/North, Upper Deck	Y14	Foundation Template 1, Conn.4	Z41	Tether String Gr.4 no.1 (North/East)
W50	Wellbay, North, General	Y20	Foundation Template 2, North/West	Z42	Tether String GR 4 no.2 (South/East)
W51	Wellbay, North, Cellar Deck	Y21	Foundation Template 2, Conn.1	Z43	Tether String Gr.4 no.3 (North/East)
W52	Wellbay, North, Cellar Mezzanine	Y22	Foundation Template 2, Conn.2	Z44	Tether String Gr.4 no.4 (North/East)
W53	Wellbay, North, Intermediate Deck	Y23	Foundation Template 2, Conn.3	ZZZZ	Scrapped Equipments
W55	Wellbay, North, Upper Deck	Y24	Foundation Template 2, Conn.4		
W60	Well Intervention Tower.	Y30	Foundation Template 3, North/East		
W66	RIGG 2, SKID FRAME	Y31	Foundation Template 3, Conn.1		
W67	RIGG 2, MUD MODULE	Y32	Foundation Template 3, North/East		

A.5 Notifikasjoner - Arbeidsgruppe

A.51 Notifikasjoner/høykritiske notifikasjoner - Arbeidsgruppe

Arbeidssenter	Antall	Prosent
IMOAUTSA	23	2,32
IMOTEL	48	4,83
POMAUT	89	8,96
POMELE	7	0,70
POMMEC	49	4,93
PPMAUT	238	23,97
PPMAUTM	39	3,93
PPMELE	74	7,45
PPMISP	4	0,40
PPMMEC	258	25,98
Andre jobbsenter	164	16,52
Totalt	993	100,00

Arbeidssenter	Antall	Prosent
IMOAUTSA	4	4
IMOTEL	4	4
POMAUT	61	61
POMELE	5	5
POMMEC	19	19
PPMAUT	1	1
PPMAUTM	1	1
PPMELE	1	1
PPMISP	1	1
PPMMEC	3	3
Andre jobbsenter	0	0
Totalt	100	100

Workcenter	Antall tag	Høykritiske	Andel høykritiske %
IMOAUTSA	0	0	0,0
PPMAUTM	0	0	0,0
PPMELE	0	0	0,0
PPMISP	0	0	0,0
PPMAUT	81	1	1,2
PPMMEC	300	75	25,0
IMOTEL	635	372	58,6
POMELE	16328	5614	34,4
POMMEC	33938	10852	32,0
POMAUT	56367	15790	28,0
Andre	10174	1489	14,6
Totalt	107649	32704	30,4

A.52 Notifikasjoner/høykritiske notifikasjoner - Arbeidsgruppe, statistikk

Workcenter	Totalt	High	% høykritisk	μ notifikasjo	μ Høykritisk	Differanse notifikasjoner	Differanse Høykritisk	% Differanse notifikasjoner	% Differanse Høykritisk
IMOAUTSA	27	4	#DIV/0!	0,00	0,00	-27,00	-4,00	0,00	0,00
IMOTEL	52	4	58,58	5,35	1,09	-46,65	1,35	-871,69	124,21
POMAUT	150	61	28,01	475,04	46,18	325,04	414,04	68,42	896,48
POMELE	12	5	34,38	137,60	16,42	125,60	132,60	91,28	807,56
POMMEC	68	19	31,98	286,01	31,74	218,01	267,01	76,22	841,22
PPMAUT	239	1	1,23	0,68	0,00	-238,32	-0,32	-34911,61	0,00
PPMAUTM	40	1	#DIV/0!	0,00	0,00	-40,00	-1,00	0,00	0,00
PPMELE	75	1	#DIV/0!	0,00	0,00	-75,00	-1,00	0,00	0,00
PPMISP	5	1	#DIV/0!	0,00	0,00	-5,00	-1,00	0,00	0,00
PPMMEC	261	3	25,00	2,53	0,22	-258,47	-0,47	-10223,30	-215,04
Andre:	-929		14,64	85,74	4,36	1014,74	85,74	1183,49	1968,72

A.53 Oversikt over Arbeidsgrupper - Beskrivelse

C18SA6	Fabricom V&M ABB Offshore	XSORCO	Sørco	B80 AKWS	B&B Aker Kvaerner Well Service
G-OS	OS team	XUNIFAB	Unifab	B83 DRQI	B&B DrilQuip
INSTLED	PLA MOD installasjonsleder	XVETCO	Vetco Aibel AS	B84 EXGR	B&B Expro Group
SNA-IIT	IT Support	COLSSNA	V&M AOP Sokkel SNA	B85 SMIT	B&B Smith International
SRP	SNOREV Commissioning	G-SG1	Systemgruppe 1 - Vedlikehold	B86 RDSP	B&B RedSpider
XAKEREL	AkerKvaerner elektro	LOG	Logistikk	B87 ODFJ	B&B Odfjell Drilling AS
XANZETT	Anzett	PDW	Boring og brønn	B88 PEAK	B&B Peak Well Solutions AS
XASNA	C-Tour ferdigstillelse	POM	Drift og vedlikehold	B89 WDYM	B&B Well Dynamics
XAUTRONI	Autronica Fire & Security	SNA_X&E	Snorre A eksterne	B90 VETC	B&B Vetco Aibel
XDNV	Det Norske Veritas	SNAD&V	Snorre A D&V lag	B91 MAER	B&B Maersk
XERMERSO	Emerson	SNATOT	Snorre A total	B92 CT	B&B Champion Technologies
XFAB	Fabricom	SNAV&M_H	Snorre A V&M hvite fag	B93 SD	B&B Seadrill
XFSNA	C-Tour automasjon og elektro	SNAV&M_S	Snorre A V&M svarte fag	B94 WF	B&B Weatherford
XIFE	Institutt for energiteknikk	B01 LAND	B&B Landstøtte	B95 SPS	B&B SPS INTERNATIONAL NORGE
XINSTRUT	Instrutek as	B02 OFF	B&B Offshore	B96 PI	B&B PI Intervension
XITIS	ITIS AS	B03 EXT	B&B Eksterne ressurser utenfor SAP	B97 TCO	B&B Total Catcher Offshore AS
XJVCENGI	JVC Engineering AS	B10 BOT	B&B Baker Oil & Tools	B98 WELL	B&B Welltech
XKONGS	Kongsberg Maritime AS	B15 BHI	B&B Baker Hughes INTEQ	B99 WEPC	B&B Wepco
XLMT	LMT	B20 BJ	B&B BJ Service	COLAUT	AKER V&M AUTOMASJON
XLSNA	C-Tour rør og sveis	B25 GYRO	B&B Gyrodata Ltd. - NUF	COLDOC	AKER V&M DOKUMENT OPPDATERING
XMATOR	Mator AS	B30 CAME	B&B Cameron	COLELE	AKER V&M ELEKTRO
XMIROS	Miros	B35 DPI	B&B Diamond Products International	COLENG	AKER V&M FELT INGENIØR
XNATOILW	National Oilwell Norway AS	B40 HALL	B&B Halliburton	COLFAB	AKER V&M PREFABRIKASJON
XNORCONS	Norconsult	B45 LYNG	B&B Lyng Drilling AS	COLGEN	Aker V&M Generell multidisiplin
XODTLSNA	ODT rør og sveis	B50 MI	B&B MI	COLHVC	AKER V&M HVAC
XODTRSNA	ODT mekanisk	B51 OCEE	B&B Oceaneering	COLMAN	AKER V&M LEDELSE
XORIGO	Origo Engineering AS	B55 REED	B&B Reed Hycalog Norway - NUF	COLMCC	AKER V&M FERDIGSTILLING
XRCC	RC Consultants AS	B60 ROXA	B&B Roxar	COLMEC	AKER V&M MEKANISK
XROSENBE	Rosenberg verft	B65 HC	B&B Hughes Christensen	COLPIP	AKER V&M RØR INSTALLASJON
XSEMCO	Semco Maritime AS	B70 SLB	B&B Schlumberger	COLSPE	AKER V&M SPESIALIST
XSIEMENS	Siemens AS Oil & Gas Division	B72 DEWE	B&B DeepWell AS	COLSTE	AKER V&M STÅL
XSMEDVIG	Smedvig	B75 SDC	B&B Scientific Drilling Controls	COLTEL	AKER V&M TELECOM

A.53 Fortsettelse: Oversikt over Arbeidsgrupper - Beskrivelse

C01WLD	AKER V&M SVEISER	C81TEL	ABB V&M Tele	GOOBOROO	B&B Offshore
C18AUT	Fabricom V&M Automasjon	E-AUT	Utgår overføres G-AUT-F	IMOAUTFM	FFO Fiskal måling
C18DOC	Fabricom V&M Dokument oppdatering	E-BOR	Boring (borekontraktor)	IMOAUTSA	FFO Automasjon SAS
C18ELE	Fabricom V&M Elektro	E-BRN	Brønnoperasjoner	IMOMEYRO	FFO Mekanisk roterende / vedl.
C18ENG	Fabricom V&M Felt ingeniør	E-ELE	Utgår overføres G-ELE	IMOMEYTK	FFO Mekanisk roterende / TK
C18FAB	Fabricom V&M Prefabrikasjon	E-INS	Utgår overføres AKOP	IMOMEYTM	FFO Mekanisk termografi
C18GEN	Fabricom V&M Generell multidisiplin	E-INS-S	-UTGÅR- bruk E00ISP	IMOTEL	FFO Tele
C18HVC	Fabricom V&M HVAC	E-INS-U	Inspeksjon undervannssystemer	L-DRT	TO DVM DRT (Driftsteknikk)
C18MAN	Fabricom V&M Ledelse	E-MAR	Utgår overføres G-MAR	L-FLO	Florø Base inspection/repair work center
C18MCC	Fabricom V&M Ferdigstilling	E-MEK	Mekanisk (entreprenør)	L-MOD	TO DVM MOD (Modifikasjoner)
C18MEC	Fabricom V&M Mekanisk	E-MEK-V	Mekanisk Ventil (entreprenør)	L-OPS	SNA operasjoner land
C18PIP	Fabricom V&M Rørinstallasjon	E-PRO	Utgår overføres G-PRO	L-OPS-P	SNA operasjoner - Plan
C18SPE	Fabricom V&M Spesialist	E-ROV	ROV operasjoner	L-PLA	TO PLA MOD (Prosjekter)
C18STE	Fabricom V&M Stål	E00CLE	Rengjøring	L-RES	TO RESU Boring
C18TEL	Fabricom V&M Telecom	E00EOCCL	Sakkyndig Kran & løft	L-V&M	V&M Kontraktor
C18WLD	Fabricom V&M Sveiser	E00ISP	Spesialtjenester inspeksjon	L-V&M-D	V&M Dokument oppdatering
C32CLB	BIS ISO Tilkomstteknikk/klatrer	E00PAI	Overflatevedlikehold	L-VDL	TO DVM VDL (Vedlikehold)
C32CLB2	BIS ISO Tilkomst./klatrer 24t skift	E00SPE	Spesialist	M02AUT	SNEX Automasjon
C32CLE	BIS ISO Rengjøring	E00SUB	Subsea operasjoner	M02ELE	SNEX Elektro
C32CLE2	BIS ISO Rengjøring 24t skift	E18MECRO	BIS Production Partner Mechanical maint.	M02LOG	SNEX Rigging/transport
C32ISU	BIS ISO Isolasjon	E20AUT	Kaefer Energy Automasjon	M02MEC	SNEX Mekanisk
C32ISU2	BIS ISO Isolasjon 24t skift	E20ELE	Kaefer Energy Elektro	M02PIP	SNEX Rørinstallasjon
C32MAN	BIS ISO Ledelse	E20HVC	Kaefer Energy HVAC	M02SAF	SNEX Sikringsvakter
C32MAN2	BIS ISO Ledelse 24t skift	E20ISU	Kaefer Energy Isolasjon	M02SPE	SNEX Spesialist
C32SCA	BIS ISO Stillas	E20MEC	Kaefer Energy Mekanisk	M02STE	SNEX Stål
C32SCA2	BIS ISO Stillas 24t skift	E20PIP	Kaefer Energy Rørinstallasjon	M02TEL	SNEX Telecom
C32SCACL	BIS ISO Kran og Løft	E20STR	Kaefer Energy Struktur	M02WLD	SNEX Sveiser
C32SPE	BIS ISO Spesialist	E20SUR	Kaefer Energy Overflatevedlikehold	M09SASAB	ABB
C32SPE2	BIS ISO Spesialist 24t skift	E20TEL	Kaefer Energy Tele	M09SASAI	Aibel
C32SUR	BIS ISO Overflatevedlikehold	E20WLD	Kaefer Energy Sveiser	M09SASAK	Aker
C32SUR2	BIS ISO Overflatevedlikehold 24t skift	G-LED	SMA lederlag	M09SASAM	Amitec
C43ISP	AGR Inspeksjon SNA	G-TK	TK-Operatør	M09SASAN	Andre

A.53 Fortsettelse: Oversikt over Arbeidsgrupper - Beskrivelse

M09SASAP	ApplySørco	PPMSUB	PV Subsea
M09SASEM	Emerson	PPMSUR	PV Overflate
M09SASF	Fabricom	SBB	Systemgruppe Boring & Brønn (kun LWCtr)
M09SASFM	FMC-Kongsberg	SG1	Systemgruppe 1 (brukes kun som LWCtr)
M09SASGO	Goodtech	SG2	Systemgruppe 2 (brukes kun som LWCtr)
M09SASKM	KM	SG3	Systemgruppe 3 (utgår, se ORO146)
M09SASOD	Odfjell	SG4	Systemgruppe 4 (brukes kun som LWCtr)
M09SASOR	Origo	SPIEOCCL	Sakkyndig K & L
M09SASRV	RV	SRP-COM	Commissioning
M09SASSE	Semco	XFAB-AUT	Fabricom instrument (automasjon)
M09SASSI	Siemens	XFAB-ELE	Fabricom elektro
M09SASST	Statoil	XFAB-HVA	Fabricom HVAC
M09SASTE	TeamUp	XFAB-ISO	Fabricom isolasjon
M09SASWE	WellDynamics	XFAB-MEK	Fabricom mekanisk
MODAUTAK	PSK MOD auto Aker	XFAB-NDT	Fabricom NDT
POMAUT	D&V Automasjon	XFAB-OFL	Fabricom overflate
POMAUTD	D&V Automasjon Digital	XFAB-RØR	Fabricom rør
POMELE	D&V Elektro	XFAB-STÅ	Fabricom stål/struktur
POMLAB	D&V Laborant	XFAB-STI	Fabricom stillas
POMLOG	D&V Logistikk	XFAB-TEL	Fabricom telecom
POMMEC	D&V Mekanisk		
POMNUR	D&V HMS Koordinator		
POMPRO	D&V Prosess		
PPMAUT	PV Automasjon		
PPMAUTM	PV Automasjon Måling		
PPMAUTTG	PV Automasjon-Tele		
PPMELE	PV Elektro		
PPMISP	PV Inspeksjon statisk prosessutstyr		
PPMISPR	PV Inspeksjon subsea rørledningssystemer		
PPMISPS	PV Inspeksjon bærende konstruksjoner		
PPMMEC	PV Mekanisk		
PPMPRO	PV Prosess		

A.6 Notifikasjoner - Planleggingsgruppe

A.61 Notifikasjoner/høykritiske notifikasjoner - Planleggingsgruppe

Arbeidssenter	Antall	Prosent	Arbeidssenter	Antall	Prosent
POM	95	95	POM	170	17,12
SOP	2	2	SOP	656	66,06
PPM	1	1	PPM	38	3,83
SOM	2	2	SOM	60	6,04
Andre	0	0	Andre	69	6,95
Totalt	100	100	Totalt	993	100,00

Videre analyse av planleggingsgruppe har ingen hensikt. De to tabellene er bare for å vise fordelingen.

A.62 Oversikt over Planleggingsgrupper - Beskrivelse

PG	Name
SPI	Anleggsintegritet
SDW	B&B leverandør
SBA	Base
SOM	Flerfeltsoperasjon
SIP	Inspeksjon land
SIN	ISO contr. Support
PIN	ISO contract Plant
SOP	Operasjonsgruppe
SSF	Overflatevedl.
PDW	Plattform B&B
POM	Plattform D&V
PPM	Plattform PV
PRO	PRO mod
SRM	RMM - R&V styring
SSU	Subsea land
SVM	V&M leverandør

7.2 Oversikt, Etterslep - Sikkerhetskritisk Vedlikehold

Måned	Antall
jan.07	22
feb.07	22
mar.07	45
apr.07	23
mai.07	19
jun.07	27
jul.07	54
aug.07	29
sep.07	37
okt.07	37
nov.07	35
des.07	21
jan.08	12
feb.08	10
mar.08	16
apr.08	26
mai.08	20
jun.08	40
jul.08	70
aug.08	50
sep.08	26
okt.08	16
nov.08	25
des.08	4
jan.09	10
feb.09	9
mar.09	21
apr.09	7
mai.09	8
jun.09	5
jul.09	9
aug.09	11
sep.09	6
okt.09	10
nov.09	6
des.09	15
jan.10	9
feb.10	7

mar.09	21
apr.09	7
mai.09	8
jun.09	5
jul.09	9
aug.09	11
sep.09	6
okt.09	10
nov.09	6
des.09	15
jan.10	9
feb.10	7
mar.10	2
apr.10	3
mai.10	8
jun.10	3
jul.10	10
aug.10	8
sep.10	9
okt.10	2
nov.10	2
des.10	2
jan.11	0
feb.11	0
mar.11	0
apr.11	0

A.8 CMR Sikkerhetskritisk Korrektivt Vedlikehold - 30 dager

Disse er enten i etterslep, eller kommer i etterslep dersom de ikke er utført innen 30 dager.

Maint planning plant	Func.	F. Imp.	Order		LWctr	MPG	MWctr	PLAN	DISP	Status	Pri	Not. date	Req. end
Snorre A Platform	1220-	S	21679320	Lavt erifonnivå på	1220/POM	SOP	1220/P	#	#	PRCO	M	31.10.2010	30.12.2010
	1220-	S	22085686	N2 lekkasje i	1220/POM	SOP	1220/P	#	#	RDEX	M	27.04.2011	27.05.2011
	1220-	S	21930864	Pakkboks lekkasje på	1220/POM	SOP	1220/P	#	#	RDEX	M	04.12.2010	03.01.2011
	1220-	S	22065356	Skifte stem pakning på	1220/POM	SOP	1220/P	#	#	PREP	M	29.03.2011	28.04.2011
	1220-	S	21499781	Ukjent ventilstatus på	1220/POM	SDW	1220/E-	#	#	PREP	M	19.02.2010	21.03.2010
	1220-	S	21252615	Skifte ut bolter mellom	1220/POM	SOP	1220/P	#	#	RDEX	U	22.05.2009	10.09.2010
	1220-	S	21648818	Gangtid er tilstrekkelig	1220/POM	SOP	1220/P	#	#	PRCO	M	26.09.2010	26.04.2011
	1220-	S	21648819	Gangtid er tilstrekkelig	1220/POM	SOP	1220/P	#	#	PRCO	M	26.09.2010	26.04.2011
	1220-	S	21979313	Hydraulikklekkasje på	1220/POM	SOP	1220/P	#	#	PRCO	M	13.01.2011	12.02.2011
	1220-2"	S	21881069	Utbedre	1220/POM	PPM	1220/C	PLAN	#	RDEX	M	28.11.2010	28.12.2010
	1220-	S	22023621	Nivåmåler testseparator	1220/POM	PPM	1220/P	PLAN	#	RDEX	M	16.02.2011	18.03.2011
	1220-	S	21563144	Hyd. lekk. fra	1220/POM	SOP	1220/P	#	#	RDEX	M	25.05.2010	01.05.2011
	1220-	S	22023619	LAHH kom ikke inn	1220/POM	SOP	1220/P	#	#	PREP	M	16.02.2011	18.03.2011
	1220-	S	22083169	Pakkbokslekkasje i	1220/POM	SOP	1220/P	#	#	RDEX	M	23.04.2011	23.05.2011
	1220-	S	22079005	LASK:Extern feil på	1220/POM	SOP	1220/P	#	#	RDEX	M	11.04.2011	11.05.2011
	1220-	S	22079006	LASK:Extern feil på	1220/POM	SOP	1220/P	#	#	RDEX	M	11.04.2011	11.05.2011
	1220-	S	21865633	Pakkbokslekkasje	1220/POM	SOP	1220/P	#	#	RDEX	M	30.11.2010	30.12.2010
	1220-	S	21518647	Defus gasslekkasje	1220/POM	PPM	1220/P	PLAN	#	PRCO	M	18.03.2010	10.04.2011
	1220-	S	21986154	Liten Stemlekkasje,	1220/POM	SOP	1220/P	#	#	PRCO	M	23.01.2011	22.02.2011
	1220-	S	21986153	Defuss lekkasje, gass	1220/POM	SOP	1220/P	#	#	PRCO	M	23.01.2011	22.02.2011
	1220-	S	21986156	Stemlekkasje, gass	1220/POM	SOP	1220/P	#	#	PRCO	M	23.01.2011	22.02.2011
	1220-	S	21986155	Stemlekkasje, gass	1220/POM	SOP	1220/P	#	#	PRCO	M	23.01.2011	22.02.2011
	1220-4"	S	22064980	Lekkasje 4"-DO-56A216-	1220/POM	PPM	1220/C	PLAN	#	RDEX	M	28.03.2011	31.05.2011
	1220-	S	21956356	Intern lekkasje i ventil	1220/POM	SOP	1220/P	#	#	PRCO	M	13.12.2010	12.01.2011
	1220-	S	22030485	4 stk transmittere feil	1220/POM	SOP	1220/P	#	#	RDEX	M	25.02.2011	27.03.2011
	1220-	S	21964555	Stopper 1cm før den er	1220/POM	SOP	1220/P	#	#	RDEX	M	28.12.2010	27.01.2011
	1220-	S	21570407	For lang gangtid under	1220/POM	PPM	1220/P	PLAN	#	PRCO	M	06.06.2010	31.12.2010
	1220-	S	21674576	Lavt N2-trykk på	1220/POM	SOP	1220/P	#	#	RDEX	M	22.10.2010	21.02.2011
	1220-	S	22031956	Instrumentet flakker	1220/POM	SOP	1220/P	#	#	RDEX	M	02.03.2011	01.04.2011
	1220-	S	21949832	Intern PSV på pumpe	1220/POM	SOP	1220/P	#	#	RDEX	M	09.12.2010	08.01.2011
	1220-	S	21460265	Lekkasje gjennom	1220/POM	SOP	1220/P	#	#	RDEX	M	02.01.2010	01.02.2011
	1220-	S	21997027	Open drain pumpe P31	1220/POM	PPM	1220/P	PLAN	#	PRCO	M	01.02.2011	03.03.2011
	1220-	S	21482435	Lekkasje i mekanisk	1220/POM	SOP	1220/P	#	#	PRCO	L	29.01.2010	28.12.2010
	1220-	D	22083175	Pumpe starter ikke.	1220/POM	SOP	1220/P	#	#	RDEX	M	22.04.2011	22.05.2011
	1220-	D	22080070	Dieselmotor på	1220/POM	PPM	1220/P	PLAN	#	RDEX	H	15.04.2011	20.04.2011
	1220-	S	22084993	Montere overhalt	1220/POM	PPM	1220/P	PLAN	#	PRCO	M	26.04.2011	26.05.2011
	1220-	S	21960647	Feil på heater, varmer	1220/POM	SOP	1220/P	#	#	PRCO	M	18.12.2010	17.01.2011
	1220-	S	22066400	Jordfeil brannpumpe E	1220/POM	PPM	1220/P	PLAN	#	RDEX	M	31.03.2011	30.04.2011
	1220-	S	21970581	Oljelekkasje i simering	1220/POM	SOP	1220/P	#	#	PRCO	M	06.01.2011	05.02.2011
	1220-	S	21969797	Oljelekkasje i simering	1220/POM	SOP	1220/P	#	#	RDEX	M	05.01.2011	04.02.2011
	1220-	S	21970963	Oljelekkasje i simering	1220/POM	SOP	1220/P	#	#	RDEX	M	06.01.2011	05.02.2011
	1220-	S	21881003	Luftlekkasje manifold B	1220/POM	SOP	1220/P	#	#	RDEX	L	29.11.2010	28.05.2011
	1220-	S	21674571	Testing av PCV'er på	1220/POM	SOP	1220/P	#	#	RDEX	M	23.10.2010	22.02.2011

A.8 Fortsettelse: CMR Sikkerhetskritisk Korrektivt Vedlikehold - 30 dager

1220-	S	22025720	Drain ventil lekker	1220/POM	SOP	1220/P	#	#	PREP	M	20.02.2011	22.03.2011
1220-	S	21648806	Intern lekk ut til dysene.	1220/POM	SOP	1220/P	#	#	RDEX	M	25.09.2010	25.05.2011
1220-	S	21624662	Uidentifisert lekkasje.	1220/POM	SOP	1220/P	#	#	RDEX	M	25.08.2010	24.02.2011
1220-	S	21713521	Pakkbokslekkasje på	1220/POM	SOP	1220/P	#	#	RDEX	M	21.11.2010	21.12.2010
1220-	S	22000995	Lekk. gjennom stengt	1220/POM	SOP	1220/P	#	#	RDEX	M	04.02.2011	06.03.2011
1220-	S	22019258	Lekker i begge	1220/POM	SOP	1220/P	#	#	PRCO	M	13.02.2011	15.03.2011
1220-	S	22019257	Mangler et munnstykke	1220/POM	SOP	1220/P	#	#	PRCO	M	13.02.2011	15.03.2011
1220-	S	22019255	lekkasje/stenger ikke	1220/POM	SOP	1220/P	#	#	RDEX	M	13.02.2011	15.03.2011
1220-	S	22019254	lekker/stenger ikke +	1220/POM	SOP	1220/P	#	#	RDEX	M	13.02.2011	15.03.2011
1220-	S	22019253	Lekkasje/stenger ikke	1220/POM	SOP	1220/P	#	#	RDEX	M	13.02.2011	15.03.2011
1220-	S	22019251	lekkasje/stenger ikke	1220/POM	SOP	1220/P	#	#	RDEX	M	13.02.2011	15.03.2011
1220-	S	22019248	lekkasje/stenger ikke	1220/POM	SOP	1220/P	#	#	RDEX	M	13.02.2011	15.03.2011
1220-	S	21969218	Lekkasje på	1220/LOG	SOP	1220/P	#	#	PREP	M	04.01.2011	03.02.2011
1220-	S	21968132	Rustutslag i kranbom	1220/LOG	SIP	1220/P	#	#	PRCO	M	01.01.2011	31.01.2011
1220-	S	21607134	Wireskive bomløft	1220/LOG	SOP	1220/P	#	#	RDEX	M	27.07.2010	26.02.2011
1220-	D	22087129	Vifte til vannkjøler	1220/LOG	POM	1220/P	PLAN	#	PRCO	H	30.04.2011	05.05.2011
1220-	S	21671730	Synlige partikler i oljen	1220/LOG	PPM	1220/P	PLAN	#	RDEX	M	18.10.2010	17.02.2011
1220-	S	21972547	Finne årsak til skum i	1220/LOG	SOP	1220/P	#	#	PREP	M	07.01.2011	06.02.2011
1220-	S	21631965	Davit kan ikke svinges,	1220/LOG	SOP	1220/P	#	#	RDEX	M	04.09.2010	04.02.2011
1220-	S	21964118	åpner, men lukker ikke.	1220/LOG	SOP	1220/P	#	#	RDEX	M	26.12.2010	25.01.2011
1220-	S	22077159	Rorindikator virker ikke	1220/LOG	SOP	1220/P	#	#	RDEX	M	10.04.2011	10.05.2011
1220-	S	21669213	Medisinsk oxygen	1220/LOG	SOP	1220/P	#	#	PRCO	M	15.10.2010	14.12.2010
1220-	S	22042827	Deksel til nøddusj er	1220/LOG	SOP	1220/P	#	#	PREP	M	13.03.2011	12.04.2011
1220-	S	21559875	Røykmasker må bytes.	1220/LOG	SOP	1220/P	#	#	RDEX	M	13.05.2010	12.02.2011
1220-8"	S	22071524	Korrosjon på 8"-DO-	1220/POM	PPM	1220/C	PLAN	#	RDEX	M	01.04.2011	31.05.2011
1220-	S	21544669	Lav temperatur på	1220/POM	SOP	1220/P	#	#	RDEX	M	25.04.2010	25.11.2010
1220-	S	21108945	Radiatorvifte motor er	1220/G-SG1	SOP	1220/P	#	#	PRCO	M	05.08.2008	30.03.2011
1220-	S	21108944	Radiatorvifte motor er	1220/G-SG1	SOP	1220/P	#	#	PRCO	M	05.08.2008	30.03.2011
1220-	S	21578520	Hull i kjøler til	1220/POM	SOP	1220/P	#	#	PREP	M	13.06.2010	01.04.2011
1220-	S	21680876	Foreløpig leveranse (fra	1220/POM	PPM	1220/P	PLAN	#	PRCO	M	03.11.2010	01.03.2011
1220-	S	21674567	Jordfeil ESD node	1220/POM	PPM	1220/P	PLAN	#	RDEX	M	24.10.2010	23.12.2010
1220-	S	22086657	Ettertrekke	1220/POM	SOP	1220/P	#	#	PREP	M	28.04.2011	28.05.2011
1220-	D	22087078	Ballast nettverk A ute	1220/POM	POM	1220/IM	PLAN	#	STRT	H	30.04.2011	05.05.2011
1220-	S	22078404	Armatyr lyser ikke	1220/LOG	PPM	1220/P	PLAN	#	RDEX	M	12.04.2011	12.05.2011
1220-	S	22083136	Defekt ljuskastar F31	1220/POM	PPM	1220/P	PLAN	#	RDEX	M	23.04.2011	23.05.2011
1220-	S	22061728	Innfesting til skap iferd	1220/LOG	PPM	1220/P	PLAN	#	RDEX	M	23.03.2011	22.04.2011
1220-	D	22086898	Flammedetektor ligger i	1220/POM	POM	1220/P	PLAN	#	RDEX	H	30.04.2011	05.05.2011
1220-	S	22084702	Jordingsskinne i boks	1220/POM	SOP	1220/P	#	#	PREP	M	25.04.2011	25.05.2011
1220-	S	22071802	Rustne klemmer i	1220/POM	PPM	1220/P	PLAN	#	RDEX	M	07.04.2011	07.05.2011
1220-	S	21680981	Vaninntregning i PA-	1220/POM	SOP	1220/P	#	#	STRT	L	03.11.2010	02.05.2011
1220-	D	22022174	Vindmåler virker ikke -	1220/LOG	SOP	1220/P	#	#	PRCO	H	15.02.2011	20.02.2011

